

# R3000

Industrial Dual SIM Cellular VPN Router

2 Eth + 1 RS-232 + 1 RS-485 + 1 USB Host



robustOS

Guangzhou Robustel LTD

[www.robustel.com](http://www.robustel.com)

## About This Document

This document provides hardware and software information of the Robustel R3000 Router, including introduction, installation, configuration and operation.

**Copyright©2019 Guangzhou Robustel LTD**

**All rights reserved.**

## Trademarks and Permissions

robustel, robustOS are trademarks of Guangzhou Robustel LTD. All other trademarks and trade names mentioned in this document are the property of their respective owners.

## Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner. The contents of this document are subject to change without notice due to continued progress in methodology, design and manufacturing. Robustel shall have no liability for any error or damage of any kind resulting from the use of this document.

## Technical Support

Tel: +86-20-29019902

Fax: +86-20-82321505

Email: [support@robustel.com](mailto:support@robustel.com)

Web: [www.robustel.com](http://www.robustel.com)

## Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the router is used in a normal manner with a well-constructed network, the router should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Robustel accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the router, or for failure of the router to transmit or receive such data.

## Safety Precautions

### General

- The router generates radio frequency (RF) power. When using the router, care must be taken on safety issues related to RF interference as well as regulations of RF equipment.
- Do not use your router in aircraft, hospitals, petrol stations or in places where using cellular products is prohibited.
- Be sure that the router will not be interfering with nearby equipment. For example: pacemakers or medical equipment. The antenna of the router should be away from computers, office equipment, home appliance, etc.
- An external antenna must be connected to the router for proper operation. Only uses approved antenna with the router. Please contact authorized distributor on finding an approved antenna.
- Always keep the antenna with minimum safety distance of 20 cm or more from human body. Do not put the antenna inside metallic box, containers, etc.
- When used, the device needs a suitable environment.
  1. If indoors, it needs to be provided an indoor enclosure.
  2. If outdoors, it needs to be provided a rain proof enclosure.
- RF exposure statements
  1. For mobile devices without co-location (the transmitting antenna is installed or located more than 20cm away from the body of user and nearby person)
- FCC RF Radiation Exposure Statement
  1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
  2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and human body.

**Note:** Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Router may be used at this time.

### Using the Router in Vehicle

- Check for any regulation or law authorizing the use of cellular devices in vehicle in your country before installing the router.
- The driver or operator of any vehicle should not operate the router while driving.
- Install the router by qualified personnel. Consult your vehicle distributor for any possible interference of electronic parts by the router.
- The router should be connected to the vehicle's supply system by using a fuse-protected terminal in the vehicle's fuse box.
- Be careful when the router is powered by the vehicle's main battery. The battery may be drained after extended period.

## Protecting Your Router

To ensure error-free usage, please install and operate your router with care. Do remember the following:

- Do not expose the router to extreme conditions such as high humidity / rain, high temperature, direct sunlight, caustic / harsh chemicals, dust, or water.
- Do not try to disassemble or modify the router. There is no user serviceable part inside and the warranty would be void.
- Do not drop, hit or shake the router. Do not use the router under extreme vibrating conditions.
- Do not pull the antenna or power supply cable. Attach/detach by holding the connector.
- Connect the router only according to the instruction manual. Failure to do it will void the warranty.
- In case of problem, please contact authorized distributor.

## Regulatory and Type Approval Information

**Table 1:** Directives

|            |                                                                                                                                                                                                                               |                                                                                     |
|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| 2011/65/EU | The European RoHS2.0 2011/65/EU Directive was issued by the European parliament and the European Council on 1 July 2011 on the restriction of the use of certain Hazardous substances in electrical and electronic equipment. |  |
| 2012/19/EU | The European WEEE 2012/19/EU Directive was issued by the European parliament and the European Council on 24 July 2012 on waste electrical and electronic equipment.                                                           |  |
| 2013/56/EU | The European 2013/56/EU Directive is a battery Directive which published in the EU official gazette on 10 December 2013. The button battery used in this product conforms to the standard of 2013/56/EU directive.            |                                                                                     |

**Table 2:** Standards of the electronic industry of the People's Republic of China

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SJ/T<br>11363-2006 | <p>The electronic industry standard of the People's Republic of China SJ/T 11363-2006 "Requirements for Concentration Limits for Certain Toxic and Hazardous Substances in Electronic Information Products" issued by the ministry of information industry of the People's Republic of China on November 6, 2006, stipulates the maximum allowable concentration of toxic and hazardous substances in electronic information products.</p> <p>Please see <b>Table 3</b> for an overview of toxic or hazardous substances or elements that might be contained in product parts in concentrations above the limits defined by SJ/T 11363-2006.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| SJ/T<br>11364-2014 | <p>The electronic industry standard of the People's Republic of China SJ/T 11364-2014 "Labeling Requirements for Restricted Use of Hazardous Substances in Electronic and Electrical Products" issued by the ministry of Industry and information technology of the People's Republic of China on July 9, 2014, stipulates the Labeling requirements of hazardous substances in electronic and electrical products, environmental protection use time limit and whether it can be recycled. This standard is applicable to electronic and electrical products sold within the territory of the People's Republic of China, and can also be used for reference in the logistics process of electronic and electrical products.</p> <p>The orange logo below is used for Robustel products:</p> <div style="text-align: right;">  </div> <p>Indicates its warning attribute, that is, some hazardous substances are contained in the product. The "10" in the middle of the legend refers to the environment-friendly Use Period (EFUP) * of electronic information product, which is 10 years. It can be used safely during the environment-friendly Use Period. After the environmental protection period of use, it should enter the recycling system.</p> <p>*The term of environmental protection use of electronic information products refers to the term during which the toxic and hazardous substances or elements contained in electronic information products will not be leaked or mutated and cause serious pollution to the environment or serious damage to people and property under normal conditions of use.</p> |

**Table 3:** Toxic or Hazardous Substances or Elements with Defined Concentration Limits

| Name of the Part                                                                                                                                                                                                                                                                                                                                                | Hazardous Substances |      |      |          |       |        |        |       |       |        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|------|------|----------|-------|--------|--------|-------|-------|--------|
|                                                                                                                                                                                                                                                                                                                                                                 | (Pb)                 | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) | (DEHP) | (BBP) | (DBP) | (DIBP) |
| Metal parts                                                                                                                                                                                                                                                                                                                                                     | o                    | o    | o    | o        | o     | o      | o      | o     | o     | o      |
| Circuit modules                                                                                                                                                                                                                                                                                                                                                 | o                    | o    | o    | o        | o     | o      | o      | o     | o     | o      |
| Cables and cable assemblies                                                                                                                                                                                                                                                                                                                                     | o                    | o    | o    | o        | o     | o      | o      | o     | o     | o      |
| Plastic and polymeric parts                                                                                                                                                                                                                                                                                                                                     | o                    | o    | o    | o        | o     | o      | o      | o     | o     | o      |
| <p>o:<br/>Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in RoHS2.0.</p> <p>X:<br/>Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials for this part <i>might exceed</i> the limit requirement in RoHS2.0.</p> |                      |      |      |          |       |        |        |       |       |        |

## Document History

Updates between document versions are cumulative. Therefore, the latest document version contains all updates made to previous versions.

| Date          | Firmware Version | Document Version | Change Description                                                                                                                                                             |
|---------------|------------------|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mar. 27, 2017 | 3.0.0            | v.4.0.0          | Initial release                                                                                                                                                                |
| Jul. 17, 2017 | 3.0.0            | v.4.0.1          | <ul style="list-style-type: none"> <li>Updated pictures in Chapter 2</li> <li>Updated OpenVPN configuration in Chapter 4.3.2</li> <li>Other minor editorial changes</li> </ul> |
| Jul. 20, 2017 | 3.0.0            | v.4.0.2          | Updated the description of DI/DO interface                                                                                                                                     |
| Aug. 11, 2017 | 3.0.0            | v.4.0.4          | Added the new model R3000-NU to the ordering information                                                                                                                       |
| Feb.26, 2018  | 3.0.5            | v.4.0.8          | Updated firmware                                                                                                                                                               |
| Jun. 29, 2018 | 3.0.5            | v.4.0.9          | Revised the company name                                                                                                                                                       |
| Jan. 29, 2019 | 3.0.5            | v.4.0.15         | <ul style="list-style-type: none"> <li>Revised the certifications</li> <li>Revised the Frequency bands of Wifi</li> </ul>                                                      |
| Jul. 22, 2019 | 3.0.5            | v.4.1.0          | <ul style="list-style-type: none"> <li>Revised the description of enclosure</li> <li>Revised the Regulatory and Type Approval Information</li> </ul>                           |
| Sep. 23, 2019 | 3.0.5            | v.4.1.1          | <ul style="list-style-type: none"> <li>Revised the Approvals</li> </ul>                                                                                                        |
| Oct. 23, 2019 | 3.0.5            | v.4.1.2          | <ul style="list-style-type: none"> <li>Added the DNP3 Transparent to Serial port</li> <li>Added the Storage Temperature</li> </ul>                                             |

## Contents

|                  |                                               |           |
|------------------|-----------------------------------------------|-----------|
| <b>Chapter 1</b> | <b>Product Overview .....</b>                 | <b>10</b> |
| 1.1              | Key Features .....                            | 10        |
| 1.2              | Package Contents .....                        | 11        |
| 1.3              | Specifications .....                          | 13        |
| 1.4              | Dimensions.....                               | 16        |
| 1.5              | Ordering Information .....                    | 16        |
| 1.6              | Warning .....                                 | 17        |
| <b>Chapter 2</b> | <b>Hardware Installation.....</b>             | <b>18</b> |
| 2.1              | PIN Assignment .....                          | 18        |
| 2.2              | LED Indicators.....                           | 19        |
| 2.3              | USB Interface.....                            | 20        |
| 2.4              | Reset Button.....                             | 21        |
| 2.5              | Ethernet Ports .....                          | 22        |
| 2.6              | Insert or Remove SIM Card/Micro SD Card ..... | 23        |
| 2.7              | Attach External Antenna (SMA Type).....       | 24        |
| 2.8              | Mount the Router .....                        | 24        |
| 2.9              | Ground the Router .....                       | 26        |
| 2.10             | Connect the Router to a Computer.....         | 27        |
| 2.11             | Power Supply.....                             | 27        |
| <b>Chapter 3</b> | <b>Initial Configuration .....</b>            | <b>28</b> |
| 3.1              | Configure the PC.....                         | 28        |
| 3.2              | Factory Default Settings .....                | 31        |
| 3.3              | Log in the Router .....                       | 31        |
| 3.4              | Control Panel.....                            | 32        |
| 3.5              | Status.....                                   | 33        |
| 3.6              | Interface > Link Manager .....                | 35        |
| 3.7              | Interface > LAN.....                          | 46        |
| 3.8              | Interface > Ethernet .....                    | 50        |
| 3.9              | Interface > Cellular .....                    | 52        |
| 3.10             | Interface > WiFi .....                        | 56        |
| 3.11             | Interface > USB.....                          | 62        |
| 3.12             | Interface > DI/DO .....                       | 63        |
| 3.13             | Interface > Serial Port.....                  | 67        |
| 3.14             | Network > Route .....                         | 71        |
| 3.15             | Network > Firewall .....                      | 72        |
| 3.16             | Network > IP Passthrough .....                | 77        |
| 3.17             | VPN > IPsec.....                              | 78        |
| 3.18             | VPN > OpenVPN .....                           | 86        |
| 3.19             | VPN > GRE .....                               | 94        |
| 3.20             | Services > Syslog.....                        | 95        |
| 3.21             | Services > Event.....                         | 97        |
| 3.22             | Services > NTP .....                          | 100       |
| 3.23             | Services > SMS.....                           | 101       |

|                      |                                    |            |
|----------------------|------------------------------------|------------|
| 3.24                 | Services > Email.....              | 102        |
| 3.25                 | Services > DDNS .....              | 103        |
| 3.26                 | Services > SSH.....                | 104        |
| 3.27                 | Services > GPS .....               | 105        |
| 3.28                 | Services > Web Server .....        | 109        |
| 3.29                 | Services > Advanced.....           | 110        |
| 3.30                 | System > Debug.....                | 112        |
| 3.31                 | System > Update .....              | 113        |
| 3.32                 | System > App Center .....          | 114        |
| 3.33                 | System > Tools .....               | 115        |
| 3.34                 | System > Profile.....              | 117        |
| 3.35                 | System > User Management .....     | 119        |
| <b>Chapter 4</b>     | <b>Configuration Examples.....</b> | <b>121</b> |
| 4.1                  | Interface .....                    | 121        |
| 4.1.1                | Console Port .....                 | 121        |
| 4.1.2                | Digital Input .....                | 122        |
| 4.1.3                | Digital Output .....               | 122        |
| 4.1.4                | RS-232.....                        | 123        |
| 4.1.5                | RS-485.....                        | 123        |
| 4.2                  | Cellular .....                     | 124        |
| 4.2.1                | Cellular Dial-Up .....             | 124        |
| 4.2.2                | SMS Remote Control .....           | 126        |
| 4.3                  | Network.....                       | 128        |
| 4.3.1                | IPsec VPN .....                    | 128        |
| 4.3.2                | OpenVPN .....                      | 132        |
| 4.3.3                | GRE VPN.....                       | 134        |
| <b>Chapter 5</b>     | <b>Introductions for CLI.....</b>  | <b>136</b> |
| 5.1                  | What Is CLI.....                   | 136        |
| 5.2                  | How to Configure the CLI .....     | 137        |
| 5.3                  | Commands Reference .....           | 143        |
| <b>Glossary.....</b> |                                    | <b>144</b> |

# Chapter 1 Product Overview

## 1.1 Key Features

The Robustel Industrial Dual SIM Cellular VPN Router (R3000) is a rugged cellular router offering state-of-the-art mobile connectivity for machine to machine (M2M) applications.

R3000 is a powerful router developed from RobustOS, a Robustel self-developed and Linux-based operating system which is designed to be used in Robustel devices. The RobustOS includes basic networking features and protocols providing customers with a very good user experience. Meanwhile, Robustel offers a Software Development Kit (SDK) for partners and customers to allow additional customization by using C, Python or Java. It also provides rich Apps to meet fragmented IoT market demands.

- The feature *Link Manager* supporting Cellular WAN, Ethernet WAN, WLAN WAN link backup and ICMP detection
- The option *Backup Mode* supporting cold, warm and load balancing
- WiFi supporting AP mode and Client modes (2.4 GHz/5 GHz), also supporting Captive Portal
- RobustOS + SDK + App
- IPsec/OpenVPN/GRE/L2TP/PPTP/DMVPN
- Supporting DHCP server
- Supporting 802.1 Q VLAN Trunk
- Supporting IP Pass-through
- Supporting Modbus gateway (Modbus RTU to Modbus TCP) and Modbus Master
- Supporting TCP Client/Server, UDP and virtual serial port
- Management and maintenance via Web/CLI/SMS/USB/RobustLink Cloud
- Supporting RobustVPN, a Cloud VPN Portal providing easy and secure remote access for PLCs and machines
- Supporting RobustLink, a centralized M2M management platform for remote monitoring, configuration and firmware update
- Auto reboot via SMS/Timing
- Robust industrial design (9 to 60V DC, desktop or wall mounting or DIN rail mounting)

## 1.2 Package Contents

Before installing your R3000 Router, verify the kit contents as following.

**Note:** The following pictures are for illustration purposes only, not based on their actual sizes.

- 1 x Robustel R3000 Industrial Dual SIM Cellular VPN Router (GPS/WiFi optional)



With WiFi and GPS



Only with GPS



Only with WiFi



Without WiFi and GPS


- 1 x 3-pin 5 mm male terminal block with lock for power supply



- 1 x 7-pin 3.5 mm male terminal block with lock for serial port, I/O and console port



- 1 x *Quick Start Guide* with download link of other documents or tools



**Note:** If any of the above items is missing or damaged, please contact your Robustel sales representative.

**Optional Accessories** (sold separately):

- 3G/4G SMA cellular antenna (stubby/magnet optional)

Stubby antenna



Magnet antenna



- RP-SMA WiFi antenna (stubby/magnet optional)

Stubby antenna



Magnet antenna



- Wall mounting kit



- 35 mm DIN rail mounting kit



- Ethernet cable



- AC/DC power adapter (12V DC, 1.5 A; EU/US/UK/AU plug optional)



## 1.3 Specifications

### Cellular Interface

- Number of antennas: 2 (MAIN + AUX)
- Connector: SMA female
- SIM: 2 (3.0 V & 1.8 V)
- Standards: GSM/GPRS/EDGE/WCDMA/HSDPA/HSUPA/HSPA+/DC-HSPA+/TD-SCDMA/CDMA (CDMA 1X/EVDO)/FDD LTE/TDD LTE
  - GSM: max DL/UL = 9.6/2.7 Kbps
  - GPRS: max DL/UL = 86 Kbps
  - EDGE: max DL/UL = 236.8 Kbps
  - WCDMA/TD-SCDMA: max DL/UL = 2.8 Mbps/384 Kbps
  - EVDO: max DL/UL = 5.4 Mbps/14.7 Kbps
  - HSPA+: max DL/UL = 21/5.76 Mbps, fallback to 2G
  - DC-HSPA+: max DL/UL = 42/5.76 Mbps, fallback to 2G
  - FDD LTE: max DL/UL = 100/50 Mbps, fallback to 2G/3G
  - TDD LTE: max DL/UL = 100/50 Mbps, fallback to 2G/3G

### Ethernet Interface

- Number of ports: 2 x 10/100 Mbps, 2 x LAN or 1 x LAN + 1 x WAN
- Magnet isolation protection: 1.5 KV

### WiFi Interface (Optional)

- Number of antennas: 1
- Connector: RP-SMA, male
- Standards: 802.11a/b/g/n, supporting AP and Client modes
- Frequency bands: 2.4 GHz  
5 GHz
- Security: Open ,WPA, WPA2, WEP
- Encryption: AES, TKIP, WEP64
- Data speed: Up to 150 Mbps

- Receiving sensitivity: 1 M -97 dBm (< 8% PER)
- (+/- 1 dBm) 54 Mbps -76.5 dBm (< 10% PER)
- MCS7 (20 MHz) -72 dBm (< 10% PER)
- MCS7 (40 MHz) -69 dBm (< 10% PER)

#### GPS/GLONASS Interface (Optional)

- Number of antennas: 1
- Connector: SMA female with 50 ohms impedance
- Tracking sensitivity: GPS: greater than -148 dBm  
GLONASS: greater than -140 dBm
- Horizontal position accuracy: GPS: 2.5 m  
GLONASS: 4.0 m
- Protocol: NMEA-0183 V2.3

#### Serial Interface

- Number of ports: 1 x RS-232 + 1 x RS-485 or 2 x RS-232 or 2 x RS-485
- Connector: 7-pin 3.5 mm female socket with lock
- ESD protection:  $\pm 15$  KV
- Baud rate: 300 bps to 230400 bps
- Parameters: 8E1, 8O1, 8N1, 8N2, 7E2, 7O2, 7N2, 7E1
- RS-232: TxD, RxD, RTS, CTS, GND
- RS-485: Data+ (A), Data- (B)

#### DI/DO

- Type: 2 x DI (dry contact) + 2 x DO (wet contact), 4 x DI, 4 x DO, 3 x DI + 1 x DO or 3 x DO + 1 x DI
- Connector: 7-pin 3.5 mm female socket with lock
- Isolation: 3KVDC or 2KVrms
- Absolute maximum VDC: "V+" +5V DC (DI), 30V DC (DO)
- Absolute maximum ADC: 300 mA

#### Others

- 1 x RST button
- 1 x Micro SD interface
- 1 x USB 2.0 host up to 480 Mbps
- 1 x CLI interface
- LED indicators - 1 x RUN, 1 x PPP, 1 x USB, 1 x RSSI, 1 x NET, 1 x SIM

#### Software (Basic features of RobustOS)

- Network protocols: PPP, PPPoE, TCP, UDP, DHCP, ICMP, NAT, HTTP, HTTPs, DNS, ARP, NTP, SMTP, Telnet, VLAN, SSH2, DDNS, etc.
- VPN tunnel: IPsec, OpenVPN, GRE
- Firewall: DMZ, anti-DoS, Filtering (IP/Domain name/MAC address), Port Mapping, Access Control
- Management: Web, CLI, SMS
- Serial port: Transparent, DNP3 Transparent, TCP Client/Server, UDP, Modbus RTU Gateway

**App Center** (Available Apps for RobustOS)

- Apps\*: L2TP, PPTP, DMVPN, RobustVPN, VRRP, QoS, SNMP, Language, RobustLink

\*Request on demand. For more Apps please visit [www.robustel.com](http://www.robustel.com).

**Power Supply and Consumption**

- Connector: 3-pin 5 mm female socket with lock
- Input voltage: 9 to 60V DC
- Power consumption: Idle: 100 mA@12 V  
Data link: 400 mA (peak) @12 V


**Physical Characteristics**

- Ingress protection: IP30
- Housing & Weight: Metal, 570 g
- Dimensions: 125 x 104 x 43.5 mm
- Installations: Desktop, wall mounting or 35 mm DIN rail mounting

**Approvals**

- Regulatory: CE, NBTC, FCC, RCM, PTCRB, GCF, IC, TRA, IMDA, EAC, Anatel, UL, CB, ICASA
- Carrier: AT&T, Rogers, Vodafone
- Application: E-mark (Vehicle), IEC 61000-4-12 (Electromagnetic Compatibility - Oscillatory Waves Immunity Test), EN50155 (Railway Applications - Electronic equipment used on rolling stock)
- Environmental: RoHS2.0, WEEE
- EMI: EN 55032: 2012/AC: 2013 (CE & RE) Class B
- EMS: IEC 61000-4-2 (ESD) Level 4  
IEC 61000-4-3 (RS) Level 4  
IEC 61000-4-4 (EFT) Level 4  
IEC 61000-4-5 (Surge) Level 3  
IEC 61000-4-6 (CS) Level 2  
IEC 61000-4-8 (M/S) Level 4

## 1.4 Dimensions



## 1.5 Ordering Information

| Model                    | R3000-3P                                | R3000-4L                                                                                                                                                                   | R3000-NU        |
|--------------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Router Type              | HSPA+ router                            | LTE router                                                                                                                                                                 | Wireline Router |
| Air Interface            | GSM/GPRS/EDGE/<br>HSDPA/HSUPA/<br>HSPA+ | GSM/GPRS/EDGE/WCDMA/HSDPA/HSUPA/<br>HSPA+/DC-HSPA+/TD-SCDMA/CDMA (CDMA<br>1X/EVDO)/FDD LTE/TDD LTE                                                                         | --              |
| Frequency Bands<br>4G*   | --                                      | AU: B1/B3/B5/B7/B8/B28, B40<br>EU: B1/B3/B7/B8/B20/B28/B31, B38/B40<br>US: B2/B4/B5/B13/B17/B25, B41<br>JP: B1/B3/B8/B9/B18/B19/B21/B28, B41<br>CN: B1/B3, B38/B39/B40/B41 | --              |
| 3G                       | B1/B2/B4(AWS)/B5<br>/B8/B19             | WCDMA/HSDPA/HSUPA/HSPA+/DC-HSPA+:<br>B1/B2/B5/B6/B8/B9/B19<br>TD-SCDMA: B34/B39<br>CDMA (CDMA 1X/EVDO): R0/A BC0/BC1/BC10                                                  | --              |
| 2G                       | 850/900/1800/<br>1900 MHz               | 850/900/1800/1900 MHz                                                                                                                                                      | --              |
| Operating<br>Temperature | -40 to +75 °C                           | -40 to +75 °C                                                                                                                                                              | -40 to +75 °C   |
| Storage<br>Temperature   | -40 to +85 °C                           | -40 to +85 °C                                                                                                                                                              | -40 to +85 °C   |
| Relative Humidity        | 5 to 95% RH                             | 5 to 95% RH                                                                                                                                                                | 5 to 95% RH     |

\*For more information about 4G frequency bands in different countries, please contact your Robustel sales representative.


## 1.6 Warning

WARNING – EXPLOSION HAZARD. DO NOT REMOVE OR REPLACE WHILE CIRCUIT IS LIVE UNLESS THE AREA IS FREE OF IGNITIBLE CONCENTRATIONS.


AVERTISSEMENT — RISQUE D'EXPLOSION. NE PAS RETIRER OU REMPLACER LORSQUE LE CIRCUIT EST SOUS TENSION, À MOINS QUE LE MILIEU SOIT LIBRE DE SUBSTANCES INFLAMMABLES CONCENTRÉES.

# Chapter 2 Hardware Installation


## 2.1 PIN Assignment



| PIN | Debug | RS-232 | Direction      |
|-----|-------|--------|----------------|
| 1   | CR    | --     | R3000 ← Device |
| 2   | CT    | --     | R3000 → Device |
| 3   | GND   | GND    | --             |
| 4   | --    | TXD    | R3000 → Device |
| 5   | --    | RXD    | R3000 ← Device |
| 6   | --    | RTS    | R3000 → Device |
| 7   | --    | CTS    | R3000 ← Device |



| PIN | Power    |
|-----|----------|
| 8   | Positive |
| 9   | Negative |
| 10  | GND      |



| PIN | DI/DO    | RS-485    | Direction      |
|-----|----------|-----------|----------------|
| 11  | Input 1  | --        | R3000 ← Device |
| 12  | Input 2  | --        | R3000 ← Device |
| 13  | Output 1 | --        | R3000 → Device |
| 14  | Output 2 | --        | R3000 → Device |
| 15  | GND      | --        | --             |
| 16  | --       | Data+(A)  | R3000 ↔ Device |
| 17  | --       | Data- (B) | R3000 ↔ Device |

## 2.2 LED Indicators



| Name        | Color  | Status                                     | Description                                      |
|-------------|--------|--------------------------------------------|--------------------------------------------------|
| RUN         | Green  | On, fast blinking<br>(250 mSec blink time) | Router is powered on<br>(System is initializing) |
|             |        | On, blinking<br>(500 mSec blink time)      | Router starts operating                          |
|             |        | Off                                        | Router is powered off                            |
| PPP         | Green  | On, solid                                  | Link connection is working                       |
|             |        | Off                                        | Link connection is not working                   |
| USR-OpenVPN | Green  | On, solid                                  | OpenVPN connection is established                |
|             |        | Off                                        | OpenVPN connection is not established            |
| USR-IPsec   | Green  | On, solid                                  | IPsec connection is established                  |
|             |        | Off                                        | IPsec connection is not established              |
| USR-WiFi    | Green  | On, solid                                  | WiFi is enabled and working properly             |
|             |        | Off                                        | WiFi is disabled or not working properly         |
|             | Green  | On, solid                                  | High Signal strength (21-31) is available        |
|             | Yellow | On, solid                                  | Medium Signal strength (11-20) is available      |
|             | Red    | On, solid                                  | Low Signal strength (1-10) is available          |
|             | --     | Off                                        | No signal                                        |
| NET         | Green  | On, solid                                  | Connection to 4G network is established          |
|             | Yellow | On, solid                                  | Connection to 3G network is established          |

|     |       |              |                                                          |
|-----|-------|--------------|----------------------------------------------------------|
|     | Red   | On, solid    | Connection to 2G network is established                  |
|     | --    | Off          | Connection to network is not established or establishing |
| SIM | Green | On, blinking | Backup card is being used                                |
|     |       | Off          | Main card is being used                                  |

**Note:** You can choose the display type of USR LED. For more details, please refer to **3.29 Service > Advanced**.

## 2.3 USB Interface



| Function         | Operation                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Firmware upgrade | USB interface is used for batch firmware upgrading, but cannot be used for sending or receiving data from slave devices which connected to it. You can insert a USB storage device into the router's USB interface, such as a U disk or a hard disk. If there have a supported configuration file or a router firmware in this USB storage device, the router will automatically update the configuration file or the firmware. For more details, see <b>3.11 Interface &gt; USB</b> . |

## 2.4 Reset Button



| Function                            | Operation                                                                                                                                                                                     |
|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Reboot                              | Press and hold the RST button for at least 5 seconds under the operating status.                                                                                                              |
| Restore to factory default settings | Wait for 5 seconds after powering up the router, press and hold the RST button until all six LEDs start blinking one by one, and release the button to return the router to factory defaults. |


## 2.5 Ethernet Ports



There are two Ethernet ports on R3000 Router, including ETH0 and ETH1. Each Ethernet port has two LED indicators. The yellow one is a link indicator, while the green one is a speed indicator. For details about status, see the table below.

| Indicator       | Status       | Description                   |
|-----------------|--------------|-------------------------------|
| Link indicator  | On, solid    | Connection is established     |
|                 | On, blinking | Data is being transferred     |
|                 | Off          | Connection is not established |
| Speed indicator | On, solid    | 100 Mbps mode                 |
|                 | Off          | 10 Mbps mode                  |

## 2.6 Insert or Remove SIM Card/Micro SD Card



Insert or remove the SIM/Micro SD card as shown in the following steps.

- **Insert SIM card/Micro SD card**

1. Make sure router is powered off.
2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot/SD card slot.
3. To insert SIM card/Micro SD card, press the card with finger until you hear a click and then tighten the screws associated with the cover by using a screwdriver.
4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.

- **Remove SIM card/Micro SD card**

1. Make sure router is powered off.
2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot/SD card slot.
3. To remove SIM card/Micro SD card, press the card with finger until it pops out and then take out the card.
4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.

**Note:**


1. Recommended torque for inserting is 0.5 N.m, and the maximum allowed is 0.7 N.m.
2. Use the specific card when the device is working in extreme temperature (temperature exceeding 40 °C), because the regular card for long-time working in harsh environment will be disconnected frequently.
3. Do not forget to twist the cover tightly to avoid being stolen.
4. Do not touch the metal of the card surface in case information in the card will lose or be destroyed.

5. Do not bend or scratch the card.
6. Keep the card away from electricity and magnetism.
7. Make sure router is powered off before inserting or removing the card.

## 2.7 Attach External Antenna (SMA Type)

Attach an external SMA antenna to the router's antenna connector and twist tightly. Make sure the antenna is within the correct frequency range provided by the ISP and with 50 Ohm impedance.

**Note:** Recommended torque for tightening is 0.35 N.m.



## 2.8 Mount the Router

The router can be placed on a desktop or mounted to a wall or a 35 mm DIN rail.



**Note:**

When used, the device needs a suitable environment.

1. If indoors, it needs to be provided an indoor enclosure.
2. If outdoors, it needs to be provided a rain proof enclosure.

**Two methods for mounting the router**


1. Wall mounting (measured in mm)




Use 3 pcs of M3\*4 flat head Phillips screws to fix the wall mounting kit to the router, and then use 2 pcs of M3 drywall screws to mount the router associated with the wall mounting kit on the wall.

**Note:** Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.

2. DIN rail mounting (measured in mm)






Use 3 pcs of M3\*6 flat head Phillips screws to fix the DIN rail to the router, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

**Note:** Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.

## 2.9 Ground the Router


Router grounding helps prevent the noise effect due to electromagnetic interference (EMI). Connect the router to the site ground wire by the ground screw before powering on.

**Note:** This product is appropriate to be mounted on a sound grounded device surface, such as a metal panel.



## 2.10 Connect the Router to a Computer


Connect an Ethernet cable to the port marked ETH0 or ETH1 at the front of the R3000 Router, and connect the other end of the cable to your computer.



## 2.11 Power Supply

### CONNECTING THE POWER CABLE

| COLOR  | POLARITY |
|--------|----------|
| RED    | +        |
| YELLOW | -        |



R3000 Router supports reverse polarity protection, but always refers to the figure above to connect the power adapter correctly. There are two cables associated with the power adapter. Following to the color of the head, connect the cable marked red to the positive pole through a terminal block, and connect the yellow one to the negative in the same way. The last step is to plug the power adapter into your socket.

**Note:** The range of power voltage is 9 to 60V DC.

## Chapter 3 Initial Configuration


The router can be configured through your web browser that including IE 8.0 or above, Chrome and Firefox, etc. A web browser is included as a standard application in the following operating systems: Linux, Mac OS, Windows 98/NT/2000/XP/Me/Vista/7/8, etc. It provides an easy and user-friendly interface for configuration. There are various ways to connect the router, either through an external repeater/hub or connect directly to your PC. However, make sure that your PC has an Ethernet interface properly installed prior to connecting the router. You must configure your PC to obtain an IP address through a DHCP server or a fixed IP address that must be in the same subnet as the router. If you encounter any problems accessing the router web interface, it is advisable to uninstall your firewall program on your PC, as this tends to cause problems accessing the IP address of the router.

### 3.1 Configure the PC


There are two methods to get IP address for the PC. One is to obtain an IP address automatically from “Local Area Connection”, and another is to configure a static IP address manually within the same subnet of the router. Please refer to the steps below.

Here take **Windows 7** as example, and the configuration for windows system is similar.


1. Click **Start > Control panel**, double-click **Network and Sharing Center**, and then double-click **Local Area Connection**.



- Click **Properties** in the window of **Local Area Connection Status**.




- Choose **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.




#### 4. Two ways for configuring the IP address of PC

##### Obtain an IP address automatically:



##### Use the following IP address:

(Configured a static IP address manually within the same subnet of the router)



#### 5. Click **OK** to finish the configuration.

## 3.2 Factory Default Settings


Before configuring your router, you need to know the following default settings.

| Item        | Description                         |
|-------------|-------------------------------------|
| Username    | admin                               |
| Password    | admin                               |
| ETH0        | 192.168.0.1/255.255.255.0, LAN mode |
| ETH1        | 192.168.0.1/255.255.255.0, LAN mode |
| DHCP Server | Enabled                             |

## 3.3 Log in the Router


To log in to the management page and view the configuration status of your router, please follow the steps below.

1. On your PC, open a web browser such as Internet Explorer, Google and Firefox, etc.
2. From your web browser, type the IP address of the router into the address bar and press enter. The default IP address of the router is [192.168.0.1](https://192.168.0.1/), though the actual address may vary.



3. In the login page, enter the username and password, choose language and then click **LOGIN**. The default username and password are "admin".

**Note:** If enter the wrong username or password over six times, the login web will be locked for 5 minutes.




### 3.4 Control Panel

After logging in, the home page of the R3000 Router’s web interface is displayed, for example.



Using the original password to log in the router, the page will pop up the following tab



It is strongly recommended for security purposes that you change the default username and/or password. To change your username and/or password, see **3.35 System > User Management**.

| Control Panel |                                                                                                                                                                                                                      |                         |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Item          | Description                                                                                                                                                                                                          | Button                  |
| Save & Apply  | Click to save the current configuration into router’s flash and apply the modification on every configuration page, to make the modification taking effect.                                                          | <b>Save &amp; Apply</b> |
| Reboot        | Click to reboot the router. If the Reboot button is yellow, it means that some completed configurations will take effect only after reboot.                                                                          | <b>Reboot</b>           |
| Logout        | Click to log the current user out safely. After logging out, it will switch to login page. Shut down web page directly without logout, the next one can login web on this browser without a password before timeout. | <b>Logout</b>           |
| Submit        | Click to save the modification on current configuration page.                                                                                                                                                        | <b>Submit</b>           |
| Cancel        | Click to cancel the modification on current configuration page.                                                                                                                                                      | <b>Cancel</b>           |

**Note:** The steps of how to modify configuration are as bellow:

1. Modify in one page;
2. Click **Submit** under this page;
3. Modify in another page;
4. Click **Submit** under this page;
5. Complete all modification;
6. Click **Save & Apply**.

## 3.5 Status

This page allows you to view the System Information, Internet Status and LAN Status of your Router.

### System Information

| ^ System Information    |                          |
|-------------------------|--------------------------|
| <b>Device Model</b>     | R3000                    |
| <b>System Uptime</b>    | 0 days, 00:03:32         |
| <b>System Time</b>      | Mon Feb 26 14:46:56 2018 |
| <b>RAM Usage</b>        | 81M Free/128M Total      |
| <b>Firmware Version</b> | 3.0.5 (Rev 1042)         |
| <b>Hardware Version</b> | 1.2                      |
| <b>Kernel Version</b>   | 4.1.0                    |
| <b>Serial Number</b>    | 10201809021770           |

| System Information |                                                                |
|--------------------|----------------------------------------------------------------|
| Item               | Description                                                    |
| Device Model       | Show the model name of your device.                            |
| System Uptime      | Show the current amount of time the router has been connected. |
| System Time        | Show the current system time.                                  |
| RAM Usage          | Show the free memory and the total memory.                     |
| Firmware Version   | Show the firmware version running on the router.               |
| Hardware Version   | Show the current hardware version.                             |
| Kernel Version     | Show the current kernel version.                               |
| Serial Number      | Show the serial number of your device.                         |

## Internet Status

| ^ Internet Status  |                              |
|--------------------|------------------------------|
| <b>Active Link</b> | WWAN1                        |
| <b>Uptime</b>      | 0 days, 00:39:31             |
| <b>IP Address</b>  | 10.122.74.11/255.255.255.248 |
| <b>Gateway</b>     | 10.122.74.9                  |
| <b>DNS</b>         | 210.21.4.130 221.5.88.88     |

| Internet Status |                                                              |
|-----------------|--------------------------------------------------------------|
| Item            | Description                                                  |
| Active Link     | Show the current active link.                                |
| Uptime          | Show the current amount of time the link has been connected. |
| IP Address      | Show the IP address of current link.                         |
| Gateway         | Show the gateway address of the current link.                |
| DNS             | Show the current primary DNS server and secondary server.    |


## LAN Status

| ^ LAN Status       |                             |
|--------------------|-----------------------------|
| <b>IP Address</b>  | 192.168.0.1/255.255.255.240 |
| <b>MAC Address</b> | 34:FA:40:04:68:F0           |

| LAN Status  |                                                    |
|-------------|----------------------------------------------------|
| Item        | Description                                        |
| IP Address  | Show the IP address and the Netmask of the router. |
| MAC Address | Show the MAC address of the router.                |

### 3.6 Interface > Link Manager

This section allows you to setup the link connection.



| General Settings @ Link Manager |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |             |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Item                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Default     |
| Primary Link                    | Select from “WWAN1”, “WWAN2”, “WAN” or “WLAN”. <ul style="list-style-type: none"> <li>• WWAN1: Select to make SIM1 as the primary wireless link</li> <li>• WWAN2: Select to make SIM2 as the primary wireless link</li> <li>• WAN: Select to make WAN Ethernet port as the primary wired link<br/> <b>Note:</b> WAN link is available only if enable eth0 as WAN port in <b>Interface &gt; Ethernet &gt; Ports &gt; Port Settings</b>.</li> <li>• WLAN: Select to make WLAN as the primary wireless link<br/> <b>Note:</b> WLAN link is available only if enable WiFi as Client mode, please refer to <b>3.10 Interface &gt; WiFi</b>.</li> </ul>                                                 | WWAN1       |
| Backup Link                     | Select from “None”, “WWAN1”, “WWAN2”, “WAN” or “WLAN”. <ul style="list-style-type: none"> <li>• None: Do not select any backup link</li> <li>• WWAN1: Select to make SIM1 as backup wireless link</li> <li>• WWAN2: Select to make SIM2 as backup wireless link</li> <li>• WAN: Select to make WAN Ethernet port as the backup wired link<br/> <b>Note:</b> WAN link is available only if enable eth0 as WAN interface in <b>Interface &gt; Ethernet &gt; Ports &gt; Port Settings</b>.</li> <li>• WLAN: Select to make WLAN as the backup wireless link<br/> <b>Note:</b> WLAN link is available only if enable WiFi as Client mode, please refer to <b>3.10 Interface &gt; WiFi</b>.</li> </ul> | WWAN2       |
| Backup Mode                     | Select from “Cold Backup”, “Warm Backup” or “Load Balancing”. <ul style="list-style-type: none"> <li>• Cold Backup: The inactive link is offline on standby</li> <li>• Warm Backup: The inactive link is online on standby<br/> <b>Note:</b> Warm backup mode is not available for dual SIM backup.</li> <li>• Load Balancing: Use two links simultaneously</li> </ul>                                                                                                                                                                                                                                                                                                                            | Cold Backup |
| Revert Interval                 | Specify the number of minutes that elapses before the primary link is checked if a backup link is being used in cold backup mode. 0 means disable checking.<br><b>Note:</b> Revert interval is available only under the cold backup mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 0           |
| Emergency Reboot                | Click the toggle button to enable/disable this option. Enable to reboot the whole system if no links available.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | OFF         |

**Note:** Click for help.

**Link Settings** allows you to configure the parameters of link connection, including WWAN1/WWAN2, WAN and WLAN. It is recommended to enable Ping detection to keep the router always online. The Ping detection increases the reliability and also costs the data traffic.

| ^ Link Settings |       |             |                 |
|-----------------|-------|-------------|-----------------|
| Index           | Type  | Description | Connection Type |
| 1               | WWAN1 |             | DHCP            |
| 2               | WWAN2 |             | DHCP            |
| 3               | WAN   |             | DHCP            |
| 4               | WLAN  |             | DHCP            |

Click on the right-most of WWAN1/WWAN2 to enter the configuration window.

## WWAN1/WWAN2

**Link Manager**

^ General Settings

Index

Type

Description

The window is displayed as below when enabling the “Automatic APN Selection” option.

^ WWAN Settings

**Automatic APN Selection**  ON  OFF

Dialup Number

Authentication Type

Aggressive Reset  ON  OFF

Switch SIM By Data Allowance  ON  OFF

Data Allowance

Billing Day

The window is displayed as below when disabling the “Automatic APN Selection” option.

^ WWAN Settings

Automatic APN Selection
ON OFF

APN

Username

Password

Dialup Number

Authentication Type

Aggressive Reset
ON OFF
?

Switch SIM By Data Allowance
ON OFF
?

Data Allowance

?

Billing Day

?

^ Ping Detection Settings
?

Enable
ON OFF

Primary Server

Secondary Server

Interval

?

Retry Interval

?

Timeout

?

Max Ping Tries

?

^ Advanced Settings

NAT Enable
ON OFF

Upload Bandwidth

?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Debug Enable
ON OFF

Verbose Debug Enable
ON OFF

| Link Settings (WWAN) |                                    |         |
|----------------------|------------------------------------|---------|
| Item                 | Description                        | Default |
| General Settings     |                                    |         |
| Index                | Indicate the ordinal of the list.  | --      |
| Type                 | Show the type of the link.         | WWAN1   |
| Description          | Enter a description for this link. | Null    |

| Link Settings (WWAN)           |                                                                                                                                                                                                                                                                                                            |                 |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Item                           | Description                                                                                                                                                                                                                                                                                                | Default         |
| <b>WWAN Settings</b>           |                                                                                                                                                                                                                                                                                                            |                 |
| Automatic APN Selection        | Click the toggle button to enable/disable the “Automatic APN Selection” option. After enabling, the device will recognize the access point name automatically. Alternatively, you can disable this option and manually add the access point name.                                                          | ON              |
| APN                            | Enter the Access Point Name for cellular dial-up connection, provided by local ISP.                                                                                                                                                                                                                        | internet        |
| Username                       | Enter the username for cellular dial-up connection, provided by local ISP.                                                                                                                                                                                                                                 | Null            |
| Password                       | Enter the password for cellular dial-up connection, provided by local ISP.                                                                                                                                                                                                                                 | Null            |
| Dialup Number                  | Enter the dialup number for cellular dial-up connection, provided by local ISP.                                                                                                                                                                                                                            | *99***1#        |
| Authentication Type            | Select from “Auto”, “PAP” or “CHAP” as the local ISP required.                                                                                                                                                                                                                                             | Auto            |
| Switch SIM By Data Allowance   | Click the toggle button to enable/disable this option. After enabling, it will switch to another SIM when the data limit reached.<br><b>Note:</b> Only used for dual SIM backup.                                                                                                                           | OFF             |
| Data Allowance                 | Set the monthly data traffic limitation. The system will record the data traffic statistics when data traffic limitation (MiB) is specified. The traffic record will be displayed in <b>Interface &gt; Link Manager &gt; Status &gt; WWAN Data Usage Statistics</b> . 0 means disable data traffic record. | 0               |
| Billing Day                    | Specify the monthly billing day. The data traffic statistics will be recalculated from that day.                                                                                                                                                                                                           | 1               |
| <b>Ping Detection Settings</b> |                                                                                                                                                                                                                                                                                                            |                 |
| Enable                         | Click the toggle button to enable/disable the ping detection mechanism, a keep-alive policy of the router.                                                                                                                                                                                                 | ON              |
| Primary Server                 | Router will ping this primary address/domain name to check that if the current connectivity is active.                                                                                                                                                                                                     | 8.8.8.8         |
| Secondary Server               | Router will ping this secondary address/domain name to check that if the current connectivity is active.                                                                                                                                                                                                   | 114.114.114.114 |
| Interval                       | Set the ping interval.                                                                                                                                                                                                                                                                                     | 300             |
| Retry Interval                 | Set the ping retry interval. When ping failed, the router will ping again every retry interval.                                                                                                                                                                                                            | 5               |
| Timeout                        | Set the ping timeout.                                                                                                                                                                                                                                                                                      | 3               |
| Max Ping Tries                 | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached.                                                                                                                                                                                          | 3               |
| <b>Advanced Settings</b>       |                                                                                                                                                                                                                                                                                                            |                 |
| NAT Enable                     | Click the toggle button to enable/disable the Network Address Translation option.                                                                                                                                                                                                                          | ON              |
| Upload Bandwidth               | Set the upload bandwidth used for QoS, measured in kbps.                                                                                                                                                                                                                                                   | 10000           |
| Download Bandwidth             | Set the download bandwidth used for QoS, measured in kbps.                                                                                                                                                                                                                                                 | 10000           |
| Overridden Primary DNS         | Override primary DNS will override the automatically obtained DNS.                                                                                                                                                                                                                                         | Null            |

| Link Settings (WWAN)     |                                                                                                         |         |
|--------------------------|---------------------------------------------------------------------------------------------------------|---------|
| Item                     | Description                                                                                             | Default |
| Overridden Secondary DNS | Override secondary DNS will override the automatically obtained DNS.                                    | Null    |
| Debug Enable             | Click the toggle button to enable/disable this option. Enable for debugging information output.         | ON      |
| Verbose Debug Enable     | Click the toggle button to enable/disable this option. Enable for verbose debugging information output. | OFF     |

## WAN

Router will obtain IP automatically from DHCP server if choosing “DHCP” as connection type. The window is displayed as below.

**Link Manager**

^ **General Settings**

Index

Type

Description

**Connection Type**

The window is displayed as below when choosing “Static” as the connection type.

^ **General Settings**

Index

Type

Description

**Connection Type**

^ **Static Address Settings**

IP Address  ⓘ

Gateway

Primary DNS

Secondary DNS

The window is displayed as below when choosing “PPPoE” as the connection type.

^ **General Settings**

Index

Type

Description

Connection Type

^ **PPPoE Settings**

Username

Password

Authentication Type

PPP Expert Options  ?

^ **Ping Detection Settings** ?

Enable  ON  OFF

Primary Server

Secondary Server

Interval  ?

Retry Interval  ?

Timeout  ?

Max Ping Tries  ?

^ **Advanced Settings**

NAT Enable  ON  OFF

MTU

Upload Bandwidth  ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Debug Enable  ON  OFF

Verbose Debug Enable  ON  OFF

| Link Settings (WAN)     |                                    |         |
|-------------------------|------------------------------------|---------|
| Item                    | Description                        | Default |
| <b>General Settings</b> |                                    |         |
| Index                   | Indicate the ordinal of the list.  | --      |
| Type                    | Show the type of the link.         | WAN     |
| Description             | Enter a description for this link. | Null    |

|                                |                                                                                                                                                           |                     |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| Connection Type                | Select from "DHCP", "Static" or "PPPoE".                                                                                                                  | DHCP                |
| <b>Static Address Settings</b> |                                                                                                                                                           |                     |
| IP Address                     | Set the IP address with Netmask which can access the internet.<br>IP address with Netmask, e.g. 192.168.1.1/24                                            | Null                |
| Gateway                        | Set the gateway of the IP address in WAN port.                                                                                                            | Null                |
| Primary DNS                    | Set the primary DNS.                                                                                                                                      | Null                |
| Secondary DNS                  | Set the secondary DNS.                                                                                                                                    | Null                |
| <b>PPPoE Settings</b>          |                                                                                                                                                           |                     |
| Username                       | Enter the username provided by your Internet Service Provider.                                                                                            | Null                |
| Password                       | Enter the password provided by your Internet Service Provider.                                                                                            | Null                |
| Authentication Type            | Select from "Auto", "PAP" or "CHAP" as the local ISP required.                                                                                            | Auto                |
| PPP Expert Options             | Enter the PPP Expert options used for PPPoE dialup. You can enter some other PPP dial strings in this field. Each string can be separated by a semicolon. | Null                |
| <b>Ping Detection Settings</b> |                                                                                                                                                           |                     |
| Enable                         | Click the toggle button to enable/disable the ping detection mechanism, a keep-alive policy of the router.                                                | ON                  |
| Primary Server                 | Router will ping this primary address/domain name to check that if the current connectivity is active.                                                    | 8.8.8.8             |
| Secondary Server               | Router will ping this secondary address/domain name to check that if the current connectivity is active.                                                  | 114.114.1<br>14.114 |
| Interval                       | Set the ping interval.                                                                                                                                    | 300                 |
| Retry Interval                 | Set the ping retry interval. When ping failed, the router will ping again every retry interval.                                                           | 5                   |
| Timeout                        | Set the ping timeout.                                                                                                                                     | 3                   |
| Max Ping Tries                 | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached.                                         | 3                   |
| <b>Advanced Settings</b>       |                                                                                                                                                           |                     |
| NAT Enable                     | Click the toggle button to enable/disable the Network Address Translation option.                                                                         | ON                  |
| MTU                            | Enter the Maximum Transmission Unit.                                                                                                                      | 1500                |
| Upload Bandwidth               | Enter the upload bandwidth used for QoS, measured in kbps.                                                                                                | 10000               |
| Download Bandwidth             | Enter the download bandwidth used for QoS, measured in kbps.                                                                                              | 10000               |
| Overridden Primary DNS         | Override primary DNS will override the automatically obtained DNS.                                                                                        | Null                |
| Overridden Secondary DNS       | Override secondary DNS will override the automatically obtained DNS.                                                                                      | Null                |
| Debug Enable                   | Click the toggle button to enable/disable this option. Enable for debugging information output.                                                           | ON                  |
| Verbose Debug Enable           | Click the toggle button to enable/disable this option. Enable for verbose debugging information output.                                                   | OFF                 |

## WLAN

Router will obtain IP automatically from the WLAN AP if choosing “DHCP” as the connection type. The specific parameter configuration of SSID is shown as below.

### Link Manager

#### ^ General Settings

|                 |                                   |
|-----------------|-----------------------------------|
| Index           | <input type="text" value="4"/>    |
| Type            | <input type="text" value="WLAN"/> |
| Description     | <input type="text"/>              |
| Connection Type | <input type="text" value="DHCP"/> |

#### ^ WLAN Settings

|                        |                                                                     |
|------------------------|---------------------------------------------------------------------|
| SSID                   | <input type="text" value="Robustel"/>                               |
| Connect to Hidden SSID | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Password               | <input type="password" value="....."/>                              |

The window is displayed as below when choosing “Static” as the connection type.

### Link Manager

#### ^ General Settings

|                 |                                     |
|-----------------|-------------------------------------|
| Index           | <input type="text" value="4"/>      |
| Type            | <input type="text" value="WLAN"/>   |
| Description     | <input type="text"/>                |
| Connection Type | <input type="text" value="Static"/> |

#### ^ WLAN Settings

##### ^ Static Address Settings

|               |                      |                                                                |
|---------------|----------------------|----------------------------------------------------------------|
| IP Address    | <input type="text"/> | <input data-bbox="922 1355 954 1388" type="button" value="?"/> |
| Gateway       | <input type="text"/> |                                                                |
| Primary DNS   | <input type="text"/> |                                                                |
| Secondary DNS | <input type="text"/> |                                                                |

R3000 Router does not support the **PPPoE** WLAN Connection Type.

**^ Ping Detection Settings** ?

Enable  ON  OFF

Primary Server

Secondary Server

Interval  ?

Retry Interval  ?

Timeout  ?

Max Ping Tries  ?

**^ Advanced Settings**

NAT Enable  ON  OFF

MTU

Upload Bandwidth  ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Debug Enable  ON  OFF

Verbose Debug Enable  ON  OFF

| Link Settings (WLAN)           |                                                                                                                                                                                      |         |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                           | Description                                                                                                                                                                          | Default |
| <b>General Settings</b>        |                                                                                                                                                                                      |         |
| Index                          | Indicate the ordinal of the list.                                                                                                                                                    | --      |
| Type                           | Show the type of the link.                                                                                                                                                           | WLAN    |
| Description                    | Enter a description for this link.                                                                                                                                                   | Null    |
| Connection Type                | Select from "DHCP" or "Static".                                                                                                                                                      | DHCP    |
| <b>WLAN Settings</b>           |                                                                                                                                                                                      |         |
| SSID                           | Enter a 1-32 characters SSID which your router wants to connect. SSID (Service Set Identifier) is the name of your wireless network.                                                 | router  |
| Connect to Hidden SSID         | Click the toggle button to enable/disable this option. When router works as Client mode and needs to connect any access point which has hidden SSID, you need to enable this option. | OFF     |
| Password                       | Enter an 8-63 characters password of the access point which your router wants to connect.                                                                                            | Null    |
| <b>Static Address Settings</b> |                                                                                                                                                                                      |         |
| IP Address                     | Enter the IP address with Netmask which can access the Internet, e.g. 192.168.1.1/24                                                                                                 | Null    |
| Gateway                        | Enter the IP address of WiFi AP.                                                                                                                                                     | Null    |
| Primary DNS                    | Set the primary DNS.                                                                                                                                                                 | Null    |

|                                |                                                                                                                   |                     |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------|---------------------|
| Secondary DNS                  | Set the secondary DNS.                                                                                            | Null                |
| <b>Ping Detection Settings</b> |                                                                                                                   |                     |
| Enable                         | Click the toggle button to enable/disable the ping detection mechanism, a keepalive policy of the router.         | ON                  |
| Primary Server                 | Router will ping this primary address/domain name to check that if the current connectivity is active.            | 8.8.8.8             |
| Secondary Server               | Router will ping this secondary address/domain name to check that if the current connectivity is active.          | 114.114.1<br>14.114 |
| Interval                       | Set the ping interval.                                                                                            | 300                 |
| Retry Interval                 | Set the ping retry interval. When ping failed, the router will ping again every retry interval.                   | 5                   |
| Timeout                        | Set the ping timeout.                                                                                             | 3                   |
| Max Ping Tries                 | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached. | 3                   |
| <b>Advance Settings</b>        |                                                                                                                   |                     |
| NAT Enable                     | Click the toggle button to enable/disable the Network Address Translation option.                                 | ON                  |
| MTU                            | Enter the Maximum Transmission Unit.                                                                              | 1500                |
| Upload Bandwidth               | Enter the upload bandwidth used for QoS, measured in kbps.                                                        | 10000               |
| Download Bandwidth             | Enter the download bandwidth used for QoS, measured in kbps.                                                      | 10000               |
| Overridden Primary DNS         | Override primary DNS will override the automatically obtained DNS.                                                | Null                |
| Overridden Secondary DNS       | Override secondary DNS will override the automatically obtained DNS.                                              | Null                |
| Debug Enable                   | Click the toggle button to enable/disable this option. Enable for debugging information output.                   | ON                  |
| Verbose Debug Enable           | Click the toggle button to enable/disable this option. Enable for verbose debugging information output.           | OFF                 |

## Status

This page allows you to view the status of link connection and clear the monthly data usage statistics.

| Index | Link  | Status       | Uptime           | IP Address     |
|-------|-------|--------------|------------------|----------------|
| 1     | WWAN1 | Connected    | 0 days, 01:03:29 | 10.122.74.11.. |
| 2     | WWAN2 | Disconnected |                  |                |

Click the right-most button  to select the connection status of the current link.



Click the row of the link, and it will show the details information of the current link connection under the row.

Link Manager
Status

^ Link Status
⋮

| Index                                          | Link  | Status       | Uptime           | IP Address     |
|------------------------------------------------|-------|--------------|------------------|----------------|
| 1                                              | WWAN1 | Connected    | 0 days, 01:03:29 | 10.122.74.11.. |
| <b>Index</b> 1                                 |       |              |                  |                |
| <b>Link</b> WWAN1                              |       |              |                  |                |
| <b>Status</b> Connected                        |       |              |                  |                |
| <b>Interface</b> wwan                          |       |              |                  |                |
| <b>Uptime</b> 0 days, 01:03:29                 |       |              |                  |                |
| <b>IP Address</b> 10.122.74.11/255.255.255.248 |       |              |                  |                |
| <b>Gateway</b> 10.122.74.9                     |       |              |                  |                |
| <b>DNS</b> 210.21.4.130 221.5.88.88            |       |              |                  |                |
| <b>RX Packets</b> 42                           |       |              |                  |                |
| <b>TX Packets</b> 46                           |       |              |                  |                |
| <b>RX Bytes</b> 2962                           |       |              |                  |                |
| <b>TX Bytes</b> 3568                           |       |              |                  |                |
| 2                                              | WWAN2 | Disconnected |                  |                |

^ WWAN Data Usage Statistics

WWAN1 Monthly Stats
Clear

WWAN2 Monthly Stats
Clear

Click the **Clear** button to clear SIM1 or SIM2 monthly data traffic usage statistics. Data statistics will be displayed only if enable the Data Allowance function in **Interface > Link Manager > Link Settings > WWAN Settings > Data Allowance**.

### 3.7 Interface > LAN

This section allows you to set the related parameters for LAN port. There are two LAN ports on R3000 Router, including ETH0 and ETH1. The ETH0 and ETH1 can freely choose from lan0 and lan1, but at least one LAN port must be assigned as lan0. The default settings of ETH0 and ETH1 are lan0 and their default IP are 192.168.0.1/255.255.255.0.

#### LAN

By default, there is a LAN port (lan0) in the list. To begin adding a new LAN port (lan1), please configure ETH0 or ETH1 as lan1 first in **Ethernet > Ports > Port Settings**. Otherwise, the operation will be prompted as “List is full”.

| LAN                                                          | Multiple IP | VLAN Trunk   | Status      |
|--------------------------------------------------------------|-------------|--------------|-------------|
| <b>^ Network Settings</b> <span style="float:right">?</span> |             |              |             |
| Index                                                        | Interface   | IP Address   | Netmask     |
| 1                                                            | lan0        | 172.16.24.24 | 255.255.0.0 |
| <span>+</span> <span>✕</span> <span>✎</span>                 |             |              |             |

**Note:** Lan0 cannot be deleted.

You may click + to add a new LAN port, or click ✕ to delete the current LAN port. Now, click ✎ to edit the configuration of the LAN port. The maximum count is 2.

**LAN**

**^ General Settings**

Index:

Interface:  v

IP Address:

Netmask:

MTU:

| General Settings |                                                                                                                                         |               |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------|
| Item             | Description                                                                                                                             | Default       |
| Index            | Indicate the ordinal of the list.                                                                                                       | --            |
| Interface        | Show the editing port. Lan1 is available only if it was selected by one of ETH0~ETH1 in <b>Ethernet &gt; Ports &gt; Port Settings</b> . | --            |
| IP Address       | Set the IP address of the LAN port.                                                                                                     | 192.168.0.1   |
| Netmask          | Set the Netmask of the LAN port.                                                                                                        | 255.255.255.0 |
| MTU              | Enter the Maximum Transmission Unit.                                                                                                    | 1500          |

The window is displayed as below when choosing “Server” as the mode.

^ DHCP Settings

Enable  ON  OFF

Mode  v

IP Pool Start

IP Pool End

Subnet Mask

^ DHCP Advanced Settings

Gateway

Primary DNS

Secondary DNS

WINS Server

Lease Time  ?

Static lease  ?

Expert Options  ?

Debug Enable  ON  OFF

The window is displayed as below when choosing “Relay” as the mode.

^ DHCP Settings

Enable  ON  OFF

Mode  v

DHCP Server For Relay

^ DHCP Advanced Settings

Debug Enable  ON  OFF

| LAN                  |                                                                                                                                                                                                                                                                                                                         |             |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Item                 | Description                                                                                                                                                                                                                                                                                                             | Default     |
| <b>DHCP Settings</b> |                                                                                                                                                                                                                                                                                                                         |             |
| Enable               | Click the toggle button to enable/disable the DHCP function.                                                                                                                                                                                                                                                            | ON          |
| Mode                 | Select from “Server” or “Relay”. <ul style="list-style-type: none"> <li>Server: Lease IP address to DHCP clients which have been connected to LAN port</li> <li>Relay: Router can be DHCP Relay, which will provide a relay tunnel to solve problem that DHCP Client and DHCP Server is not in a same subnet</li> </ul> | Server      |
| IP Pool Start        | Define the beginning of the pool of IP addresses which will be leased to DHCP clients.                                                                                                                                                                                                                                  | 192.168.0.2 |

| LAN                    |                                                                                                                                  |               |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------|---------------|
| Item                   | Description                                                                                                                      | Default       |
| IP Pool End            | Define the end of the pool of IP addresses which will be leased to DHCP clients.                                                 | 192.168.0.100 |
| Subnet Mask            | Define the subnet mask of IP address obtained by DHCP clients from DHCP server.                                                  | 255.255.255.0 |
| DHCP Server for Relay  | Enter the IP address of DHCP relay server.                                                                                       | Null          |
| DHCP Advanced Settings |                                                                                                                                  |               |
| Gateway                | Define the gateway assigned by the DHCP server to the clients, which must be on the same network segment with DHCP address pool. | Null          |
| Primary DNS            | Define the primary DNS server assigned by the DHCP server to the clients.                                                        | Null          |
| Secondary DNS          | Define the secondary DNS server assigned by the DHCP server to the clients.                                                      | Null          |
| WINS Server            | Define the Windows Internet Naming Service obtained by DHCP clients from DHCP sever.                                             | Null          |
| Lease Time             | Set the lease time which the client can use the IP address obtained from DHCP server, measured in seconds.                       | 120           |
| Static lease           | Bind a lease to correspond an IP address via a MAC address.<br>format: mac,ip;mac,ip;..., e.g. FF:ED:CB:A0:98:01,192.168.0.200   | Null          |
| Expert Options         | Enter some other options of DHCP server in this field.<br>format: config-desc;config-desc, e.g. log-dhcp;quiet-dhcp              | Null          |
| Debug Enable           | Click the toggle button to enable/disable this option. Enable for DHCP information output.                                       | OFF           |

## Multiple IP

| LAN                    | Multiple IP | VLAN Trunk   | Status      |
|------------------------|-------------|--------------|-------------|
| ^ Multiple IP Settings |             |              |             |
| Index                  | Interface   | IP Address   | Netmask     |
| 1                      | lan0        | 172.16.24.24 | 255.255.0.0 |

You may click to add a multiple IP to the LAN port, or click to delete the multiple IP of the LAN port. Now, click to edit the multiple IP of the LAN port.

**Multiple IP**

^ IP Settings

Index:

Interface:  v

IP Address:

Netmask:

| IP Settings |                                              |         |
|-------------|----------------------------------------------|---------|
| Item        | Description                                  | Default |
| Index       | Indicate the ordinal of the list.            | --      |
| Interface   | Show the editing port, read only.            | --      |
| IP Address  | Set the multiple IP address of the LAN port. | Null    |
| Netmask     | Set the multiple Netmask of the LAN port.    | Null    |

## VLAN Trunk

LAN
Multiple IP
VLAN Trunk
Status

^ VLAN Settings
 

|       |        |           |     |            |         |   |
|-------|--------|-----------|-----|------------|---------|---|
| Index | Enable | Interface | VID | IP Address | Netmask | + |
|-------|--------|-----------|-----|------------|---------|---|

Click **+** to add a VLAN. The maximum count is 8.

VLAN Trunk

^ VLAN Settings

|            |                                                                            |
|------------|----------------------------------------------------------------------------|
| Index      | <input type="text" value="1"/>                                             |
| Enable     | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF        |
| Interface  | <input type="text" value="lan0"/> <span style="font-size: 0.8em;">v</span> |
| VID        | <input type="text" value="100"/>                                           |
| IP Address | <input type="text"/>                                                       |
| Netmask    | <input type="text"/>                                                       |

| VLAN Trunk |                                                                                                                                                      |         |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item       | Description                                                                                                                                          | Default |
| Index      | Indicate the ordinal of the list.                                                                                                                    | --      |
| Enable     | Click the toggle button to enable/disable this VLAN. Enable to make router can encapsulate and de-encapsulate the VLAN tag.                          | ON      |
| Interface  | Choose the interface which wants to enable VLAN trunk function. Select from "lan0" or "lan1" depends on your ETH0 and ETH1's corresponding LAN port. | lan0    |
| VID        | Set the tag ID of VLAN and digits from 1 to 4094.                                                                                                    | 100     |
| IP Address | Set the IP address of VLAN port.                                                                                                                     | Null    |
| Netmask    | Set the Netmask of VLAN port.                                                                                                                        | Null    |

## Status

This section allows you to view the status of LAN connection.

| LAN                        | Multiple IP | VLAN Trunk           | Status            |               |
|----------------------------|-------------|----------------------|-------------------|---------------|
| <b>^ Interface Status</b>  |             |                      |                   |               |
| Index                      | Interface   | IP Address           | MAC Address       |               |
| 1                          | lan0        | 172.16.24.24/255.... | 34:FA:40:07:38:91 |               |
| <b>^ Connected Devices</b> |             |                      |                   |               |
| Index                      | IP Address  | MAC Address          | Interface         | Inactive Time |
| 1                          | 172.16.5.76 | D0:50:99:4D:F9:35    | lan0              | 0s            |
| <b>^ DHCP Lease Table</b>  |             |                      |                   |               |
| Index                      | IP Address  | MAC Address          | Interface         | Expired Time  |

Click the row of status, the details status information will be display under the row. Please refer to the screenshot below.

| <b>^ Interface Status</b> |                    |                          |                   |
|---------------------------|--------------------|--------------------------|-------------------|
| Index                     | Interface          | IP Address               | MAC Address       |
| 1                         | lan0               | 172.16.24.24/255....     | 34:FA:40:07:38:91 |
|                           | <b>Index</b>       | 1                        |                   |
|                           | <b>Interface</b>   | lan0                     |                   |
|                           | <b>IP Address</b>  | 172.16.24.24/255.255.0.0 |                   |
|                           | <b>MAC Address</b> | 34:FA:40:07:38:91        |                   |
|                           | <b>RX Packets</b>  | 191624                   |                   |
|                           | <b>TX Packets</b>  | 2010                     |                   |
|                           | <b>RX Bytes</b>    | 16406167                 |                   |
|                           | <b>TX Bytes</b>    | 1812605                  |                   |

## 3.8 Interface > Ethernet

This section allows you to set the related parameters for Ethernet. There are two Ethernet ports on R3000 Router, including ETH0 and ETH1. The ETH0 on the router can be configured as either a WAN or a LAN port, while ETH1 can only be configured as a LAN port. By default, ETH0 and ETH1 are lan0, and their IP are 192.168.0.1/255.255.255.0. Since lan0 must be assigned to one port and WAN port must be assigned to the ETH0, there are four configurations. You can choose the appropriate configuration to fit your current needs. The specific port configurations are shown below.

| <b>^ Port Settings</b> |      |                 |  |
|------------------------|------|-----------------|--|
| Index                  | Port | Port Assignment |  |
| 1                      | eth0 | lan0            |  |
| 2                      | eth1 | lan0            |  |

| ^ Port Settings |      |                 | ? |
|-----------------|------|-----------------|---|
| Index           | Port | Port Assignment |   |
| 1               | eth0 | lan0            |   |
| 2               | eth1 | lan1            |   |

| ^ Port Settings |      |                 | ? |
|-----------------|------|-----------------|---|
| Index           | Port | Port Assignment |   |
| 1               | eth0 | lan1            |   |
| 2               | eth1 | lan0            |   |

| ^ Port Settings |      |                 | ? |
|-----------------|------|-----------------|---|
| Index           | Port | Port Assignment |   |
| 1               | eth0 | wan             |   |
| 2               | eth1 | lan0            |   |

This section introduces you to set the parameters of the WAN port.

| Ports                                                                                                                                                                                                                                                                                                                      | Status |                 |   |  |   |       |      |                 |  |   |      |     |  |   |      |      |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------|---|--|---|-------|------|-----------------|--|---|------|-----|--|---|------|------|--|
| <table border="1"> <thead> <tr> <th colspan="3">^ Port Settings</th> <th>?</th> </tr> <tr> <th>Index</th> <th>Port</th> <th>Port Assignment</th> <th></th> </tr> </thead> <tbody> <tr> <td>1</td> <td>eth0</td> <td>wan</td> <td></td> </tr> <tr> <td>2</td> <td>eth1</td> <td>lan0</td> <td></td> </tr> </tbody> </table> |        | ^ Port Settings |   |  | ? | Index | Port | Port Assignment |  | 1 | eth0 | wan |  | 2 | eth1 | lan0 |  |
| ^ Port Settings                                                                                                                                                                                                                                                                                                            |        |                 | ? |  |   |       |      |                 |  |   |      |     |  |   |      |      |  |
| Index                                                                                                                                                                                                                                                                                                                      | Port   | Port Assignment |   |  |   |       |      |                 |  |   |      |     |  |   |      |      |  |
| 1                                                                                                                                                                                                                                                                                                                          | eth0   | wan             |   |  |   |       |      |                 |  |   |      |     |  |   |      |      |  |
| 2                                                                                                                                                                                                                                                                                                                          | eth1   | lan0            |   |  |   |       |      |                 |  |   |      |     |  |   |      |      |  |

Click button of eth0 to configure its parameters. The port assignment can be changed by selecting from the drop down list.

| Ports                                                                                                                                                                                                                                                                                                                                                                           |                                     |                 |  |   |       |                                |  |      |                                     |  |                 |                                    |   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-----------------|--|---|-------|--------------------------------|--|------|-------------------------------------|--|-----------------|------------------------------------|---|
| <table border="1"> <thead> <tr> <th colspan="2">^ Port Settings</th> <th>?</th> </tr> </thead> <tbody> <tr> <td>Index</td> <td><input type="text" value="1"/></td> <td></td> </tr> <tr> <td>Port</td> <td><input type="text" value="eth0"/> v</td> <td></td> </tr> <tr> <td>Port Assignment</td> <td><input type="text" value="wan"/> v</td> <td>?</td> </tr> </tbody> </table> |                                     | ^ Port Settings |  | ? | Index | <input type="text" value="1"/> |  | Port | <input type="text" value="eth0"/> v |  | Port Assignment | <input type="text" value="wan"/> v | ? |
| ^ Port Settings                                                                                                                                                                                                                                                                                                                                                                 |                                     | ?               |  |   |       |                                |  |      |                                     |  |                 |                                    |   |
| Index                                                                                                                                                                                                                                                                                                                                                                           | <input type="text" value="1"/>      |                 |  |   |       |                                |  |      |                                     |  |                 |                                    |   |
| Port                                                                                                                                                                                                                                                                                                                                                                            | <input type="text" value="eth0"/> v |                 |  |   |       |                                |  |      |                                     |  |                 |                                    |   |
| Port Assignment                                                                                                                                                                                                                                                                                                                                                                 | <input type="text" value="wan"/> v  | ?               |  |   |       |                                |  |      |                                     |  |                 |                                    |   |

| Port Settings   |                                                                                                                                                                                                                                                         |         |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                                                                                                                                             | Default |
| Index           | Indicate the ordinal of the list.                                                                                                                                                                                                                       | --      |
| Port            | Show the editing port, read only.                                                                                                                                                                                                                       | --      |
| Port Assignment | Choose the Ethernet port's type, as a WAN port or a LAN port. When setting the port as a LAN port in <b>Interface &gt; LAN &gt; LAN &gt; Network Settings &gt; General Settings</b> , you can click the drop-down list to select from "lan0" or "lan1". | lan0    |

This column allows you to view the status of Ethernet port.

| Ports                |      | Status |
|----------------------|------|--------|
| <b>^ Port Status</b> |      |        |
| Index                | Port | Link   |
| 1                    | eth0 | Down   |
| 2                    | eth1 | Up     |

Click the row of status, the details status information will be display under the row. Please refer to the screenshot below.

| ^ Port Status |      |      |
|---------------|------|------|
| Index         | Port | Link |
| 1             | eth0 | Down |
| 2             | eth1 | Up   |

|              |      |
|--------------|------|
| <b>Index</b> | 2    |
| <b>Port</b>  | eth1 |
| <b>Link</b>  | Up   |

### 3.9 Interface > Cellular

This section allows you to set the related parameters of Cellular. The R3000 Router has two SIM card slots, but do not support two SIM cards online simultaneously due to its single-module design. If insert single SIM card at the first time, SIM1 slot and SIM2 slots are available.

| Cellular                            |          | Status       | AT Debug     |                  |
|-------------------------------------|----------|--------------|--------------|------------------|
| <b>^ Advanced Cellular Settings</b> |          |              |              |                  |
| Index                               | SIM Card | Phone Number | Network Type | Band Select Type |
| 1                                   | SIM1     |              | Auto         | All              |
| 2                                   | SIM2     |              | Auto         | All              |

Click of SIM 1 to edit the parameters.

| Cellular                  |                                     |
|---------------------------|-------------------------------------|
| <b>^ General Settings</b> |                                     |
| <b>Index</b>              | <input type="text" value="1"/>      |
| <b>SIM Card</b>           | <input type="text" value="SIM1"/> v |
| <b>Phone Number</b>       | <input type="text"/>                |
| <b>PIN Code</b>           | <input type="text"/> ?              |
| <b>Extra AT Cmd</b>       | <input type="text"/> ?              |
| <b>Telnet Port</b>        | <input type="text" value="0"/> ?    |

The window is displayed as below when choosing “Auto” as the network type.

^ Cellular Network Settings

Network Type

v ?

Band Select Type

v ?

^ Advanced Settings

Debug Enable

ON  OFF

Verbose Debug Enable

ON  OFF

The window is displayed as below when choosing “Specify” as the band select type.

^ Cellular Network Settings

Network Type

v ?

Band Select Type

v ?

^ Band Settings

|             |                                                                     |
|-------------|---------------------------------------------------------------------|
| GSM 850     | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| GSM 900     | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| GSM 1800    | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| GSM 1900    | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| WCDMA 850   | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| WCDMA 900   | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| WCDMA 1900  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| WCDMA 2100  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 1  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 2  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 3  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 4  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 5  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 7  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 8  | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| LTE Band 20 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |

^ Advanced Settings

Debug Enable

ON  OFF

Verbose Debug Enable

ON  OFF

| Cellular                |             |         |
|-------------------------|-------------|---------|
| Item                    | Description | Default |
| <b>General Settings</b> |             |         |

| Cellular                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |         |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Default |
| Index                     | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | --      |
| SIM Card                  | Set the currently editing SIM card.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | SIM1    |
| Phone Number              | Enter the phone number of the SIM card.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Null    |
| PIN Code                  | Enter a 4-8 characters PIN code used for unlocking the SIM.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Null    |
| Extra AT Cmd              | Enter the AT commands used for cellular initialization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Null    |
| Telnet Port               | Specify the Port listening of telnet service, used for AT over Telnet.                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 0       |
| Cellular Network Settings |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |         |
| Network Type              | Select from "Auto", "2G Only", "2G First", "3G Only", "3G First", "4G Only", "4G First". <ul style="list-style-type: none"> <li>Auto: Connect to the best signal network automatically</li> <li>2G Only: Only the 2G network is connected</li> <li>2G First: Connect to the 2G Network preferentially</li> <li>3G Only: Only the 3G network is connected</li> <li>3G First: Connect to the 3G Network preferentially</li> <li>4G Only: Only the 4G network is connected</li> <li>4G First: Connect to the 4G Network preferentially</li> </ul> | Auto    |
| Band Select Type          | Select from "All" or "Specify". You may choose certain bands if choosing "Specify".                                                                                                                                                                                                                                                                                                                                                                                                                                                            | All     |
| Advanced Settings         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |         |
| Debug Enable              | Click the toggle button to enable/disable this option. Enable for debugging information output.                                                                                                                                                                                                                                                                                                                                                                                                                                                | ON      |
| Verbose Debug Enable      | Click the toggle button to enable/disable this option. Enable for verbose debugging information output.                                                                                                                                                                                                                                                                                                                                                                                                                                        | OFF     |

This section allows you to view the status of the cellular connection.

| Cellular |              |             |                 |                            |
|----------|--------------|-------------|-----------------|----------------------------|
| Status   |              | AT Debug    |                 |                            |
| ^ Status |              |             |                 |                            |
| Index    | Modem Status | Modem Model | IMSI            | Registration               |
| 1        | Ready        | ME909s-120  | 460066559097705 | Registered to home network |

Click the row of status, the details status information will be displayed under the row.

| ^ Status                                       |              |             |                 |                            |
|------------------------------------------------|--------------|-------------|-----------------|----------------------------|
| Index                                          | Modem Status | Modem Model | IMSI            | Registration               |
| 1                                              | Ready        | ME909s-120  | 460066559097705 | Registered to home network |
| <b>Index</b> 1                                 |              |             |                 |                            |
| <b>Modem Status</b> Ready                      |              |             |                 |                            |
| <b>Modem Model</b> ME909s-120                  |              |             |                 |                            |
| <b>Current SIM</b> SIM1                        |              |             |                 |                            |
| <b>Phone Number</b>                            |              |             |                 |                            |
| <b>IMSI</b> 460066559097705                    |              |             |                 |                            |
| <b>ICCID</b> 89860616090062456452              |              |             |                 |                            |
| <b>Registration</b> Registered to home network |              |             |                 |                            |
| <b>Network Provider</b> CHN-UNICOM             |              |             |                 |                            |
| <b>Network Type</b> LTE                        |              |             |                 |                            |
| <b>Signal Strength</b> 25 (-63dBm)             |              |             |                 |                            |
| <b>Bit Error Rate</b> 99                       |              |             |                 |                            |
| <b>PLMN ID</b> 46001                           |              |             |                 |                            |
| <b>Local Area Code</b> 2507                    |              |             |                 |                            |
| <b>Cell ID</b> 06074702                        |              |             |                 |                            |
| <b>IMEI</b> 867377020253088                    |              |             |                 |                            |
| <b>Firmware Version</b> 11.617.01.00.00        |              |             |                 |                            |

| Status           |                                                                                                                                                                                                                       |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item             | Description                                                                                                                                                                                                           |
| Index            | Indicate the ordinal of the list.                                                                                                                                                                                     |
| Modem Status     | Show the status of the radio module.                                                                                                                                                                                  |
| Modem Model      | Show the model of the radio module.                                                                                                                                                                                   |
| Current SIM      | Show the SIM card that your router is using.                                                                                                                                                                          |
| Phone Number     | Show the phone number of the current SIM.<br><b>Note:</b> This option will be displayed if enter manually in <b>Cellular &gt; Advanced Cellular Settings &gt; SIM1/SIM2 &gt; General Settings &gt; Phone Number</b> . |
| IMSI             | Show the IMSI number of the current SIM.                                                                                                                                                                              |
| ICCID            | Show the ICCID number of the current SIM.                                                                                                                                                                             |
| Registration     | Show the current network status.                                                                                                                                                                                      |
| Network Provider | Show the name of Network Provider.                                                                                                                                                                                    |
| Network Type     | Show the current network service type, e.g. GPRS.                                                                                                                                                                     |
| Signal Strength  | Show the signal strength detected by the mobile.                                                                                                                                                                      |
| Bit Error Rate   | Show the current bit error rate.                                                                                                                                                                                      |
| PLMN ID          | Show the current PLMN ID.                                                                                                                                                                                             |
| Local Area Code  | Show the current local area code used for identifying different area.                                                                                                                                                 |

| Status           |                                                                                     |
|------------------|-------------------------------------------------------------------------------------|
| Item             | Description                                                                         |
| Cell ID          | Show the current cell ID used for locating the router.                              |
| IMEI             | Show the IMEI (International Mobile Equipment Identity) number of the radio module. |
| Firmware Version | Show the current firmware version of the radio module.                              |

This page allows you to check the AT Debug.

Cellular
Status
AT Debug

^ At Debug

**Command**

**Result**

Send

| AT Debug                                                                                                 |                                                                                 |         |
|----------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|---------|
| Item                                                                                                     | Description                                                                     | Default |
| Command                                                                                                  | Enter the AT command that you want to send to cellular module in this text box. | Null    |
| Result                                                                                                   | Show the AT command responded by cellular module in this text box.              | Null    |
| <span style="background-color: #2c5e8c; color: white; padding: 2px 5px; border-radius: 3px;">Send</span> | Click the button to send AT command.                                            | --      |

### 3.10 Interface > WiFi

This section allows you to configure the parameters of two WiFi modes. Router supports either WiFi AP mode or Client mode, and default as AP mode.

**Note:** Need to reboot to make configuration take effect if switching the AP and Client mode.

#### WiFi AP

##### Configure Router as WiFi AP

Click **Interface > WiFi > WiFi**, select "AP" as the mode and click "Submit".

WiFi
Access Point
ACL
Status

^ General Settings

Mode

AP
v
?

Region

SE
?

**Note:** Please remember to click **Save & Apply > Reboot** after finish the configuration, so that the configuration can be took effect.

Click the **Access Point** column to configure the parameters of WiFi AP. By default, the security mode is set as “Disabled”.

| WiFi                      | Access Point | ACL                                                                 | Status |
|---------------------------|--------------|---------------------------------------------------------------------|--------|
| <p>^ General Settings</p> |              |                                                                     |        |
| Enable                    |              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |        |
| Band                      |              | 2.4G v                                                              |        |
| Bandwidth                 |              | 20MHz v                                                             |        |
| Channel                   |              | Auto v ?                                                            |        |
| SSID                      |              | router                                                              |        |
| Broadcast SSID            |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |        |
| Security Mode             |              | Disabled v ?                                                        |        |
| RTS/CTS Threshold         |              | 2346 ?                                                              |        |
| Transmit Rate             |              | Auto v                                                              |        |
| Debug Level               |              | none v                                                              |        |

The window is displayed as below when setting “WPA” as the security mode.

|                           |  |                                                                     |  |
|---------------------------|--|---------------------------------------------------------------------|--|
| <p>^ General Settings</p> |  |                                                                     |  |
| Enable                    |  | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |  |
| Band                      |  | 2.4G v                                                              |  |
| Bandwidth                 |  | 20MHz v                                                             |  |
| Channel                   |  | Auto v ?                                                            |  |
| SSID                      |  | router                                                              |  |
| Broadcast SSID            |  | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |  |
| Security Mode             |  | WPA v ?                                                             |  |
| WPA Version               |  | Auto v                                                              |  |
| Encryption                |  | Auto v ?                                                            |  |
| PSK Password              |  | <input type="text"/> ?                                              |  |
| Group Key Update Interval |  | 3600                                                                |  |
| RTS/CTS Threshold         |  | 2346 ?                                                              |  |
| Transmit Rate             |  | Auto v                                                              |  |
| Debug Level               |  | none v                                                              |  |

The window is displayed as below when setting “WEP” as the security mode.

**^ General Settings**

Enable  ON  OFF

Band  v

Bandwidth  v

Channel  v ?

SSID

Broadcast SSID  ON  OFF

**Security Mode**  v ?

WEP Key

RTS/CTS Threshold  ?

Transmit Rate  v

Debug Level  v

| General Settings @ Access Point |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |         |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Default |
| Enable                          | Click the toggle button to enable/disable the WiFi access point option.                                                                                                                                                                                                                                                                                                                                                                                                                                                | OFF     |
| Band                            | Choose from “2.4G” or “5G”.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 2.4G    |
| Bandwidth                       | Select from “20MHz”, “40MHz”. 40 MHz channel width provides twice the data rate available over a single 20 MHz channel.                                                                                                                                                                                                                                                                                                                                                                                                | 20MHz   |
| Channel                         | Select the frequency channel, including “Auto”, “1”, “2” ..... “13”. <ul style="list-style-type: none"> <li>• Auto: Router will scan all frequency channels until the best one is found</li> <li>• 1~13: Router will be fixed to work with this channel</li> </ul> Following are the frequency of 1~13 channel.<br>1: 2412 MHz<br>2: 2417 MHz<br>3: 2422 MHz<br>4: 2427 MHz<br>5: 2432 MHz<br>6: 2437 MHz<br>7: 2442 MHz<br>8: 2447 MHz<br>9: 2452 MHz<br>10: 2457 MHz<br>11: 2462 MHz<br>12: 2467 MHz<br>13: 2472 MHz | Auto    |
| SSID                            | Enter the Service Set Identifier, the name of your wireless network. The SSID of a client and the SSID of the AP must be identical for the client and AP to be able to communicate with each other. Enter 1 to 32 characters.                                                                                                                                                                                                                                                                                          | router  |

| General Settings @ Access Point |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |          |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Default  |
| Broadcast SSID                  | Click the toggle button to enable/disable the SSID being broadcast. When enabled, the client can scan your SSID. When disabled, the client cannot scan your SSID. If you want to connect to the router AP, you need to manually enter the SSID of router AP at WiFi client side.                                                                                                                                                                                                                                                                                                                                                                        | ON       |
| Security Mode                   | Select from "Disabled", "WPA" or "WEP". <ul style="list-style-type: none"> <li>Disabled: User can access the WiFi without the password when disable security</li> </ul> <p><b>Note:</b> It is strongly recommended for security purposes that you do not choose this kind of mode.</p> <ul style="list-style-type: none"> <li>WPA: Include WPA and WPA2. Personal version of WPA (WiFi Protected Access), also known as WPA/WPA-PSK (Pre-Shared Key), provides a simple way of encrypting a wireless connection for high confidentiality</li> <li>WEP: Wired Equivalent Privacy provides encryption for wireless device's data transmission.</li> </ul> | Disabled |
| WPA Version                     | Select from "Auto", "WPA" or "WPA2". <ul style="list-style-type: none"> <li>Auto: Router will choose automatically the most suitable WPA version</li> <li>WPA2 is a stronger security feature than WPA</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                       | Auto     |
| Encryption                      | Select from "Auto", "TKIP" or "AES". <ul style="list-style-type: none"> <li>Auto: Router will choose automatically the most suitable encryption</li> <li>TKIP: Temporal Key Integrity Protocol (TKIP) encryption uses a wireless connection. TKIP encryption can be used for WPA-PSK and WPA with 802.1x authentication.</li> </ul> <p><b>Note:</b> It's not recommended to use TKIP encryption in 802.11n mode.</p> <ul style="list-style-type: none"> <li>AES: AES encryption uses a wireless connection. AES can be used for WPA-PSK and WPA with 802.1x authentication. AES is a stronger encryption algorithm than TKIP</li> </ul>                 | Auto     |
| PSK Password                    | Enter the Pre share key password. When router works as AP mode, enter Master key to generate keys for encryption. A PSK Password is used as a basis for encryption methods (or cipher types) in a WLAN connection. The PSK Password should be complicated and as long as possible. For security reasons, this PSK Password should only be disclosed to users who need it, and it should be changed regularly. Enter 8 to 63 characters.                                                                                                                                                                                                                 | Null     |
| Group Key Update Interval       | Enter the time period of group key renewal.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 3600     |
| WEP Key                         | Enter the WEP key. The key length should be 10 or 26 hexadecimal digits depending on which WEP key is used, 64 digits or 128 digits.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Null     |
| RTS/CTS Threshold               | Specify the RTS (request to send) threshold or CTS (clear to send) threshold and digits from 256 to 2346. The router AP will never send the signal before sending out data if setting the RTS threshold as 2347, and the router AP will send the signal once it sending out data if setting the RTS threshold as 0.                                                                                                                                                                                                                                                                                                                                     | 2346     |
| Transmit Rate                   | Set the transmit rate. You can choose Auto or specify a Transmit Rate.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Auto     |
| Debug Level                     | Select from "verbose", "debug", "info", "notice", "warning" or "none".                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | none     |

WiFi | Access Point | **ACL** | Status

^ General Settings

Enable ACL  ON  OFF

ACL Mode  v ?

^ Access Control List

| Index | Description | MAC Address |
|-------|-------------|-------------|
|-------|-------------|-------------|

Click **+** to add a MAC address to the Access Control List. The maximum count for MAC address is 64.

ACL

^ Access Control List

Index

Description

MAC Address

| ACL                        |                                                                                                                                                                                                                                                                                                                                                                                         |         |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                       | Description                                                                                                                                                                                                                                                                                                                                                                             | Default |
| <b>General Settings</b>    |                                                                                                                                                                                                                                                                                                                                                                                         |         |
| Enable ACL                 | Click the toggle button to enable ACL (Access Control List) option.                                                                                                                                                                                                                                                                                                                     | OFF     |
| ACL Mode                   | Select from "Accept" or "Deny". <ul style="list-style-type: none"> <li>Accept: Only the packets fitting the entities of the "Access Control List" can be allowed</li> <li>Deny: All the packets fitting the entities of the "Access Control List" will be denied</li> </ul> <b>Note:</b> Router can only allow or deny devices which are included in "Access Control List" at one time. | Accept  |
| <b>Access Control List</b> |                                                                                                                                                                                                                                                                                                                                                                                         |         |
| Index                      | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                                                                                       | --      |
| Description                | Enter a description for this access control list.                                                                                                                                                                                                                                                                                                                                       | Null    |
| MAC Address                | Add a MAC address here.                                                                                                                                                                                                                                                                                                                                                                 | Null    |

This section allows you to view the status of AP.

WiFi | Access Point | **ACL** | Status

^ AP Status

Status COMPLETED

SSID R3000

MAC Address 34:FA:40:08:6A:B5

^ Associated Stations

| Index | MAC Address | IP Address | Name | Connected Time |
|-------|-------------|------------|------|----------------|
|-------|-------------|------------|------|----------------|

## WiFi Client

### Configure Router as WiFi client

Click **Interface > WiFi > WiFi**, select “Client” as the mode and click “Submit > Save & Apply”.



WiFi

^ General Settings

Mode Client ?

Region SE ?

And then a “WLAN” column will appear under the Interface list.



Status

Interface

Link Manager

LAN

Ethernet

Cellular

WiFi

WLAN

WiFi

^ General Settings

Mode Client ?

Region SE ?

Click **Interface > Link Manager > Link Settings**, and click the edit button of WLAN, then configure the related parameters of WLAN.



^ WLAN Settings

SSID Robustel

Connect to Hidden SSID ON OFF

Password .....

Click **Interface > WLAN** to configure the parameters of WiFi Client after setting the mode as Client. Please remember to click **Save & Apply > Reboot** after finish the configuration, so that the configuration can be took effect.



Status

^ WLAN Status

Status Connected

Uptime 0 days, 00:00:01

IP Address 172.20.10.2/255.255.255.240

Gateway 172.20.10.1

DNS 172.20.10.1

MAC Address 00:23:a7:a4:15:60

**^ Link Status**

|              |         |
|--------------|---------|
| Signal       | -65 dBm |
| Noise        | 0 dBm   |
| Link Quality | 70/80   |

**^ WPA Status**

|                 |                   |
|-----------------|-------------------|
| WPA State       | COMPLETED         |
| Frequency       | 2.462 GHz         |
| BSSID           | fe:2b:2a:84:79:8f |
| SSID            | Chen              |
| Mode            | station           |
| Key Management  | WPA2-PSK          |
| Pairwise Cipher | CCMP              |
| Group Cipher    | CCMP              |

This window allows you to scan for all the available SSIDs in your area and click one of those shown on the “Scan Results” list.

**^ Scan Results** ⋮

| Index | SSID | MAC Address | Frequency | Signal | Scan |
|-------|------|-------------|-----------|--------|------|
|-------|------|-------------|-----------|--------|------|

**^ Scan Results** ⋮

| Index | SSID   | MAC Address       | Frequency | Signal |
|-------|--------|-------------------|-----------|--------|
| 1     | Chen   | FE:2B:2A:84:79:8F | 2462      | 61 dBm |
| 2     | appapp | 68:A0:F6:E4:DF:1B | 2427      | 65 dBm |

### 3.11 Interface > USB

This section allows you to set the USB parameters. The USB interface of the router can be used for firmware upgrade and configuration upgrade.

USB
Key

**^ General Settings**

|                                    |                                                                     |
|------------------------------------|---------------------------------------------------------------------|
| Enable USB                         | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable Automatic Firmware Updating | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |

| General Settings @ USB             |                                                                                                                                                                              |         |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                               | Description                                                                                                                                                                  | Default |
| Enable USB                         | Click the toggle button to enable/disable the USB option.                                                                                                                    | ON      |
| Enable Automatic Firmware Updating | Click the toggle button to enable/disable this option. Enable to automatically update the firmware of the router when inserting a USB storage device with a router firmware. | ON      |

Router has the key for USB automatic update. User can generate the key in this page.



| Key                      |                                          |         |
|--------------------------|------------------------------------------|---------|
| Item                     | Description                              | Default |
| USB Automatic Update Key | Click <b>Generate</b> to generate a key. | --      |


### 3.12 Interface > DI/DO

This section allows you to set the DI/DO parameters. Digital Input and Digital Output are the specific interfaces for R3000. The DI interface can be used for triggering alarm, while the DO can be used for controlling the slave device so as to realize real-time monitoring.

#### DI

| Index | Enable | Mode   | Inversion |
|-------|--------|--------|-----------|
| 1     | false  | ON-OFF | false     |
| 2     | false  | ON-OFF | false     |

Click the right-most button of index 1 as below. The default mode is “ON-OFF”.



The window is displayed as below when choosing “Counter” as the mode.

DI

^ General Settings

**Index**

**Enable**  ON  OFF

**Mode** Counter ▼

**Inversion**  ON  OFF

**Threshold Value**

**Alarm On Content**

**Alarm Off Content**

| General Settings @ DI |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |           |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| Item                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Default   |
| Index                 | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | --        |
| Enable                | Click the toggle button to enable/disable this DI.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | OFF       |
| Mode                  | Select from "ON-OFF" or "Counter". <ul style="list-style-type: none"> <li>ON-OFF: DI interface support ON and OFF mode (high or low level electrical) trigger DI alarm. The mode default to ON, and OFF mode is available only when enabling the inversion feature</li> <li>ON—Under this mode, DI alarm status will be triggered to ON when DI interface open from GND or input a high level electrical (logic 1), on the contrary DI alarm status will be trigged to OFF when DI interface connect to GND or input a low level electrical (logic 0)</li> <li>OFF—Under this mode, DI alarm status will be triggered to ON when DI interface connect to GND or input a low level electrical (logic 0), on the contrary DI alarm status will be trigged to OFF when DI interface open from GND or input a high level electrical (logic 1)</li> <li>Counter: Event counter mode</li> </ul> | ON-OFF    |
| Inversion             | Click the toggle button to enable/disable this option. Enable to set DI mode as OFF mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | OFF       |
| Threshold Value       | Set the threshold vale. It will trigger alarm when event counter reaches this figure. After triggering alarm, DI will keep counting but not trigger alarm again. Enter 0 to 65535 digits. (0=will not trigger alarm)<br><b>Note:</b> This option is only available when DI under the "Counter" mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Null      |
| Alarm On Content      | When the alarm is on, show its content.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Alarm On  |
| Alarm Off Content     | When the alarm is off, show its content.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Alarm Off |

**Note:** It defaults as high alarm, while turns to low alarm after enabling the "Inversion" button.

## DO

| DI                   | DO     | Status          |                  |               |              |
|----------------------|--------|-----------------|------------------|---------------|--------------|
| <b>^ DO Settings</b> |        |                 |                  |               |              |
| Index                | Enable | Alarm On Action | Alarm Off Action | Initial State | Alarm Source |
| 1                    | false  | High            | Low              | Last          | DI1 Alarm    |
| 2                    | false  | High            | Low              | Last          | DI1 Alarm    |

Click to enter the DO configuration window.

DO

**^ General Settings**

Index:

Enable:

Alarm On Action:  v

Alarm Off Action:  v

Initial State:  v

Delay:  ?

Hold Time:  ?

Alarm Source:  v

The window is displayed as below when choosing “Pulse” as the alarm on action.

DO

**^ General Settings**

Index:

Enable:

**Alarm On Action:  v**

Alarm Off Action:  v

Initial State:  v

Delay:  ?

Hold Time:  ?

Low-level Width:  ?

High-level Width:  ?

Alarm Source:  v

The window is displayed as below when choosing “Pulse” as the alarm off action.

DO

^ General Settings

Index

Enable  ON  OFF

Alarm On Action  v

Alarm Off Action  v

Initial State  v

Delay  ?

Hold Time  ?

Low-level Width  ?

High-level Width  ?

Alarm Source  v

| DO               |                                                                                                                                                                                                                                                                                                                              |         |
|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item             | Description                                                                                                                                                                                                                                                                                                                  | Default |
| Index            | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                            | --      |
| Enable           | Click the toggle button to enable/disable this DO.                                                                                                                                                                                                                                                                           | OFF     |
| Alarm On Action  | Digital Output initiates when there is an alarm. Selected from “High”, “Low” or “Pulse”. <ul style="list-style-type: none"> <li>High: a high electrical level output</li> <li>Low: a low electrical level output</li> <li>Pulse: Generates a square wave as specified in the pulse mode parameters when triggered</li> </ul> | High    |
| Alarm Off Action | Digital Output initiates when alarm removed. Selected from “High”, “Low” or “Pulse”. <ul style="list-style-type: none"> <li>High: a high electrical level output</li> <li>Low: a low electrical level output</li> <li>Pulse: Generates a square wave as specified in the pulse mode parameters when triggered</li> </ul>     | Low     |
| Initial State    | Specify the Digital Output status when powered on. Selected from “Last”, “High” or “Low”. <ul style="list-style-type: none"> <li>Last: DO’s status will consist with the status of last power off</li> <li>High: DO interface is in high electrical level</li> <li>Low: DO interface is in low electrical level</li> </ul>   | Low     |
| Delay            | Set the delay time for DO alarm start-up. The first pulse will be generated after a “Delay”. Enter from 0 to 30000ms. (0=generate pulse without delay)                                                                                                                                                                       | 0       |
| Hold Time        | Set the hold time of DO status (Alarm On Action/Alarm Off Action). When the action time reach this specified time, DO will stop the action. Enter from 0 to 255 seconds. (0=keep on until the next action)                                                                                                                   | 0       |
| Low-level Width  | Set the low-level width. It is available when enabling Pulse as “Alarm On Action/Alarm Off Action”. In Pulse Output mode, the selected digital output channel will generate a                                                                                                                                                | 10      |

| DO               |                                                                                                                                                                                                                                                                                                           |           |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| Item             | Description                                                                                                                                                                                                                                                                                               | Default   |
|                  | square wave as specified in the pulse mode parameters. The low level widths are specified here. Enter from 1 to 30000 ms.                                                                                                                                                                                 |           |
| High-level Width | Set the high-level width. It is available when enabling Pulse as “Alarm On Action/Alarm Off Action”. In Pulse Output mode, the selected digital output channel will generate a square wave as specified in the pulse mode parameters. The high level widths are specified here. Enter from 1 to 30000 ms. | 10        |
| Alarm Source     | Digital Output initiates according to different alarm source. Selected from “DI1 Alarm”, “DI2 Alarm”. DI1/DI2 Alarm: Digital Output triggers the related action when there is alarm from Digital Input.                                                                                                   | DI1 Alarm |

### Status

This window allows you to view the status of DO and DI interface. It also can clear the counter alarm of DI in here. Click **Clear** button to clear DI1 or DI2 monthly usage statistics info for counter alarm.

DI

DO

Status

^ DI Status

| Index | Level | Status | Count |
|-------|-------|--------|-------|
|       |       |        |       |

^ Action Of Clear

Counter Alarm Of DI 1
**Clear**

Counter Alarm Of DI 2
**Clear**

^ DO Status

| Index | Level | Low-level Width | High-level Width |
|-------|-------|-----------------|------------------|
|       |       |                 |                  |

### 3.13 Interface > Serial Port

This section allows you to set the serial port parameters. R3000 Router supports one COM1 and one COM2, also can be configured as either two COM1 or two COM2.

Serial Port

Status

^ Serial Port Settings

| Index | Port | Enable | Baud Rate | Application Mode |  |
|-------|------|--------|-----------|------------------|--|
| 1     | COM1 | false  | 115200    | Transparent      |  |
| 2     | COM2 | false  | 115200    | Transparent      |  |

Click the edit button of COM1.

**Serial Port**

^ **Serial Port Application Settings**

|              |                                                                            |
|--------------|----------------------------------------------------------------------------|
| Index        | <input type="text" value="1"/>                                             |
| Port         | <input style="border-bottom: 1px solid #ccc;" type="text" value="COM1"/>   |
| Enable       | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF        |
| Baud Rate    | <input style="border-bottom: 1px solid #ccc;" type="text" value="115200"/> |
| Data Bits    | <input style="border-bottom: 1px solid #ccc;" type="text" value="8"/>      |
| Stop Bits    | <input style="border-bottom: 1px solid #ccc;" type="text" value="1"/>      |
| Parity       | <input style="border-bottom: 1px solid #ccc;" type="text" value="None"/>   |
| Flow Control | <input style="border-bottom: 1px solid #ccc;" type="text" value="None"/>   |

^ **Data Packing**

|                 |                                   |   |
|-----------------|-----------------------------------|---|
| Packing Timeout | <input type="text" value="50"/>   | ? |
| Packing Length  | <input type="text" value="1200"/> |   |

| Serial Port                             |                                                                                                                                                                                                                                                                                                                             |         |
|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                                    | Description                                                                                                                                                                                                                                                                                                                 | Default |
| <b>Serial Port Application Settings</b> |                                                                                                                                                                                                                                                                                                                             |         |
| Index                                   | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                           | --      |
| Port                                    | Show the current serial's name, read only.                                                                                                                                                                                                                                                                                  | --      |
| Enable                                  | Click the toggle button to enable/disable this serial port. When the status is OFF, the serial port is not available.                                                                                                                                                                                                       | OFF     |
| Baud Rate                               | Select from "300", "600", "1200", "2400", "4800", "9600", "19200", "38400", "57600", "115200" or "230400".                                                                                                                                                                                                                  | 115200  |
| Data Bits                               | Select from "7" or "8".                                                                                                                                                                                                                                                                                                     | 8       |
| Stop Bits                               | Select from "1" or "2".                                                                                                                                                                                                                                                                                                     | 1       |
| Parity                                  | Select from "None", "Odd" or "Even".                                                                                                                                                                                                                                                                                        | None    |
| Flow control                            | Select from "None", "Software" or "Hardware".                                                                                                                                                                                                                                                                               | None    |
| <b>Data Packing</b>                     |                                                                                                                                                                                                                                                                                                                             |         |
| Packing Timeout                         | Set the packing timeout. The serial port will queue the data in the buffer and send the data to the Cellular WAN/Ethernet WAN when it reaches the Interval Timeout in the field.<br><b>Note:</b> Data will also be sent as specified by the packet length even when data is not reaching the interval timeout in the field. | 50      |
| Packing Length                          | Set the packet length. The Packet length setting refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending. When a packet length between 1 and 3000 bytes is specified, data in the buffer will be sent as soon it reaches the specified length.                          | 1200    |

- The window is displayed as below when choosing “Transparent” as the application mode and “TCP Client” as the protocol.

^ Server Setting

|                  |                      |   |
|------------------|----------------------|---|
| Application Mode | Transparent          | v |
| Protocol         | TCP Client           | v |
| Server Address   | <input type="text"/> |   |
| Server Port      | <input type="text"/> |   |

The window is displayed as below when choosing “Transparent” as the application mode and “TCP Server” as the protocol.

^ Server Setting

|                  |                      |   |
|------------------|----------------------|---|
| Application Mode | Transparent          | v |
| Protocol         | TCP Server           | v |
| Local IP         | <input type="text"/> |   |
| Local Port       | <input type="text"/> |   |

The window is displayed as below when choosing “Transparent” as the application mode and “UDP” as the protocol.

^ Server Setting

|                  |                      |   |
|------------------|----------------------|---|
| Application Mode | Transparent          | v |
| Protocol         | UDP                  | v |
| Local IP         | <input type="text"/> |   |
| Local Port       | <input type="text"/> |   |
| Server Address   | <input type="text"/> |   |
| Server Port      | <input type="text"/> |   |

The window is displayed as below when choosing “Transparent” as the application mode and “Robustlink” as the protocol.

^ Server Setting

|                  |             |   |
|------------------|-------------|---|
| Application Mode | Transparent | v |
| Protocol         | Robustlink  | v |

- The window is displayed as below when choosing “Modbus RTU Gateway” as the application mode and “TCP Client” as the protocol.

^ Server Setting

|                  |                      |   |
|------------------|----------------------|---|
| Application Mode | Modbus RTU Gateway   | v |
| Protocol         | TCP Client           | v |
| Server Address   | <input type="text"/> |   |
| Server Port      | <input type="text"/> |   |

The window is displayed as below when choosing “Modbus RTU Gateway” as the application mode and “TCP Server” as the protocol.

**^ Server Setting**

**Application Mode**

**Protocol**

**Local IP**

**Local Port**

The window is displayed as below when choosing “Modbus RTU Gateway” as the application mode and “UDP” as the protocol.

**^ Server Setting**

**Application Mode**

**Protocol**

**Local IP**

**Local Port**

**Server Address**

**Server Port**

The window is displayed as below when choosing “Modbus RTU Gateway” as the application mode and “Robustlink” as the protocol.

**^ Server Setting**

**Application Mode**

**Protocol**

| Server Settings  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |             |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Item             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Default     |
| Application Mode | Select from “Transparent” or “Modbus RTU Gateway”. <ul style="list-style-type: none"> <li>Transparent: Router will transmit the serial data transparently</li> <li>Modbus RTU Gateway: Router will translate the Modbus RTU data to Modbus TCP data and sent out, and vice versa</li> </ul>                                                                                                                                                                                                                                                                                                                                                  | Transparent |
| Protocol         | Select from “TCP Client”, “TCP Server”, “UDP” or “Robustlink”. <ul style="list-style-type: none"> <li>TCP Client: Router works as TCP client, initiate TCP connection to TCP server. Server address supports both IP and domain name</li> <li>TCP Server: Router works as TCP server, listening for connection request from TCP client</li> <li>UDP: Router works as UDP client</li> <li>Robustlink: Router will automatically upload the serial data to Robustlink platform under the Robustlink protocol. Robustlink is a management platform from Robustel. This function only available when Router is connects to Robustlink</li> </ul> | TCP Client  |

| Server Settings          |                                                                                                                                      |         |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                     | Description                                                                                                                          | Default |
| Server Address           | Enter the address of server which will receive the data sent from router's serial port. IP address or domain name will be available. | Null    |
| Server Port              | Enter the specified port of server which is used for receiving the serial data.                                                      | Null    |
| Local IP @ Transparent   | Enter router's LAN IP which will forward to the internet port of router.                                                             | Null    |
| Local Port @ Transparent | Enter the port of router's LAN IP.                                                                                                   | Null    |
| Local IP @ Modbus        | Enter the local IP of under Modbus mode.                                                                                             | Null    |
| Local Port @ Modbus      | Enter the local port of under Modbus mode.                                                                                           | Null    |

Click the "Status" column to view the current serial port type.

| Serial Port               | Status |    |    |                   |
|---------------------------|--------|----|----|-------------------|
| ^ Serial Port Status list |        |    |    |                   |
| Index                     | Type   | TX | RX | Connection Status |
| 1                         | RS232  | 0B | 0B |                   |
| 2                         | RS485  | 0B | 0B |                   |

### 3.14 Network > Route

This section allows you to set the static route. Static route is a form of routing that occurs when a router uses a manually-configured routing entry, rather than information from a dynamic routing traffic. Route Information Protocol (RIP) is widely used in small network with stable use rate. Open Shortest Path First (OSPF) is made router within a single autonomous system and used in large network.

#### Static Route

| Static Route         | Status      |             |         |         |           |   |
|----------------------|-------------|-------------|---------|---------|-----------|---|
| ^ Static Route Table |             |             |         |         |           |   |
| Index                | Description | Destination | Netmask | Gateway | Interface | + |

Click **+** to add static route. The maximum count is 20.

| Static Route   |                                     |
|----------------|-------------------------------------|
| ^ Static Route |                                     |
| Index          | <input type="text" value="1"/>      |
| Description    | <input type="text"/>                |
| Destination    | <input type="text"/>                |
| Netmask        | <input type="text"/>                |
| Gateway        | <input type="text"/>                |
| Interface      | <input type="text" value="wwan"/> v |

| Static Route |                                                                       |         |
|--------------|-----------------------------------------------------------------------|---------|
| Item         | Description                                                           | Default |
| Index        | Indicate the ordinal of the list.                                     | --      |
| Description  | Enter a description for this route.                                   | Null    |
| Destination  | Enter the IP address of destination host or destination network.      | Null    |
| Netmask      | Enter the Netmask of destination host or destination network.         | Null    |
| Gateway      | Define the gateway of the destination.                                | Null    |
| Interface    | Choose the corresponding port of the link that you want to configure. | wwan    |

## Status

This window allows you to view the status of route.

| Static Route  |             | Status          |             |           |        |
|---------------|-------------|-----------------|-------------|-----------|--------|
| ^ Route Table |             |                 |             |           |        |
| Index         | Destination | Netmask         | Gateway     | Interface | Metric |
| 1             | 0.0.0.0     | 0.0.0.0         | 10.122.74.9 | wwan      | 0      |
| 2             | 10.122.74.8 | 255.255.255.248 | 0.0.0.0     | wwan      | 0      |
| 3             | 172.16.0.0  | 255.255.0.0     | 0.0.0.0     | lan0      | 0      |

## 3.15 Network > Firewall

This section allows you to set the firewall and its related parameters, including Filtering, Port Mapping and DMZ.

### Filtering

The filtering rules can be used to either accept or block certain users or ports from accessing your router.

| Filtering                        | Port Mapping | Custom Rules                                                                                         | DMZ | Status |
|----------------------------------|--------------|------------------------------------------------------------------------------------------------------|-----|--------|
| <b>^ General Settings</b>        |              |                                                                                                      |     |        |
| Enable Filtering                 |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |     |        |
| Default Filtering Policy         |              | Accept <input type="button" value="v"/> <input type="button" value="?"/>                             |     |        |
| <b>^ Access Control Settings</b> |              |                                                                                                      |     |        |
| Enable Remote SSH Access         |              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF                                  |     |        |
| Enable Local SSH Access          |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |     |        |
| Enable Remote Telnet Access      |              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF                                  |     |        |
| Enable Local Telnet Access       |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |     |        |
| Enable Remote HTTP Access        |              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF                                  |     |        |
| Enable Local HTTP Access         |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |     |        |
| Enable Remote HTTPS Access       |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |     |        |
| Enable Remote Ping Respond       |              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF <input type="button" value="?"/> |     |        |

Enable DOS Defending  ON  OFF

Enable Console  ON  OFF ?

^ Filtering Rules

| Index                                                                       | Source Address | Source Port | Source MAC | Target Address | Target Port | Protocol | + |
|-----------------------------------------------------------------------------|----------------|-------------|------------|----------------|-------------|----------|---|
| <input type="button" value="Submit"/> <input type="button" value="Cancel"/> |                |             |            |                |             |          |   |

| Filtering                   |                                                                                                                                                                                                                                                                                                                                                                   |         |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                        | Description                                                                                                                                                                                                                                                                                                                                                       | Default |
| General Settings            |                                                                                                                                                                                                                                                                                                                                                                   |         |
| Enable Filtering            | Click the toggle button to enable/disable the filtering option.                                                                                                                                                                                                                                                                                                   | ON      |
| Default Filtering Policy    | Select from "Accept" or "Drop". Cannot be changed when filtering rules table is not empty. <ul style="list-style-type: none"> <li>Accept: Router will accept all the connecting requests except the hosts which fit the drop filter list</li> <li>Drop: Router will drop all the connecting requests except the hosts which fit the accept filter list</li> </ul> | Accept  |
| Access Control Settings     |                                                                                                                                                                                                                                                                                                                                                                   |         |
| Enable Remote SSH Access    | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via SSH.                                                                                                                                                                                                                                    | OFF     |
| Enable Local SSH Access     | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via SSH.                                                                                                                                                                                                                                          | ON      |
| Enable Remote Telnet Access | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via Telnet.                                                                                                                                                                                                                                 | OFF     |
| Enable Local Telnet Access  | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via Telnet.                                                                                                                                                                                                                                       | ON      |
| Enable Remote HTTP Access   | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via HTTP.                                                                                                                                                                                                                                   | OFF     |
| Enable Local HTTP Access    | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via HTTP.                                                                                                                                                                                                                                         | ON      |
| Enable Remote HTTPS Access  | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via HTTPS.                                                                                                                                                                                                                                  | ON      |
| Enable Remote Ping Respond  | Click the toggle button to enable/disable this option. When enabled, the router will reply to the Ping requests from other hosts on the Internet.                                                                                                                                                                                                                 | ON      |
| Enable DOS Defending        | Click the toggle button to enable/disable this option. When enabled, the router will defend the DOS. Dos attack is an attempt to make a machine or network resource unavailable to its intended users.                                                                                                                                                            | ON      |
| Enable Console              | Click the toggle button to enable/disable this option.                                                                                                                                                                                                                                                                                                            | ON      |

Click **+** to add filtering rule. The maximum count is 20. The window is displayed as below when defaulting “All” or choosing “ICMP” as the protocol. Here take “All” as an example.

**Filtering**

^ **Filtering Rules**

Index

Description

Source Address  ?

Source MAC  ?

Target Address  ?

Protocol All v

Action  v

The window is displayed as below when choosing “TCP”, “UDP” or “TCP-UDP” as the protocol. Here take “TCP” as an example.

^ **Filtering Rules**

Index

Description

Source Address  ?

Source Port  ?

Source MAC  ?

Target Address  ?

Target Port  ?

Protocol TCP v

Action  v

| Filtering Rules |                                                                                                                                 |         |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                     | Default |
| Index           | Indicate the ordinal of the list.                                                                                               | --      |
| Description     | Enter a description for this filtering rule.                                                                                    | Null    |
| Source Address  | Defines if access is allowed from one or a range of IP addresses which are defined by Source IP Address, or every IP addresses. | Null    |
| Source Port     | Specify an access originator and enter its source port.                                                                         | Null    |
| Source MAC      | Enter the MAC address of the defined source IP address.                                                                         | Null    |
| Target Address  | Defines if access is allowed to one or a range of IP addresses which are defined by Target IP Address, or every IP addresses.   | Null    |
| Target Port     | Enter the target port which the access originator wants to access.                                                              | Null    |

| Filtering Rules |                                                                                                                                                                                                                                                                                                                                                                                                |         |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                                                                                                                                                                                                                                                                                    | Default |
| Protocol        | Select from "All", "TCP", "UDP", "ICMP" or "TCP-UDP".<br><b>Note:</b> It is recommended that you choose "All" if you don't know which protocol of your application to use.                                                                                                                                                                                                                     | All     |
| Action          | Select from "Accept" or "Drop". <ul style="list-style-type: none"> <li>Accept: When Default Filtering Policy is drop, router will drop all the connecting requests except the hosts which fit this accept filtering list</li> <li>Drop: When Default Filtering Policy is accept, router will accept all the connecting requests except the hosts which fit this drop filtering list</li> </ul> | Drop    |

## Port Mapping

Filtering | **Port Mapping** | Custom Rules | DMZ | Status

^ Port Mapping Rules

| Index | Description | Internet Port | Local IP | Local Port | Protocol |   |
|-------|-------------|---------------|----------|------------|----------|---|
|       |             |               |          |            |          | + |

Click **+** to add port mapping rules. The maximum rule count is 40.

Port Mapping

^ Port Mapping Rules

Index:

Description:

Remote IP:  ?

Internet Port:  ?

Local IP:

Local Port:  ?

Protocol:  v

| Port Mapping Rules |                                                                                                                                                 |         |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item               | Description                                                                                                                                     | Default |
| Index              | Indicate the ordinal of the list.                                                                                                               | --      |
| Description        | Enter a description for this port mapping.                                                                                                      | Null    |
| Remote IP          | Specify the host or network which can access to the local IP address. Empty means unlimited. e.g. 10.10.10.10/255.255.255.255 or 192.168.1.0/24 | Null    |
| Internet Port      | Set the internet port of router which can be accessed by other hosts from internet.                                                             | Null    |
| Local IP           | Enter router's LAN IP which will forward to the internet port of router.                                                                        | Null    |
| Local Port         | Enter the port of router's LAN IP.                                                                                                              | Null    |
| Protocol           | Select from "TCP", "UDP" or "TCP-UDP" as your application required.                                                                             | TCP-UDP |

## Custom Rules

Filtering | Port Mapping | **Custom Rules** | DMZ | Status

^ Custom Iptables Rules

| Index | Description | Rule | + |
|-------|-------------|------|---|
|-------|-------------|------|---|

Click **+** to add custom rules.

Custom Rules

^ Custom Iptables Rule

Index

Description

Rule  ?

| Custom Iptables Rule |                                    |         |
|----------------------|------------------------------------|---------|
| Item                 | Description                        | Default |
| Index                | Indicate the ordinal of the list.  | --      |
| Description          | Enter the description of the rule. | Null    |
| Rule                 | Specify one iptables rule.         | Null    |

## DMZ

Filtering | Port Mapping | Custom Rules | **DMZ** | Status

^ DMZ Settings

Enable DMZ

Host IP Address

Source IP Address  ?

| DMZ Settings      |                                                                                                                                                               |         |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item              | Description                                                                                                                                                   | Default |
| Enable DMZ        | Click the toggle button to enable/disable DMZ. DMZ host is a host on the internal network that has all ports exposed, except those ports otherwise forwarded. | OFF     |
| Host IP Address   | Enter the IP address of the DMZ host on your internal network.                                                                                                | Null    |
| Source IP Address | Set the address which can talk to the DMZ host. 0.0.0.0 means for any addresses.                                                                              | Null    |

## Status

| Filtering              | Port Mapping | Custom Rules | DMZ      | Status |     |           |             |
|------------------------|--------------|--------------|----------|--------|-----|-----------|-------------|
| <b>^ Chain Input</b>   |              |              |          |        |     |           |             |
| Index                  | Packets      | Target       | Protocol | In     | Out | Source    | Destination |
| 1                      | 0            | REJECT       | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 2                      | 52           | ACCEPT       | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 3                      | 0            | DROP         | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 4                      | 0            | ACCEPT       | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 5                      | 0            | DROP         | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 6                      | 0            | ACCEPT       | icmp     | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| 7                      | 0            | DROP         | icmp     | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| <b>^ Chain Forward</b> |              |              |          |        |     |           |             |
| Index                  | Packets      | Target       | Protocol | In     | Out | Source    | Destination |
| 1                      | 0            | TCPMSS       | tcp      | *      | *   | 0.0.0.0/0 | 0.0.0.0/0   |
| <b>^ Chain Output</b>  |              |              |          |        |     |           |             |
| Index                  | Packets      | Target       | Protocol | In     | Out | Source    | Destination |

### 3.16 Network > IP Passthrough

Click **Network > IP Passthrough > IP Passthrough** to enable or disable the IP Pass-through option.



If router enables the IP Pass-through, the terminal device (such as PC) will enable the DHCP Client mode and connect to LAN port of the router; and after the router dial up successfully, the PC will automatically obtain the IP address and DNS server address which assigned by ISP.

### 3.17 VPN > IPsec

This section allows you to set the IPsec and the related parameters. Internet Protocol Security (IPsec) is a protocol suite for secure Internet Protocol (IP) communications that works by authenticating and encrypting each IP packet of a communication session.

#### General

| General Settings @ General |                                                                                                                                                        |         |
|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                       | Description                                                                                                                                            | Default |
| Enable NAT Traversal       | Click the toggle button to enable/disable the NAT Traversal function. This option must be enabled when router under NAT environment.                   | ON      |
| Keepalive                  | Set the keepalive time, measured in seconds. The router will send packets to NAT server every keepalive time to avoid record remove from the NAT list. | 60      |
| Debug Enable               | Click the toggle button to enable/disable this option. Enable for IPsec VPN information output to the debug port.                                      | OFF     |

#### Tunnel

Click **+** to add tunnel settings. The maximum count is 3.

Tunnel

^ General Settings

**Index**

**Enable**  ON  OFF

**Description**

**Gateway**  ?

**Mode** Tunnel v

**Protocol** ESP v

**Local Subnet**  ?

**Remote Subnet**  ?

| General Settings @ Tunnel |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |         |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Default |
| Index                     | Indicate the ordinal of the list.                                                                                                                                                                                                                                                                                                                                                                                                                                                | --      |
| Enable                    | Click the toggle button to enable/disable this IPsec tunnel.                                                                                                                                                                                                                                                                                                                                                                                                                     | ON      |
| Description               | Enter a description for this IPsec tunnel.                                                                                                                                                                                                                                                                                                                                                                                                                                       | Null    |
| Gateway                   | Enter the address of remote side IPsec VPN server. 0.0.0.0 represents for any address.                                                                                                                                                                                                                                                                                                                                                                                           | Null    |
| Mode                      | Select from "Tunnel" and "Transport". <ul style="list-style-type: none"> <li>Tunnel: Commonly used between gateways, or at an end-station to a gateway, the gateway acting as a proxy for the hosts behind it</li> <li>Transport: Used between end-stations or between an end-station and a gateway, if the gateway is being treated as a host-for example, an encrypted Telnet session from a workstation to a router, in which the router is the actual destination</li> </ul> | Tunnel  |
| Protocol                  | Select the security protocols from "ESP" and "AH". <ul style="list-style-type: none"> <li>ESP: Use the ESP protocol</li> <li>AH: Use the AH protocol</li> </ul>                                                                                                                                                                                                                                                                                                                  | ESP     |
| Local Subnet              | Enter the local subnet's address with mask protected by IPsec, e.g. 192.168.1.0/24                                                                                                                                                                                                                                                                                                                                                                                               | Null    |
| Remote Subnet             | Enter the remote subnet's address with mask protected by IPsec, e.g. 10.8.0.0/24                                                                                                                                                                                                                                                                                                                                                                                                 | Null    |

The window is displayed as below when choosing “PSK” as the authentication type.



The screenshot shows the 'IKE Settings' window with the following configuration:

| Setting                  | Value    |
|--------------------------|----------|
| IKE Type                 | IKEv1    |
| Negotiation Mode         | Main     |
| Authentication Algorithm | MD5      |
| Encryption Algorithm     | 3DES     |
| IKE DH Group             | DHgroup2 |
| Authentication Type      | PSK      |
| PSK Secret               | •••••    |
| Local ID Type            | Default  |
| Remote ID Type           | Default  |
| IKE Lifetime             | 86400    |

The window is displayed as below when choosing “CA” as the authentication type.



The screenshot shows the 'IKE Settings' window with the following configuration:

| Setting                  | Value    |
|--------------------------|----------|
| IKE Type                 | IKEv1    |
| Negotiation Mode         | Main     |
| Authentication Algorithm | MD5      |
| Encryption Algorithm     | 3DES     |
| IKE DH Group             | DHgroup2 |
| Authentication Type      | CA       |
| Private Key Password     |          |
| IKE Lifetime             | 86400    |

The window is displayed as below when choosing “xAuth PSK” as the authentication type.

^ IKE Settings

**Negotiation Mode**

**Authentication Algorithm**

**Encryption Algorithm**

**IKE DH Group**

**Authentication Type**

**PSK Secret**

**Local ID Type**

**Remote ID Type**

**Username**  ?

**Password**  ?

**IKE Lifetime**  ?

The window is displayed as below when choosing “xAuth CA” as the authentication type.

^ IKE Settings

**IKE Type**

**Negotiation Mode**

**Authentication Algorithm**

**Encryption Algorithm**

**IKE DH Group**

**Authentication Type**

**PSK Secret**

**Local ID Type**

**Remote ID Type**

**Username**  ?

**Password**  ?

**IKE Lifetime**  ?

| IKE Settings             |                                                                                                                                                                                                                                                                                           |         |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                     | Description                                                                                                                                                                                                                                                                               | Default |
| IKE Type                 | Select from IKE v1 and IKE v2.                                                                                                                                                                                                                                                            | IKE v1  |
| Negotiation Mode         | Select from “Main” and “Aggressive” for the IKE negotiation mode in phase 1. If the IP address of one end of an IPsec tunnel is obtained dynamically, the IKE negotiation mode must be aggressive. In this case, SAs can be established as long as the username and password are correct. | Main    |
| Authentication Algorithm | Select from “MD5”, “SHA1”, “SHA2 256” or “SHA2 512” to be used in IKE negotiation.                                                                                                                                                                                                        | MD5     |

| IKE Settings         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |          |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Default  |
| Encryption Algorithm | Select from "3DES", "AES128" and "AES256" to be used in IKE negotiation. <ul style="list-style-type: none"> <li>3DES: Use 168-bit 3DES encryption algorithm in CBC mode</li> <li>AES128: Use 128-bit AES encryption algorithm in CBC mode</li> <li>AES256: Use 256-bit AES encryption algorithm in CBC mode</li> </ul>                                                                                                                                                                                                                                                | 3DES     |
| IKE DH Group         | Select from "DHgroup2", "DHgroup5", "DHgroup14", "DHgroup15", "DHgroup16", "DHgroup17" or "DHgroup18" to be used in key negotiation phase 1.                                                                                                                                                                                                                                                                                                                                                                                                                          | DHgroup2 |
| Authentication Type  | Select from "PSK", "CA", "xAuth PSK" and "xAuth CA" to be used in IKE negotiation. <ul style="list-style-type: none"> <li>PSK: Pre-shared Key</li> <li>CA: Certification Authority</li> <li>xAuth: Extended Authentication to AAA server</li> </ul>                                                                                                                                                                                                                                                                                                                   | PSK      |
| PSK Secret           | Enter the pre-shared key.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Null     |
| Local ID Type        | Select from "Default", "FQDN" and "User FQDN" for IKE negotiation. <ul style="list-style-type: none"> <li>Default: Uses an IP address as the ID in IKE negotiation</li> <li>FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com.</li> <li>User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security gateway, e.g., test@robustel.com.</li> </ul> | Default  |
| Remote ID Type       | Select from "Default", "FQDN" and "User FQDN" for IKE negotiation. <ul style="list-style-type: none"> <li>Default: Uses an IP address as the ID in IKE negotiation</li> <li>FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com.</li> <li>User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security gateway, e.g., test@robustel.com.</li> </ul> | Default  |
| Private Key Password | Enter the private key under the "CA" and "xAuth CA" authentication types.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Null     |
| Username             | Enter the username used for the "xAuth PSK" and "xAuth CA" authentication types.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Null     |
| Password             | Enter the password used for the "xAuth PSK" and "xAuth CA" authentication types.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Null     |
| IKE Lifetime         | Set the lifetime in IKE negotiation. Before an SA expires, IKE negotiates a new SA. As soon as the new SA is set up, it takes effect immediately and the old one will be cleared automatically when it expires.                                                                                                                                                                                                                                                                                                                                                       | 86400    |

If click **VPN > IPsec > Tunnel > General Settings**, and choose **ESP** as protocol. The specific parameter configuration is shown as below.

**^ SA Settings**

|                          |                                       |   |
|--------------------------|---------------------------------------|---|
| Encrypt Algorithm        | <input type="text" value="3DES"/>     | v |
| Authentication Algorithm | <input type="text" value="MD5"/>      | v |
| PFS Group                | <input type="text" value="DHgroup2"/> | v |
| SA Lifetime              | <input type="text" value="28800"/>    | ? |
| DPD Interval             | <input type="text" value="60"/>       | ? |
| DPD Failures             | <input type="text" value="180"/>      | ? |

If choose **AH** as protocol, the window of SA Settings is displayed as below.

**^ General Settings**

|               |                                                                     |   |
|---------------|---------------------------------------------------------------------|---|
| Index         | <input type="text" value="1"/>                                      |   |
| Enable        | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |   |
| Description   | <input type="text"/>                                                |   |
| Gateway       | <input type="text"/>                                                | ? |
| Mode          | <input type="text" value="Tunnel"/>                                 | v |
| Protocol      | <input type="text" value="AH"/>                                     | v |
| Local Subnet  | <input type="text"/>                                                | ? |
| Remote Subnet | <input type="text"/>                                                | ? |

**^ SA Settings**

|                          |                                       |   |
|--------------------------|---------------------------------------|---|
| Authentication Algorithm | <input type="text" value="MD5"/>      | v |
| PFS Group                | <input type="text" value="DHgroup2"/> | v |
| SA Lifetime              | <input type="text" value="28800"/>    | ? |
| DPD Interval             | <input type="text" value="60"/>       | ? |
| DPD Failures             | <input type="text" value="180"/>      | ? |

**^ Advanced Settings**

|                    |                                                                     |   |
|--------------------|---------------------------------------------------------------------|---|
| Enable Compression | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |   |
| Expert Options     | <input type="text"/>                                                | ? |

| SA Settings              |                                                                                                                                                                                                                                                            |         |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                     | Description                                                                                                                                                                                                                                                | Default |
| Encrypt Algorithm        | Select from "3DES", "AES128" or "AES256" when you select "ESP" in "Protocol". Higher security means more complex implementation and lower speed. DES is enough to meet general requirements. Use 3DES when high confidentiality and security are required. | 3DES    |
| Authentication Algorithm | Select from "MD5", "SHA1", "SHA2 256" or "SHA2 512" to be used in SA negotiation.                                                                                                                                                                          | MD5     |

| SA Settings        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |          |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Default  |
| PFS Group          | Select from "DHgroup2", "DHgroup5", "DHgroup14", "DHgroup15", "DHgroup16", "DHgroup17" or "DHgroup18" to be used in SA negotiation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | DHgroup2 |
| SA Lifetime        | Set the IPsec SA lifetime. When negotiating to set up IPsec SAs, IKE uses the smaller one between the lifetime set locally and the lifetime proposed by the peer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 28800    |
| DPD Interval       | Set the interval after which DPD is triggered if no IPsec protected packets is received from the peer. DPD is a Dead peer detection. DPD irregularly detects dead IKE peers. When the local end sends an IPsec packet, DPD checks the time the last IPsec packet was received from the peer. If the time exceeds the DPD interval, it sends a DPD hello to the peer. If the local end receives no DPD acknowledgment within the DPD packet retransmission interval, it retransmits the DPD hello. If the local end still receives no DPD acknowledgment after having made the maximum number of retransmission attempts, it considers the peer already dead, and clears the IKE SA and the IPsec SAs based on the IKE SA. | 60       |
| DPD Failures       | Set the timeout of DPD (Dead Peer Detection) packets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 180      |
| Advanced Settings  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |          |
| Enable Compression | Click the toggle button to enable/disable this option. Enable to compress the inner headers of IP packets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | OFF      |
| Expert Options     | Add more PPP configuration options here, format: config-desc;config-desc, e.g. protostack=netkey;plutodebug=none                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Null     |

## Status

This section allows you to view the status of the IPsec tunnel.

| General               | Tunnel      | Status | x509   |
|-----------------------|-------------|--------|--------|
| ^ IPsec Tunnel Status |             |        |        |
| Index                 | Description | Status | Uptime |

## x509

User can upload the X509 certificates for the IPsec tunnel in this section.

**^ X509 Settings** ?

Tunnel Name:  v

Local Certificate:  ↑

Remote Certificate:  ↑

Private Key:  ↑

| ^ Certificate Files |           |           |                   |
|---------------------|-----------|-----------|-------------------|
| Index               | File Name | File Size | Modification Time |

| x509                     |                                                                                                                                                                                                                                                   |          |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item                     | Description                                                                                                                                                                                                                                       | Default  |
| <b>X509 Settings</b>     |                                                                                                                                                                                                                                                   |          |
| Tunnel Name              | Choose a valid tunnel.                                                                                                                                                                                                                            | Tunnel 1 |
| Local Certificate        | Click on “Choose File” to upload a local certificate file from your computer, and then import this file into your router.<br>The correct file format is displayed as follows:<br>@ca.crt<br>@remote.crt<br>@local.crt<br>@private.key<br>@crl.pem | Null     |
| Remote Certificate       | Click on “Choose File” to upload a remote certificate file from your computer, and then import this file into your router.                                                                                                                        | Null     |
| Private Key              | Click on “Choose File” to upload a private key from your computer                                                                                                                                                                                 | Null     |
| <b>Certificate Files</b> |                                                                                                                                                                                                                                                   |          |
| Index                    | Indicate the ordinal of the list.                                                                                                                                                                                                                 | --       |
| File Name                | Show the imported certificate’s name.                                                                                                                                                                                                             | Null     |
| File Size                | Show the size of the certificate file.                                                                                                                                                                                                            | Null     |
| Modification Time        | Show the timestamp of that the last time to modify the certificate file.                                                                                                                                                                          | Null     |

### 3.18 VPN > OpenVPN

This section allows you to set the OpenVPN and the related parameters. OpenVPN is an open-source software application that implements virtual private network (VPN) techniques for creating secure point-to-point or site-to-site connections in routed or bridged configurations and remote access facilities. Router supports point-to-point and point-to-points connections.

#### OpenVPN

| OpenVPN           | Status | x509        |      |          |                |                |   |
|-------------------|--------|-------------|------|----------|----------------|----------------|---|
| ^ Tunnel Settings |        |             |      |          |                |                |   |
| Index             | Enable | Description | Mode | Protocol | Server Address | Interface Type | + |

Click **+** to add tunnel settings. The maximum count is 3. The window is displayed as below when choosing “None” as the authentication type. By default, the mode is “Client”.

#### ^ General Settings

Index

Enable  ON  OFF

Description

Mode  v

Protocol  v

Server Address

Server Port

Interface Type  v

Authentication Type  v ?

Renegotiation Interval  ?

Keepalive Interval  ?

Keepalive Timeout  ?

Enable Compression  ON  OFF

Enable NAT  ON  OFF

Verbose Level  v ?

The window is displayed as below when choosing “P2P” as the mode.

### ^ General Settings

|                     |                                                                     |
|---------------------|---------------------------------------------------------------------|
| Index               | <input type="text" value="1"/>                                      |
| Enable              | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description         | <input type="text"/>                                                |
| Mode                | <input type="text" value="P2P"/> v                                  |
| Protocol            | <input type="text" value="UDP"/> v                                  |
| Server Address      | <input type="text"/>                                                |
| Server Port         | <input type="text" value="1194"/>                                   |
| Interface Type      | <input type="text" value="TUN"/> v                                  |
| Authentication Type | <input type="text" value="None"/> v ?                               |
| Local IP            | <input type="text" value="10.8.0.1"/>                               |
| Remote IP           | <input type="text" value="10.8.0.2"/>                               |
| Keepalive Interval  | <input type="text" value="20"/> ?                                   |
| Keepalive Timeout   | <input type="text" value="120"/> ?                                  |
| Enable Compression  | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT          | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level       | <input type="text" value="0"/> v ?                                  |

The window is displayed as below when choosing “Preshared” as the authentication type.

**^ General Settings**

|                        |                                                                     |
|------------------------|---------------------------------------------------------------------|
| Index                  | <input type="text" value="1"/>                                      |
| Enable                 | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description            | <input type="text"/>                                                |
| Mode                   | <input type="text" value="Client"/> v                               |
| Protocol               | <input type="text" value="UDP"/> v                                  |
| Server Address         | <input type="text"/>                                                |
| Server Port            | <input type="text" value="1194"/>                                   |
| Interface Type         | <input type="text" value="TUN"/> v                                  |
| Authentication Type    | <input type="text" value="Preshared"/> v ?                          |
| Encrypt Algorithm      | <input type="text" value="BF"/> v                                   |
| Renegotiation Interval | <input type="text" value="86400"/> ?                                |
| Keepalive Interval     | <input type="text" value="20"/> ?                                   |
| Keepalive Timeout      | <input type="text" value="120"/> ?                                  |
| Enable Compression     | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT             | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level          | <input type="text" value="0"/> v ?                                  |

The window is displayed as below when choosing “Password” as the authentication type.

### ^ General Settings

|                        |                                                                     |
|------------------------|---------------------------------------------------------------------|
| Index                  | <input type="text" value="1"/>                                      |
| Enable                 | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description            | <input type="text"/>                                                |
| Mode                   | <input type="text" value="Client"/> v                               |
| Protocol               | <input type="text" value="UDP"/> v                                  |
| Server Address         | <input type="text"/>                                                |
| Server Port            | <input type="text" value="1194"/>                                   |
| Interface Type         | <input type="text" value="TUN"/> v                                  |
| Authentication Type    | <input type="text" value="Password"/> v ?                           |
| Username               | <input type="text"/>                                                |
| Password               | <input type="text"/>                                                |
| Encrypt Algorithm      | <input type="text" value="BF"/> v                                   |
| Renegotiation Interval | <input type="text" value="86400"/> ?                                |
| Keepalive Interval     | <input type="text" value="20"/> ?                                   |
| Keepalive Timeout      | <input type="text" value="120"/> ?                                  |
| Enable Compression     | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT             | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level          | <input type="text" value="0"/> v ?                                  |

The window is displayed as below when choosing "X509CA" as the authentication type.

**^ General Settings**

|                        |                                                                     |
|------------------------|---------------------------------------------------------------------|
| Index                  | <input type="text" value="1"/>                                      |
| Enable                 | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description            | <input type="text"/>                                                |
| Mode                   | <input type="text" value="Client"/> v                               |
| Protocol               | <input type="text" value="UDP"/> v                                  |
| Server Address         | <input type="text"/>                                                |
| Server Port            | <input type="text" value="1194"/>                                   |
| Interface Type         | <input type="text" value="TUN"/> v                                  |
| Authentication Type    | <input type="text" value="X509CA"/> v ?                             |
| Encrypt Algorithm      | <input type="text" value="BF"/> v                                   |
| Renegotiation Interval | <input type="text" value="86400"/> ?                                |
| Keepalive Interval     | <input type="text" value="20"/> ?                                   |
| Keepalive Timeout      | <input type="text" value="120"/> ?                                  |
| Private Key Password   | <input type="text"/>                                                |
| Enable Compression     | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT             | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level          | <input type="text" value="0"/> v ?                                  |

The window is displayed as below when choosing “X509CA Password” as the authentication type.

^ **General Settings**

Index

Enable  ON  OFF

Description

Mode

Protocol

Server Address

Server Port

Interface Type

Authentication Type

Username

Password

Encrypt Algorithm

Renegotiation Interval

Keepalive Interval

Keepalive Timeout

Private Key Password

Enable Compression  ON  OFF

Enable NAT  ON  OFF

Verbose Level

| General Settings @ OpenVPN |                                                                                                                                                                                                                                                          |         |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                       | Description                                                                                                                                                                                                                                              | Default |
| Index                      | Indicate the ordinal of the list.                                                                                                                                                                                                                        | --      |
| Enable                     | Click the toggle button to enable/disable this OpenVPN tunnel.                                                                                                                                                                                           | ON      |
| Description                | Enter a description for this OpenVPN tunnel.                                                                                                                                                                                                             | Null    |
| Mode                       | Select from “P2P” or “Client”.                                                                                                                                                                                                                           | Client  |
| Protocol                   | Select from “UDP”, “TCP-Client” or “TCP-Server”.                                                                                                                                                                                                         | UDP     |
| Server Address             | Enter the end-to-end IP address or the domain of the remote OpenVPN server.                                                                                                                                                                              | Null    |
| Server Port                | Enter the end-to-end listener port or the listener port of the OpenVPN server.                                                                                                                                                                           | 1194    |
| Interface Type             | Select from “TUN”, “TAP” which are two different kinds of device interface for OpenVPN. The difference between TUN and TAP device is that a TUN device is a point-to-point virtual device on network while a TAP device is a virtual device on Ethernet. | TUN     |

| General Settings @ OpenVPN |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |          |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Default  |
| Authentication Type        | Select from “None”, “Preshared”, “Password”, “X509CA” and “X509CA Password”.<br><b>Note:</b> “None” and “Preshared” authentication type are only working with P2P mode.                                                                                                                                                                                                                                                                                                                                              | None     |
| Username                   | Enter the username used for “Password” or “X509CA Password” authentication type.                                                                                                                                                                                                                                                                                                                                                                                                                                     | Null     |
| Password                   | Enter the password used for “Password” or “X509CA Password” authentication type.                                                                                                                                                                                                                                                                                                                                                                                                                                     | Null     |
| Local IP                   | Enter the local virtual IP.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 10.8.0.1 |
| Remote IP                  | Enter the remote virtual IP.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 10.8.0.2 |
| Encrypt Algorithm          | Select from “BF”, “DES”, “DES-EDE3”, “AES128”, “AES192” and “AES256”. <ul style="list-style-type: none"> <li>BF: Use 128-bit BF encryption algorithm in CBC mode</li> <li>DES: Use 64-bit DES encryption algorithm in CBC mode</li> <li>DES-EDE3: Use 192-bit 3DES encryption algorithm in CBC mode</li> <li>AES128: Use 128-bit AES encryption algorithm in CBC mode</li> <li>AES192: Use 192-bit AES encryption algorithm in CBC mode</li> <li>AES256: Use 256-bit AES encryption algorithm in CBC mode</li> </ul> | BF       |
| Renegotiation Interval     | Set the renegotiation interval. If connection failed, OpenVPN will renegotiate when the renegotiation interval reached.                                                                                                                                                                                                                                                                                                                                                                                              | 86400    |
| Keepalive Interval         | Set keepalive (ping) interval to check if the tunnel is active.                                                                                                                                                                                                                                                                                                                                                                                                                                                      | 20       |
| Keepalive Timeout          | Set the keepalive timeout. Trigger OpenVPN restart after n seconds pass without reception of a ping or other packet from remote.                                                                                                                                                                                                                                                                                                                                                                                     | 120      |
| Private Key Password       | Enter the private key password under the “X509CA” and “X509CA Password” authentication type.                                                                                                                                                                                                                                                                                                                                                                                                                         | Null     |
| Enable Compression         | Click the toggle button to enable/disable this option. Enable to compress the data stream of the header.                                                                                                                                                                                                                                                                                                                                                                                                             | ON       |
| Enable NAT                 | Click the toggle button to enable/disable the NAT option. When enabled, the source IP address of host behind router will be disguised before accessing the remote OpenVPN client.                                                                                                                                                                                                                                                                                                                                    | OFF      |
| Verbose Level              | Select the level of the output log and values from 0 to 11. <ul style="list-style-type: none"> <li>0: No output except fatal errors</li> <li>1~4: Normal usage range</li> <li>5: Output R and W characters to the console for each packet read and write</li> <li>6~11: Debug info range</li> </ul>                                                                                                                                                                                                                  | 0        |

**^ Advanced Settings**

Enable HMAC Firewall  ON  OFF

Enable PKCS#12  ON  OFF

Enable nsCertType  ON  OFF

Expert Options  ?

| Advanced Settings @ OpenVPN |                                                                                                                                                                                  |         |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                        | Description                                                                                                                                                                      | Default |
| Enable HMAC Firewall        | Click the toggle button to enable/disable this option. Add an additional layer of HMAC authentication on top of the TLS control channel to protect against DoS attacks.          | OFF     |
| Enable PKCS#12              | Click the toggle button to enable/disable the PKCS#12 certificate. It is an exchange of digital certificate encryption standard, used to describe personal identity information. | OFF     |
| Enable nsCertType           | Click the toggle button to enable/disable nsCertType. Require that peer certificate was signed with an explicit nsCertType designation of "server".                              | OFF     |
| Expert Options              | Enter some other options of OpenVPN in this field. Each expression can be separated by a ‘;’.                                                                                    | Null    |

## Status

This section allows you to view the status of the OpenVPN tunnel.

OpenVPN
Status
x509

**^ OpenVPN Tunnel Status**

| Index | Description | Status | Uptime | Local IP |
|-------|-------------|--------|--------|----------|
|-------|-------------|--------|--------|----------|

## x509

User can upload the X509 certificates for the OpenVPN in this section.

OpenVPN | Status | x509

**^ X509 Settings** ?

Tunnel Name: Tunnel 1 v

Root CA:  ↑

Certificate File:  ↑

Private Key:  ↑

TLS-Auth Key:  ↑

PKCS#12 Certificate:  ↑

Pre-Share Key:  ↑

**^ Certificate Files**

| Index | File Name | File Size | Modification Time |
|-------|-----------|-----------|-------------------|
|-------|-----------|-----------|-------------------|

| x509                     |                                                                          |          |
|--------------------------|--------------------------------------------------------------------------|----------|
| Item                     | Description                                                              | Default  |
| <b>X509 Settings</b>     |                                                                          |          |
| Tunnel Name              | Choose a valid tunnel.                                                   | Tunnel 1 |
| Root CA                  | Click on "Choose File" to upload root CA.                                | Null     |
| Certificate File         | Click on "Choose File" to upload certificate file.                       | Null     |
| Private Key              | Click on "Choose File" to upload private key.                            | Null     |
| TLS-Auth Key             | Click on "Choose File" to upload TLS-Auth key.                           | Null     |
| PKCS#12 Certificate      | Click on "Choose File" to upload PKCS#12 Certificate.                    | Null     |
| Pre-share Key            | Click on "Choose File" to upload Pre-share Key.                          | Null     |
| <b>Certificate Files</b> |                                                                          |          |
| Index                    | Indicate the ordinal of the list.                                        | --       |
| Filename                 | Show the imported certificate's name.                                    | Null     |
| File Size                | Show the size of the certificate file.                                   | Null     |
| Modification Time        | Show the timestamp of that the last time to modify the certificate file. | Null     |

### 3.19 VPN > GRE

This section allows you to set the GRE and the related parameters. Generic Routing Encapsulation (GRE) is a tunneling protocol that can encapsulate a wide variety of network layer protocols inside virtual point-to-point links over an Internet Protocol network.

#### GRE

GRE | Status

**^ Tunnel Settings**

| Index | Enable | Description | Remote IP Address | + |
|-------|--------|-------------|-------------------|---|
|-------|--------|-------------|-------------------|---|

Click **+** to add tunnel settings. The maximum count is 3.

**GRE**

^ **Tunnel Settings**

Index

Enable  ON  OFF

Description

Remote IP Address

Local Virtual IP Address

Local Virtual Netmask

Remote Virtual IP Address

Enable Default Route  ON  OFF

Enable NAT  ON  OFF

Secrets

| Tunnel Settings @ GRE     |                                                                                                                                  |         |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                      | Description                                                                                                                      | Default |
| Index                     | Indicate the ordinal of the list.                                                                                                | --      |
| Enable                    | Click the toggle button to enable/disable this GRE tunnel.                                                                       | ON      |
| Description               | Enter a description for this GRE tunnel.                                                                                         | Null    |
| Remote IP Address         | Set the remote real IP address of the GRE tunnel.                                                                                | Null    |
| Local Virtual IP Address  | Set the local virtual IP address of the GRE tunnel.                                                                              | Null    |
| Local Virtual Netmask     | Set the local virtual Netmask of the GRE tunnel.                                                                                 | Null    |
| Remote Virtual IP Address | Set the remote virtual IP Address of the GRE tunnel.                                                                             | Null    |
| Enable Default Route      | Click the toggle button to enable/disable this option. When enabled, all the traffics of the router will go through the GRE VPN. | OFF     |
| Enable NAT                | Click the toggle button to enable/disable this option. This option must be enabled when router under NAT environment.            | Disable |
| Secrets                   | Set the key of the GRE tunnel.                                                                                                   | Null    |

## Status

This section allows you to view the status of GRE tunnel.

GRE
Status

^ **GRE tunnel status**

| Index | Description | Status | Local IP Address | Remote IP Address | Uptime |
|-------|-------------|--------|------------------|-------------------|--------|
|-------|-------------|--------|------------------|-------------------|--------|

## 3.20 Services > Syslog

This section allows you to set the syslog parameters. The system log of the router can be saved in the local, also

supports to be sent to remote log server and specified application debugging. By default, the “Log to Remote” option is disabled.

Syslog

^ Syslog Settings

|               |                                                                                                      |
|---------------|------------------------------------------------------------------------------------------------------|
| Enable        | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF                                  |
| Syslog Level  | Debug <input type="button" value="v"/>                                                               |
| Save Position | RAM <input type="button" value="v"/> <input type="button" value="?"/>                                |
| Log to Remote | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF <input type="button" value="?"/> |

The window is displayed as below when enabling the “Log to Remote” option.

| Syslog Settings   |                                                                                                                                                                                                                     |         |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item              | Description                                                                                                                                                                                                         | Default |
| Enable            | Click the toggle button to enable/disable the Syslog settings option.                                                                                                                                               | OFF     |
| Syslog Level      | Select from “Debug”, “Info”, “Notice”, “Warning” or “Error”, which from low to high. The lower level will output more syslog in detail.                                                                             | Debug   |
| Save Position     | Select the save position from “RAM”, “NVM” or “Console”. Choose “RAM”, the data will be cleared after reboot.<br><b>Note:</b> It's not recommended that saving syslog to NVM (Non-Volatile Memory) for a long time. | RAM     |
| Log to Remote     | Click the toggle button to enable/disable this option. Enable to allow router sending syslog to the remote syslog server. You need to enter the IP and Port of the syslog server.                                   | OFF     |
| Add Identifier    | Click the toggle button to enable/disable this option. When enabled, you can add serial number to syslog message which used for loading Syslog to RobustLink.                                                       | OFF     |
| Remote IP Address | Enter the IP address of syslog server when enabling the “Log to Remote” option.                                                                                                                                     | Null    |
| Remote Port       | Enter the port of syslog server when enabling the “Log to Remote” option.                                                                                                                                           | 514     |

### 3.21 Services > Event

This section allows you to set the event parameters. Event feature provides an ability to send alerts by SMS or Email when certain system events occur.

| General Settings @ Event |                                                                                                                                                                     |         |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                     | Description                                                                                                                                                         | Default |
| Signal Quality Threshold | Set the threshold for signal quality. Router will generate a log event when the actual threshold is less than the specified threshold. 0 means disable this option. | 0       |

Event Notification Query

**^ Event Notification Group Settings**

Index Description Send SMS Send Email Save to NVM +

Click + button to add an Event parameters.

**^ General Settings**

Index

Description

Send SMS  ON  OFF

Phone Number  ?

Send Email  ON  OFF

Email Addresses  ?

Save to NVM  ON  OFF ?

**^ Event Selection** ?

System Startup  ON  OFF

System Reboot  ON  OFF

System Time Update  ON  OFF

Configuration Change  ON  OFF

Cellular Network Type Change  ON  OFF

Cellular Data Stats Clear  ON  OFF

Cellular Data Traffic Overflow  ON  OFF

Poor Signal Quality  ON  OFF

Link Switching  ON  OFF

WAN Up  ON  OFF

WAN Down  ON  OFF

WLAN Up  ON  OFF

WLAN Down  ON  OFF

WWAN Up  ON  OFF

WWAN Down  ON  OFF

IPSec Connection Up  ON  OFF

IPSec Connection Down  ON  OFF

OpenVPN Connection Up  ON  OFF

OpenVPN Connection Down  ON  OFF

LAN Port Link Up  ON  OFF

LAN Port Link Down  ON  OFF

USB Device Connect  ON  OFF

USB Device Remove  ON  OFF

DDNS Update Success  ON  OFF

DDNS Update Fail  ON  OFF

Received SMS  ON  OFF

SMS Command Execute  ON  OFF

DI 1 ON  ON  OFF

DI 1 OFF  ON  OFF

DI 1 Counter Overflow  ON  OFF

DI 2 ON  ON  OFF

DI 2 OFF  ON  OFF

DI 2 Counter Overflow  ON  OFF

| General Settings @ Notification |                                                                                                                                                                                                                                                              |         |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                            | Description                                                                                                                                                                                                                                                  | Default |
| Index                           | Indicate the ordinal of the list.                                                                                                                                                                                                                            | --      |
| Description                     | Enter a description for this group.                                                                                                                                                                                                                          | Null    |
| Sent SMS                        | Click the toggle button to enable/disable this option. When enabled, the router will send notification to the specified phone numbers via SMS if event occurs. Set the related phone number in "3.24 Services > Email", and use ';' to separate each number. | OFF     |
| Phone Number                    | Enter the phone numbers used for receiving event notification. Use a semicolon (;) to separate each number.                                                                                                                                                  | Null    |
| Send Email                      | Click the toggle button to enable/disable this option. When enabled, the router will send notification to the specified email box via Email if event occurs. Set the related email address in "3.24 Services > Email".                                       | OFF     |
| Email Address                   | Enter the email addresses used for receiving event notification. Use a space to separate each address.                                                                                                                                                       | Null    |
| Save to NVM                     | Click the toggle button to enable/disable this option. Enable to save event to nonvolatile memory.                                                                                                                                                           | OFF     |

In the following window you can query various types of events record. Click **Refresh** to query filtered events while click **Clear** to clear the event records in the window.

Event
Notification
Query

^ Event Details

Save Position  v

Filtering

```
Feb 27 09:13:05, LAN port link up, eth1
Feb 27 09:13:17, WWAN (cellular) up, WWAN1, ip=10.122.74.11
Feb 27 09:13:30, system time update
```

Clear
Refresh

| Event Details  |                                                                                                                                                                                                                                            |         |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item           | Description                                                                                                                                                                                                                                | Default |
| Save Position  | Select the events' save position from "RAM" or "NVM". <ul style="list-style-type: none"> <li>RAM: Random-access memory</li> <li>NVM: Non-Volatile Memory</li> </ul>                                                                        | RAM     |
| Filter Message | Event will be filtered according to the Filter Message that the user set. Click the "Refresh" button, the filtered event will be displayed in the follow box. Use "&" to separate more than one filter message, such as message1&message2. | Null    |

### 3.22 Services > NTP

This section allows you to set the related NTP (Network Time Protocol) parameters, including Time zone, NTP Client and NTP Server.

NTP

Status

^ Timezone Settings

Time Zone

Expert Setting

^ NTP Client Settings

Enable  ON  OFF

Primary NTP Server

Secondary NTP Server

NTP Update Interval

^ NTP Server Settings

Enable  ON  OFF

| NTP                        |                                                                                                                                                 |              |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|--------------|
| Item                       | Description                                                                                                                                     | Default      |
| <b>Timezone Settings</b>   |                                                                                                                                                 |              |
| Time Zone                  | Click the drop down list to select the time zone you are in.                                                                                    | UTC +08:00   |
| Expert Setting             | Specify the time zone with Daylight Saving Time in TZ environment variable format. The Time Zone option will be ignored in this case.           | Null         |
| <b>NTP Client Settings</b> |                                                                                                                                                 |              |
| Enable                     | Click the toggle button to enable/disable this option. Enable to synchronize time with the NTP server.                                          | ON           |
| Primary NTP Server         | Enter primary NTP Server's IP address or domain name.                                                                                           | pool.ntp.org |
| Secondary NTP Server       | Enter secondary NTP Server's IP address or domain name.                                                                                         | Null         |
| NTP Update interval        | Enter the interval (minutes) which NTP client synchronize the time from NTP server. Minutes wait for next update, and 0 means update only once. | 0            |

| NTP Server Settings |                                                          |     |
|---------------------|----------------------------------------------------------|-----|
| Enable              | Click the toggle button to enable the NTP server option. | OFF |

This window allows you to view the current time of router and also synchronize the router time. Click **Sync** button to synchronize the router time with PC's.

The screenshot shows the 'NTP Status' page. It features a 'Time' section with the following information:

- System Time:** 2017-02-27 14:29:05
- PC Time:** 2017-02-27 14:32:20
- Last Update Time:** 2017-02-27 09:13:30

A **Sync** button is located next to the PC Time.

### 3.23 Services > SMS

This section allows you to set SMS parameters. Router supports SMS management, and user can control and configure their routers by sending SMS. For more details about SMS control, refer to **4.2.2 SMS Remote Control**.

The screenshot shows the 'SMS Management Settings' page. It includes:

- An **Enable** toggle switch currently set to **ON**.
- An **Authentication Type** dropdown menu set to **Password**.
- A **Phone Number** input field.

| SMS Management Settings |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
| Item                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Default  |
| Enable                  | Click the toggle button to enable/disable the SMS Management option.<br><b>Note:</b> If this option is disabled, the SMS configuration is invalid.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | ON       |
| Authentication Type     | Select Authentication Type from "Password", "Phonenum" or "Both". <ul style="list-style-type: none"> <li>• Password: Use the same username and password as WEB manager for authentication. For example, the format of the SMS should be "username: password; cmd1; cmd2; ..."</li> <li>• Phonenum: Use the Phone number for authenticating, and user should set the Phone Number that is allowed for SMS management. The format of the SMS should be "cmd1; cmd2; ..."</li> <li>• Both: Use both the "Password" and "Phonenum" for authentication. User should set the Phone Number that is allowed for SMS management. The format of the SMS should be "username: password; cmd1; cmd2; ..."</li> </ul> | Password |
| Phone Number            | Set the phone number used for SMS management, and use ' ; ' to separate each number.<br><b>Note:</b> It can be null when choose "Password" as the authentication type.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Null     |

User can test the current SMS service whether it is available in this section.

SMS
SMS Testing

**^ SMS Testing**

**Phone Number**

**Message**

**Result**

| SMS Testing                                                                                                          |                                                                           |         |
|----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|---------|
| Item                                                                                                                 | Description                                                               | Default |
| Phone Number                                                                                                         | Enter the specified phone number which can receive the SMS from router.   | Null    |
| Message                                                                                                              | Enter the message that router will send it to the specified phone number. | Null    |
| Result                                                                                                               | The result of the SMS test will be displayed in the result box.           | Null    |
| <input style="background-color: #004a7c; color: white; padding: 2px 5px; border: none;" type="button" value="Send"/> | Click the button to send the test message.                                | --      |

### 3.24 Services > Email

Email function supports to send the event notifications to the specified recipient by ways of email.

Email

**^ Email Settings**

Enable  ON  OFF

Enable TLS/SSL  ON  OFF ?

Outgoing Server

Server Port

Timeout  ?

Username

Password

From

Subject

| Email Settings |                                                               |         |
|----------------|---------------------------------------------------------------|---------|
| Item           | Description                                                   | Default |
| Enable         | Click the toggle button to enable/disable the Email option.   | OFF     |
| Enable TLS/SSL | Click the toggle button to enable/disable the TLS/SSL option. | OFF     |

| Email Settings  |                                                                                                                                     |         |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                         | Default |
| Outgoing server | Enter the SMTP server IP Address or domain name.                                                                                    | Null    |
| Server port     | Enter the SMTP server port.                                                                                                         | 25      |
| Timeout         | Set the max time for sending email to SMTP server. When the server doesn't receive the email over this time, it will try to resend. | 10      |
| Username        | Enter the username which has been registered from SMTP server.                                                                      | Null    |
| Password        | Enter the password of the username above.                                                                                           | Null    |
| From            | Enter the source address of the email.                                                                                              | Null    |
| Subject         | Enter the subject of this email.                                                                                                    | Null    |

### 3.25 Services > DDNS

This section allows you to set the DDNS parameters. The Dynamic DNS function allows you to alias a dynamic IP address to a static domain name, allows you whose ISP does not assign them a static IP address to use a domain name. This is especially useful for hosting servers via your connection, so that anyone wishing to connect to you may use your domain name, rather than having to use your dynamic IP address, which changes from time to time. This dynamic IP address is the WAN IP address of the router, which is assigned to you by your ISP. The service provider defaults to "DynDNS", as shown below.

The screenshot shows the 'DDNS Settings' window. At the top, there are tabs for 'DDNS' and 'Status'. Below the title bar, there is an 'Enable' toggle switch currently set to 'OFF'. A red box highlights the 'Service Provider' dropdown menu, which is set to 'DynDNS'. Below this, there are input fields for 'Hostname', 'Username', and 'Password'.

When "Custom" service provider chosen, the window is displayed as below.

The screenshot shows the 'DDNS Settings' window with the 'Service Provider' dropdown menu set to 'Custom'. A red box highlights this dropdown. Below it, there is an input field labeled 'URL'.

| DDNS Settings    |                                                                                                                                                                 |         |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item             | Description                                                                                                                                                     | Default |
| Enable           | Click the toggle button to enable/disable the DDNS option.                                                                                                      | OFF     |
| Service Provider | Select the DDNS service from "DynDNS", "NO-IP" or "3322".<br><b>Note:</b> the DDNS service only can be used after registered by Corresponding service provider. | DynDNS  |

|          |                                                 |      |
|----------|-------------------------------------------------|------|
| Hostname | Enter the hostname provided by the DDNS server. | Null |
| Username | Enter the username provided by the DDNS server. | Null |
| Password | Enter the password provided by the DDNS server. | Null |
| URL      | Enter the URL customized by user.               | Null |

Click "Status" bar to view the status of the DDNS.

The screenshot shows a navigation bar with 'DDNS' and 'Status' tabs. Below it is a section titled '^ DDNS Status' containing the text 'Status Disabled' and 'Last Update Time'.

| DDNS Status      |                                                                       |
|------------------|-----------------------------------------------------------------------|
| Item             | Description                                                           |
| Status           | Display the current status of the DDNS.                               |
| Last Update Time | Display the date and time for the DDNS was last updated successfully. |

### 3.26 Services > SSH

Router supports SSH password access and secret-key access.

The screenshot shows a navigation bar with 'SSH' and 'Keys Management' tabs. Below it is a section titled '^ SSH Settings' containing 'Enable' (ON/OFF toggle), 'Port' (input field with '22'), and 'Disable Password Logins' (ON/OFF toggle).

| SSH Settings            |                                                                                                                                                                                           |         |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                    | Description                                                                                                                                                                               | Default |
| Enable                  | Click the toggle button to enable/disable this option. When enabled, you can access the router via SSH.                                                                                   | OFF     |
| Port                    | Set the port of the SSH access.                                                                                                                                                           | 22      |
| Disable Password Logins | Click the toggle button to enable/disable this option. When enabled, you cannot use username and password to access the router via SSH. In this case, only the key can be used for login. | OFF     |

The screenshot shows a navigation bar with 'SSH' and 'Keys Management' tabs. Below it is a section titled '^ Import Authorized Keys' containing 'Authorized Keys', a 'Choose File' button (showing 'No file chosen'), and an 'Import' button.

| Keys Management |                                                                                                                                                                                                                    |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item            | Description                                                                                                                                                                                                        |
| Authorized Keys | Click on "Choose File" to locate an authorized key from your computer, and then click "Import" to import this key into your router.<br><b>Note:</b> This option is valid when enabling the password logins option. |

### 3.27 Services > GPS

This section allows you to set the GPS setting parameters.

| General Settings @ GPS |                                                           |         |
|------------------------|-----------------------------------------------------------|---------|
| Item                   | Description                                               | Default |
| Enable GPS             | Click the toggle button to enable/disable the GPS option. | OFF     |
| Sync GPS Time          | Click the toggle button to synchronize GPS time.          | OFF     |
| RS232 Report Settings  |                                                           |         |
| Report to RS232        | Click the toggle button to report to RS232.               | OFF     |
| Report GGA Sentence    | Click the toggle button to report GGA sentence.           | OFF     |
| Report VTG Sentence    | Click the toggle button to report VTG sentence.           | OFF     |
| Report RMC Sentence    | Click the toggle button to report RMC sentence.           | OFF     |
| Report GSV Sentence    | Click the toggle button to report GSV sentence.           | OFF     |

The window is displayed as below when choosing "TCP Client" as the protocol.

**GPS**

**^ Server Settings**

|                   |                                                                     |
|-------------------|---------------------------------------------------------------------|
| Index             | <input type="text" value="1"/>                                      |
| Enable            | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Protocol          | <input type="text" value="TCP Client"/> v                           |
| Server Address    | <input type="text"/>                                                |
| Server Port       | <input type="text"/>                                                |
| Send GGA Sentence | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Send VTG Sentence | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Send RMC Sentence | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Send GSV Sentence | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |

The window is displayed as below when choosing “TCP Server” as the protocol.

**GPS**

^ **Server Settings**

Index

Enable  ON  OFF

Protocol TCP Server v

Local Address

Local Port

Send GGA Sentence  ON  OFF

Send VTG Sentence  ON  OFF

Send RMC Sentence  ON  OFF

Send GSV Sentence  ON  OFF

The window is displayed as below when choosing “UDP” as the protocol.

**GPS**

^ **Server Settings**

Index

Enable  ON  OFF

Protocol UDP v

Server Address

Server Port

Send GGA Sentence  ON  OFF

Send VTG Sentence  ON  OFF


Send RMC Sentence  ON  OFF

Send GSV Sentence  ON  OFF

| Server Settings            |                                                                    |            |
|----------------------------|--------------------------------------------------------------------|------------|
| Item                       | Description                                                        | Default    |
| Index                      | Indicate the ordinal of the list.                                  | --         |
| Enable                     | Click the toggle button to enable/disable the GPS server settings. | ON         |
| Protocol                   | Select from “TCP Client”, “TCP Server” or “UDP”.                   | TCP Client |
| Server Address @TCP Client | Set the address of the TCP Client.                                 | Null       |
| Server Port @TCP Client    | Set the port of the remote TCP Server.                             | Null       |
| Local Address              | Set the local address when the router set as a TCP Server.         | Null       |
| Local Port                 | Set the local port when the router set as a TCP Server.            | Null       |

| Server Settings      |                                        |         |
|----------------------|----------------------------------------|---------|
| Item                 | Description                            | Default |
| Server Address @ UDP | Set the address of the TCP Server.     | Null    |
| Server Port @ UDP    | Set the port of the remote TCP Server. | Null    |
| Send GGA Sentence    | Send GGA information in NMEA format.   | OFF     |
| Send VTG Sentence    | Send VTG information in NMEA format.   | OFF     |
| Send RMC Sentence    | Send RMC information in NMEA format.   | OFF     |
| Send GSV Sentence    | Send GSV information in NMEA format.   | OFF     |

Click the “Status” column to view the status of the GPS.




The screenshot shows a navigation bar with 'GPS', 'Status', and 'Map' tabs. Below it, a 'GPS Status' menu is expanded, listing the following items:

- Status
- UTC Time
- Last Fixed Time
- Satellites In Use
- Satellites In View
- Latitude
- Longitude
- Altitude
- Speed

| GPS Status        |                                                                            |
|-------------------|----------------------------------------------------------------------------|
| Item              | Description                                                                |
| Status            | Show the GPS Status. GPS status includes: “NO Fix”, “2D Fix” and “3D Fix”. |
| UTC Time          | Show the UTC of satellites, which is world unified time, not local time.   |
| Last Fixed Time   | Show the last positioning time.                                            |
| Satellites In Use | Show the satellite quantity in use.                                        |
| Satellite In View | Show the satellite quantity in view.                                       |
| Latitude          | Show the latitude status of router.                                        |
| Longitude         | Show the longitude status of router.                                       |
| Altitude          | Show the altitude status of router.                                        |
| Speed             | Show the horizontal speed of router.                                       |

Click the “Map” column to view the current location of the router.



### 3.28 Services > Web Server

This section allows you to modify the parameters of Web Server.

| Web Server              |                                  | Certificate Management |
|-------------------------|----------------------------------|------------------------|
| <b>General Settings</b> |                                  |                        |
| HTTP Port               | <input type="text" value="80"/>  | <a href="#">?</a>      |
| HTTPS Port              | <input type="text" value="443"/> | <a href="#">?</a>      |

| Basic @ Web Server |                                                                                                                                                               |         |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item               | Description                                                                                                                                                   | Default |
| HTTP Port          | Enter the HTTP port number you want to change in router’s Web Server. On a Web server, port 80 is the port that the server "listens to" or expects to receive | 80      |

|            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |     |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
|            | from a Web client. If you configure the router with other HTTP Port number except 80, only adding that port number then you can login router’s Web Server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |     |
| HTTPS Port | <p>Enter the HTTPS port number you want to change in router’s Web Server. On a Web server, port 443 is the port that the server "listens to" or expects to receive from a Web client. If you configure the router with other HTTPS Port number except 443, only adding that port number then you can login router’s Web Server.</p> <p><b>Note:</b> HTTPS is more secure than HTTP. In many cases, clients may be exchanging confidential information with a server, which needs to be secured in order to prevent unauthorized access. For this reason, HTTP was developed by Netscape corporation to allow authorization and secured transactions.</p> | 443 |

This section allows you to import the certificate file into the route.

| Certificate Management |                                                                                                                                                                              |         |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                   | Description                                                                                                                                                                  | Default |
| Import Type            | Select from “CA” and “Private Key”. <ul style="list-style-type: none"> <li>CA: a digital certificate issued by CA center</li> <li>Private Key: a private key file</li> </ul> | CA      |
| HTTPS Certificate      | Click on “Choose File” to locate the certificate file from your computer, and then click “Import” to import this file into your router.                                      | --      |

### 3.29 Services > Advanced

This section allows you to set the Advanced and parameters.

**^ System Settings**

Device Name  ?

User LED Type  ?

- None
- OpenVPN
- IPSec
- WiFi

| System Settings |                                                                                                                                                                                                                                                                                                                                                                                                                                                            |         |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                | Default |
| Device Name     | Set the device name to distinguish different devices you have installed; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *.                                                                                                                                                                                                                                                                                                                        | router  |
| User LED Type   | Specify the display type of your USR LED. Select from “None”, “OpenVPN”, “IPsec” or “WiFi”. <ul style="list-style-type: none"> <li>• None: Meaningless indication, and the LED is off</li> <li>• OpenVPN: USR indicator showing the OpenVPN status</li> <li>• IPsec: USR indicator showing the IPsec status</li> <li>• WiFi: USR indicator showing the WiFi status</li> </ul> <b>Note:</b> For more details about USR indicator, see “2.2 LED Indicators”. | None    |

**System** | **Reboot**

**^ Periodic Reboot Settings**

Periodic Reboot  ?

Daily Reboot Time  ?

| Reboot            |                                                                                                                                                                      |         |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item              | Description                                                                                                                                                          | Default |
| Periodic Reboot   | Set the reboot period of the router. 0 means disable.                                                                                                                | 0       |
| Daily Reboot Time | Set the daily reboot time of the router, you should follow the format as HH:MM, in 24h time frame, otherwise the data will be invalid. Leave it empty means disable. | Null    |

### 3.30 System > Debug

This section allows you to check and download the syslog details.

Syslog

^ Syslog Details

Log Level Debug v

Filtering  ?

```

Feb 27 14:29:07 router user.debug link_manager[842]: target link WWAN1, state Connected
Feb 27 14:29:07 router user.info link_manager[842]: WWAN1 ping test success
Feb 27 14:29:23 router user.debug modemd[876]: +CUSATP:
"D064810301250082028182850F80005500530049004D53615E9475288F0A01807CBE54C163A883508F0A02806C83901A884C8BC18F0A03804FEB6C11670D52A18F0C0480624B673A84254E1A53858F0A05806D4191CF4E13533A8F0A0680727960E0793C5305"
Feb 27 14:31:23 router user.debug modemd[876]: +CUSATP:
"D064810301250082028182850F80005500530049004D53615E9475288F0A01807CBE54C163A883508F0A02806C83901A884C8BC18F0A03804FEB6C11670D52A18F0C0480624B673A84254E1A53858F0A05806D4191CF4E13533A8F0A0680727960E0793C5305"
Feb 27 14:33:23 router user.debug modemd[876]: +CUSATP:
"D064810301250082028182850F80005500530049004D53615E9475288F0A01807CBE54C163A883508F0A02806C83901A884C8BC18F0A03804FEB6C11670D52A18F0C0480624B673A84254E1A53858F0A05806D4191CF4E13533A8F0A0680727960E0793C5305"
Feb 27 14:34:07 router user.debug link_manager[842]: WWAN1 (wwan) start ping test
Feb 27 14:34:07 router user.debug rping[16182]: start ping 8.8.8.8 (wwan)
Feb 27 14:34:07 router user.debug rping[16182]: PING 8.8.8.8 (8.8.8.8) from 10.122.74.11: 16 data bytes
Feb 27 14:34:07 router user.debug rping[16182]: 24 bytes from 8.8.8.8: seq=0 ttl=52 time=324.080 ms
Feb 27 14:34:07 router user.debug rping[16182]:
Feb 27 14:34:07 router user.debug rping[16182]: --- 8.8.8.8 ping statistics ---
Feb 27 14:34:07 router user.debug rping[16182]: 1 packets transmitted, 1 packets received, 0% packet loss
Feb 27 14:34:07 router user.debug rping[16182]: round-trip min/avg/max = 324.080/324.080/324.080 ms
Feb 27 14:34:07 router user.debug link_manager[842]: recv action ping_success from rping
Feb 27 14:34:07 router user.debug link_manager[842]: target link WWAN1, state Connected
Feb 27 14:34:07 router user.info link_manager[842]: WWAN1 ping test success
Feb 27 14:35:23 router user.debug modemd[876]: +CUSATP:
"D064810301250082028182850F80005500530049004D53615E9475288F0A01807CBE54C163A883508F0A02806C83901A884C8BC18F0A03804FEB6C11670D52A18F0C0480624B673A84254E1A53858F0A05806D4191CF4E13533A8F0A0680727960E0793C5305"
                    
```

Manual Refresh v
Clear
Refresh

^ Syslog Files

| Index | File Name | File Size | Modification Time       |
|-------|-----------|-----------|-------------------------|
| 1     | messages  | 198937    | Mon Jan 1 01:46:24 2007 |

^ System Diagnostic Data

System Diagnostic Data
Generate

| Syslog                                                                                  |                                                                                                                                                                                                                                                                             |                |
|-----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| Item                                                                                    | Description                                                                                                                                                                                                                                                                 | Default        |
| <b>Syslog Details</b>                                                                   |                                                                                                                                                                                                                                                                             |                |
| Log Level                                                                               | Select from "Debug", "Info", "Notice", "Warn", "Error" which from low to high. The lower level will output more syslog in detail.                                                                                                                                           | Debug          |
| Filtering                                                                               | Enter the filtering message based on the keywords. Use "&" to separate more than one filter message, such as "keyword1&keyword2".                                                                                                                                           | Null           |
| Refresh                                                                                 | Select from "Manual Refresh", "5 Seconds", "10 Seconds", "20 Seconds" or "30 Seconds". You can select these intervals to refresh the log information displayed in the follow box. If selecting "manual refresh", you should click the refresh button to refresh the syslog. | Manual Refresh |
| <span style="background-color: #2c5e8c; color: white; padding: 2px 5px;">Clear</span>   | Click the button to clear the syslog.                                                                                                                                                                                                                                       | --             |
| <span style="background-color: #2c5e8c; color: white; padding: 2px 5px;">Refresh</span> | Click the button to refresh the syslog.                                                                                                                                                                                                                                     | --             |

| Syslog Files           |                                                                                                                                                                     |   |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|
| Syslog Files List      | It can show at most 5 syslog files in the list, the files' name range from message0 to message 4. And the newest syslog file will be placed on the top of the list. | / |
| System Diagnosing Data |                                                                                                                                                                     |   |
| Generate               | Click to generate the syslog diagnosing file.                                                                                                                       | / |

### 3.31 System > Update

This section allows you to upgrade the firmware of your router. Click **System > Update > System Update**, and click on "Choose File" to locate the firmware file to be used for the upgrade. Once the latest firmware has been chosen, click "Update" to start the upgrade process. The upgrade process may take several minutes. Do not turn off your Router during the firmware upgrade process.

**Note:** To access the latest firmware file, please contact your technical support engineer.



| Update        |                                                                                                                                                                                                                                                                                       |         |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item          | Description                                                                                                                                                                                                                                                                           | Default |
| System Update | Click <input type="button" value="Choose File"/> button to select the correct firmware in your PC, and then click <input type="button" value="Update"/> button to update. After updating successfully, you need to click "save and apply", and then reboot the router to take effect. | Null    |

### 3.32 System > App Center

This section allows you to add some required or customized applications to the router. Import and install your applications to the App Center, and reboot the device according to the system prompts. Each installed application will be displayed under the “Services” menu, while other applications related to VPN will be displayed under the “VPN” menu.


**Note:** After importing the applications to the router, the page display may have a slight delay due to the browser cache. It is recommended that you clear the browser cache first and log in the router again.



| App Center            |                                                                                                                                                                                                                                       |         |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                  | Description                                                                                                                                                                                                                           | Default |
| <b>App Install</b>    |                                                                                                                                                                                                                                       |         |
| File                  | Click on “Choose File” to locate the App file from your computer, and then click <b>Install</b> to import this file into your router.<br><b>Note:</b> File format should be <i>xxx.rpk</i> , e.g. <i>R3000-robustlink-1.0.0.rpk</i> . | --      |
| <b>Installed Apps</b> |                                                                                                                                                                                                                                       |         |
| Index                 | Indicate the ordinal of the list.                                                                                                                                                                                                     | --      |
| Name                  | Show the name of the App.                                                                                                                                                                                                             | Null    |
| Version               | Show the version of the App.                                                                                                                                                                                                          | Null    |
| Status                | Show the status of the App.                                                                                                                                                                                                           | Null    |
| Description           | Show the description for this App.                                                                                                                                                                                                    | Null    |

### 3.33 System > Tools

This section provides users three tools: Ping, Traceroute and Sniffer.



| Ping                                                                                |                                                                                                                                                  |         |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                                                                                | Description                                                                                                                                      | Default |
| IP address                                                                          | Enter the ping's destination IP address or destination domain.                                                                                   | Null    |
| Number of Requests                                                                  | Specify the number of ping requests.                                                                                                             | 5       |
| Timeout                                                                             | Specify the timeout of ping request.                                                                                                             | 1       |
| Local IP                                                                            | Specify the local IP from cellular WAN, Ethernet WAN or Ethernet LAN. Null stands for selecting local IP address from these three automatically. | Null    |
|  | Click this button to start ping request, and the log will be displayed in the follow box.                                                        | Null    |
|  | Click this button to stop ping request.                                                                                                          | --      |

Ping | Traceroute | Sniffer

**Traceroute**

Trace Address   
 Trace Hops   
 Trace Timeout

| Traceroute                           |                                                                                                                                             |         |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                                 | Description                                                                                                                                 | Default |
| Trace Address                        | Enter the trace's destination IP address or destination domain.                                                                             | Null    |
| Trace Hops                           | Specify the max trace hops. Router will stop tracing if the trace hops has met max value no matter the destination has been reached or not. | 30      |
| Trace Timeout                        | Specify the timeout of Traceroute request.                                                                                                  | 1       |
| <input type="button" value="Start"/> | Click this button to start Traceroute request, and the log will be displayed in the follow box.                                             | --      |
| <input type="button" value="Stop"/>  | Click this button to stop Traceroute request.                                                                                               | --      |

Ping | Traceroute | Sniffer

**Sniffer**

Interface  v  
 Host   
 Packets Request   
 Protocol  v  
 Status

**Capture Files**

| Index | File Name             | File Size | Modification Time        |
|-------|-----------------------|-----------|--------------------------|
| 1     | 17-02-27_14-39-40.cap | 24        | Mon Feb 27 14:39:41 2017 |

| Sniffer         |                                                                                                                                                                                                                                   |         |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Item            | Description                                                                                                                                                                                                                       | Default |
| Interface       | Choose the interface according to your Ethernet configuration.                                                                                                                                                                    | All     |
| Host            | Filter the packet that contain the specify IP address.                                                                                                                                                                            | Null    |
| Packets Request | Set the packet number that the router can sniffer at a time.                                                                                                                                                                      | 1000    |
| Protocol        | Select from "All", "IP", "TCP", "UDP" and "ARP".                                                                                                                                                                                  | All     |
| Port            | Set the port number for TCP or UDP that is used in sniffer.                                                                                                                                                                       | Null    |
| Status          | Show the current status of sniffer.                                                                                                                                                                                               | Null    |
|                 | Click this button to start the sniffer.                                                                                                                                                                                           | --      |
|                 | Click this button to stop the sniffer. Once you click this button, a new log file will be displayed in the following List.                                                                                                        | --      |
| Capture Files   | Every times of sniffer log will be saved automatically as a new file. You can find the file from this Sniffer Traffic Data List and click  to download the log, click  to delete the log file. It can cache a maximum of 5 files. | Null    |

### 3.34 System > Profile

This section allows you to import or export the configuration file, and restore the router to factory default setting.

Profile

Rollback

**Import Configuration File**

Reset Other Settings to Default  OFF

Ignore Invalid Settings  OFF

XML Configuration File

**Export Configuration File**

Ignore Disabled Features  OFF

Add Detailed Information  OFF

Encrypt Secret Data  OFF

XML Configuration File

**Default Configuration**

Save Running Configuration as Default

Restore to Default Configuration

| Profile                          |                                                                                 |         |
|----------------------------------|---------------------------------------------------------------------------------|---------|
| Item                             | Description                                                                     | Default |
| <b>Import Configuration File</b> |                                                                                 |         |
| Reset Other Settings to Default  | Click the toggle button as "ON" to return other parameters to default settings. | OFF     |
| Ignore Invalid Settings          | Click the toggle button as "OFF" to ignore invalid settings.                    | OFF     |

|                                       |                                                                                                                                                         |     |
|---------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| XML Configuration File                | Click on <b>Choose File</b> to locate the XML configuration file from your computer, and then click <b>Import</b> to import this file into your router. | --  |
| <b>Export Configuration File</b>      |                                                                                                                                                         |     |
| Ignore Disabled Features              | Click the toggle button as "OFF" to ignore the disabled features.                                                                                       | OFF |
| Add Detailed Information              | Click the toggle button as "On" to add detailed information.                                                                                            | OFF |
| Encrypt Secret Data                   | Click the toggle button as "ON" to encrypt the secret data.                                                                                             | OFF |
| XML Configuration File                | Click <b>Generate</b> button to generate the XML configuration file.                                                                                    | --  |
| <b>Default Configuration</b>          |                                                                                                                                                         |     |
| Save Running Configuration as Default | Click this button to save the current running parameters as default configuration.                                                                      | --  |
| Restore to Default Configuration      | Click this button to restore the factory defaults.                                                                                                      | --  |

Profile

Rollback

^ Configuration Rollback

Save as a Rollbackable Archive
Save
?

^ Configuration Archive Files

| Index | File Name | File Size | Modification Time |
|-------|-----------|-----------|-------------------|
|-------|-----------|-----------|-------------------|

| Rollback                           |                                                                                                                                   |         |
|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|---------|
| Item                               | Description                                                                                                                       | Default |
| <b>Configuration Rollback</b>      |                                                                                                                                   |         |
| Save as a Rollbackable Archive     | Create a save point manually. Additionally, the system will create a save point every day automatically if configuration changes. | --      |
| <b>Configuration Archive Files</b> |                                                                                                                                   |         |
| Configuration Archive Files        | View the related information about configuration archive files, including name, size and modification time.                       | --      |

### 3.35 System > User Management

| Root Settings    |                                                                                                 |      |
|------------------|-------------------------------------------------------------------------------------------------|------|
| New Password     | Enter a new password you want to create; valid characters are a-z, A-Z, 0-9, @, #, \$, ., *, -. | Null |
| Confirm Password | Enter the new password again to confirm.                                                        | Null |

This section allows you to change your username and password, and create or manage user accounts. One router has only one super user who has the highest authority to modify, add and manage other common users.

**Note:** Your new password must be more than 5 character and less than 32 characters and may contain numbers, upper and lowercase letters, and standard symbols.

| Super User Settings |                                                                                                     |         |
|---------------------|-----------------------------------------------------------------------------------------------------|---------|
| Item                | Description                                                                                         | Default |
| New Username        | Enter a new username you want to create; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null    |
| Old Password        | Enter the old password of your router. The default is "admin".                                      | Null    |
| New Password        | Enter a new password you want to create; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null    |
| Confirm Password    | Enter the new password again to confirm.                                                            | Null    |

Click button to add a new common user. The maximum rule count is 5.

**Common User**

^ **Common Users Settings**

|                 |                                                                               |
|-----------------|-------------------------------------------------------------------------------|
| <b>Index</b>    | <input style="width: 90%;" type="text" value="1"/>                            |
| <b>Role</b>     | <input style="border-bottom: 1px solid #ccc;" type="text" value="Visitor"/> v |
| <b>Username</b> | <input style="width: 90%;" type="text"/> ?                                    |
| <b>Password</b> | <input style="width: 90%;" type="text"/> ?                                    |


| <b>Common User Settings</b> |                                                                                                                                                                                                                                                      |                |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| <b>Item</b>                 | <b>Description</b>                                                                                                                                                                                                                                   | <b>Default</b> |
| Index                       | Indicate the ordinal of the list.                                                                                                                                                                                                                    | --             |
| Role                        | Select from "Visitor" and "Editor". <ul style="list-style-type: none"> <li>Visitor: Users only can view the configuration of router under this level</li> <li>Editor: Users can view and set the configuration of router under this level</li> </ul> | Visitor        |
| Username                    | Set the Username; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *.                                                                                                                                                                         | Null           |
| Password                    | Set the password which at least contains 5 characters; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *.                                                                                                                                    | Null           |

## Chapter 4 Configuration Examples

### 4.1 Interface

#### 4.1.1 Console Port


You can use the console port to manage the router via CLI commands, please refer to **Chapter 5 Introductions for CLI**.



### 4.1.2 Digital Input

R3000 supports digital input with dry contact. Please check the connector interface of the router, you can easily find a mark "V-" at one pin of the power connector.


**Note:** Do not connect In1/In2 directly and do not slide the switch to the port marked "GND" on the terminal block. Otherwise, the DI cannot work properly.



### 4.1.3 Digital Output


R3000 supports digital output with wet contact. Please refer to the right side figure to connect the negative pole of the power to the port marked "GND".

The maximum output voltage, output current and output power of DO is 30V DC, 0.3 A and 0.3 W respectively. It means that the voltage difference between Out1, Out2 and GND cannot exceed to 30V DC; and the current value through Out1 and Out2 cannot exceed to 300 mA; while the output power dissipated by Out1 and Out2 cannot exceed to 0.3W. Otherwise, the DO will be damaged.




### 4.1.4 RS-232

R3000 supports one RS-232 for serial data communication. Please refer to the connection diagram at the right side.



### 4.1.5 RS-485

R3000 supports one RS-485 for serial data communication. Please refer to the connection diagram at the right side.



## 4.2 Cellular

### 4.2.1 Cellular Dial-Up

This section shows you how to configure the primary and backup SIM card for Cellular Dial-up. Connect the router correctly and insert two SIM, then open the configuration page. Under the homepage menu, click **Interface > Link Manager > Link Manager > General Settings**, choose “WWAN1” as the primary link and “WWAN2” as the backup link, and set “Cold Backup” as the backup mode, then click “Submit”.

**Note:** All data will be transferred via WWAN1 when choose WWAN1 as the primary link and set backup mode as cold backup. At the same time, WWAN2 is always offline as a backup link. All data transmission will be switched to WWAN2 when the WWAN1 is disconnected.

| Index | Type  | Description | Connection Type |
|-------|-------|-------------|-----------------|
| 1     | WWAN1 |             | DHCP            |
| 2     | WWAN2 |             | DHCP            |
| 3     | WAN   |             | DHCP            |
| 4     | WLAN  |             | DHCP            |

Click the edit button of WWAN1 to set its parameters according to the current ISP.

|             |       |
|-------------|-------|
| Index       | 1     |
| Type        | WWAN1 |
| Description |       |

**^ WWAN Settings**

Automatic APN Selection  ON  OFF

Dialup Number

Authentication Type  v

Aggressive Reset  ON  OFF ?

Switch SIM By Data Allowance  ON  OFF ?

Data Allowance  ?

Billing Day  ?

**^ Ping Detection Settings** ?

Enable  ON  OFF

Primary Server

Secondary Server

Interval  ?

Retry Interval  ?

Timeout  ?

Max Ping Tries  ?

**^ Advanced Settings**

NAT Enable  ON  OFF

Upload Bandwidth  ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Debug Enable  ON  OFF

Verbose Debug Enable  ON  OFF

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The window is displayed below by clicking **Interface > Cellular > Advanced Cellular Settings**.

| Index | SIM Card | Phone Number | Network Type | Band Select Type |  |
|-------|----------|--------------|--------------|------------------|--|
| 1     | SIM1     |              | Auto         | All              |  |
| 2     | SIM2     |              | Auto         | All              |  |

Click the edit button of SIM1 to set its parameters according to your application request.

**Cellular**

^ **General Settings**

|              |                                                                     |
|--------------|---------------------------------------------------------------------|
| Index        | <input type="text" value="1"/>                                      |
| SIM Card     | <input style="border: 1px solid #ccc;" type="text" value="SIM1"/> v |
| Phone Number | <input type="text"/>                                                |
| PIN Code     | <input type="text"/> ?                                              |
| Extra AT Cmd | <input type="text"/> ?                                              |
| Telnet Port  | <input type="text" value="0"/> ?                                    |

^ **Cellular Network Settings**

|                  |                                                                       |
|------------------|-----------------------------------------------------------------------|
| Network Type     | <input style="border: 1px solid #ccc;" type="text" value="Auto"/> v ? |
| Band Select Type | <input style="border: 1px solid #ccc;" type="text" value="All"/> v ?  |

^ **Advanced Settings**

|                      |                                                                     |
|----------------------|---------------------------------------------------------------------|
| Debug Enable         | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Verbose Debug Enable | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |

When finished, click **Submit > Save & Apply** for the configuration to take effect.

## 4.2.2 SMS Remote Control

The router supports remote control via SMS. You can use following commands to get the status of the router, and set all the parameters. There are three authentication types for SMS control. You can select from “Password”, “Phonenum” or “Both”.

### An SMS command has the following structure:

1. Password mode—Username: Password;cmd1;cmd2;cmd3; ...cmdn (available for every phone number).
2. Phonenum mode--cmd1; cmd2; cmd3; ... cmdn (available when the SMS was sent from the phone number which had been added in R3000's phone group).
3. Both mode-- Username: Password;cmd1;cmd2;cmd3; ...cmdn (available when the SMS was sent from the phone number which had been added in R3000's phone group).

### SMS command Explanation:

1. User name and Password: use the same username and password as WEB manager for authentication.
2. cmd1, cmd2, cmd3 to Cmdn, the command format is the same as the CLI command, more details about CLI cmd please refer to **Chapter 5 Introductions for CLI**.

**Note:** Download the configure XML file from the configured web browser. The format of SMS control command can refer to the data of the XML file.

Go to **System > Profile > Export Configuration File**, click **Generate** to generate the XML file and click **Export** to export the XML file.

| Profile                               | Rollback                                                              |
|---------------------------------------|-----------------------------------------------------------------------|
| <b>^ Import Configuration File</b>    |                                                                       |
| Reset Other Settings to Default       | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| Ignore Invalid Settings               | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| XML Configuration File                | <input type="text" value="Choose File"/> No file chosen <b>Import</b> |
| <b>^ Export Configuration File</b>    |                                                                       |
| Ignore Disabled Features              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| Add Detailed Information              | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| Encrypt Secret Data                   | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| XML Configuration File                | <b>Generate</b>                                                       |
| <b>^ Default Configuration</b>        |                                                                       |
| Save Running Configuration as Default | <b>Save</b> ?                                                         |
| Restore to Default Configuration      | <b>Restore</b>                                                        |

**XML command:**

```
<lan >
<network max_entry_num="2" >
<id > 1</id >
<interface > lan0</interface >
<ip > 172.16.24.24</ip >
<netmask > 255.255.0.0</netmask >
<mtu > 1500</mtu >
```

**SMS cmd:**

```
set lan network 1 interface lan0
set lan network 1 ip 172.16.24.24
set lan network 1 netmask 255.255.0.0
set lan network 1 mtu 1500
```

- The semicolon character (;) is used to separate more than one command packed in a single SMS.
- E.g.

**admin:admin;status system**

In this command, username is "admin", password is "admin", and the function of the command is to get the system status.

**SMS received:**

```
hardware_version = 1.2
firmware_version = "3.0.0"
kernel_version = 4.1.0
device_model = R3000
serial_number = 201612221052
uptime = "0 days, 00:40:21"
system_time = "Mon Feb 27 09:52:52 2017"
```

**admin:admin;reboot**

In this command, username is “admin”, password is “admin”, and the command is to reboot the Router.

**SMS received:**

OK

**admin:admin;set firewall remote\_ssh\_access false;set firewall remote\_telnet\_access false**

In this command, username is “admin”, password is “admin”, and the command is to disable the remote\_ssh and remote\_telnet access.

**SMS received:**

OK

OK

**admin:admin; set lan network 1 interface lan0;set lan network 1 ip 172.16.24.24;set lan network 1 netmask 255.255.0.0;set lan network 1 mtu 1500**

In this command, username is “admin”, password is “admin”, and the commands is to configure the LAN parameter.

**SMS received:**

OK

OK

OK

OK

## 4.3 Network

### 4.3.1 IPsec VPN



The configuration of server and client is as follows.

## IPsec VPN\_Server:

### Cisco 2811:

```

Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
  authentication  Set authentication method for protection suite
  encryption     Set encryption algorithm for protection suite
  exit           Exit from ISAKMP protection suite configuration mode
  group          Set the Diffie-Hellman group
  hash           Set hash algorithm for protection suite
  lifetime       Set lifetime for ISAKMP security association
  no             Negate a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
  client  Set client configuration policy
  enable  Enable ISAKMP
  key     Set pre-shared key for remote peer
  policy  Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
  dynamic-map  Specify a dynamic crypto map template
  ipsec        Configure IPSEC policy
  isakmp       Configure ISAKMP policy
  key          Long term key operations
  map          Enter a crypto map
Router(config)#crypto ipsec ?
  security-association  Security association parameters
  transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
  ah-md5-hmac  AH-HMAC-MD5 transform
  ah-sha-hmac  AH-HMAC-SHA transform
  esp-3des    ESP transform using 3DES(EDE) cipher (168 bits)
  esp-aes     ESP transform using AES cipher
  esp-des     ESP transform using DES cipher (56 bits)
  esp-md5-hmac  ESP transform using HMAC-MD5 auth
  esp-sha-hmac  ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface fastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if)#crypto map cry-map
*Jan  3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON

```

## IPsec VPN\_Client:

The window is displayed as below by clicking **VPN > IPsec > Tunnel**.

| General           | Tunnel | Status      | x509    |              |               |   |
|-------------------|--------|-------------|---------|--------------|---------------|---|
| ^ Tunnel Settings |        |             |         |              |               |   |
| Index             | Enable | Description | Gateway | Local Subnet | Remote Subnet | + |

Click **+** button and set the parameters of IPsec Client as below.

**Tunnel**

^ General Settings

**Index**

**Enable**  ON  OFF

**Description**

**Gateway**  ?

**Mode**  v

**Protocol**  v

**Local Subnet**  ?

**Remote Subnet**  ?

^ IKE Settings

**Negotiation Mode**  v

**Authentication Algorithm**  v

**Encryption Algorithm**  v

**IKE DH Group**  v

**Authentication Type**  v

**PSK Secret**

**Local ID Type**  v

**Remote ID Type**  v

**IKE Lifetime**  ?

^ SA Settings

|                          |                                       |   |   |
|--------------------------|---------------------------------------|---|---|
| Encrypt Algorithm        | <input type="text" value="3DES"/>     | v |   |
| Authentication Algorithm | <input type="text" value="MD5"/>      | v |   |
| PFS Group                | <input type="text" value="DHgroup2"/> | v |   |
| SA Lifetime              | <input type="text" value="28800"/>    |   | ? |
| DPD Interval             | <input type="text" value="60"/>       |   | ? |
| DPD Failures             | <input type="text" value="180"/>      |   | ? |

^ Advanced Settings

|                    |                                                                                     |  |   |
|--------------------|-------------------------------------------------------------------------------------|--|---|
| Enable Compression | <input type="checkbox" value="ON"/> <input checked="" type="checkbox" value="OFF"/> |  |   |
| Expert Options     | <input type="text"/>                                                                |  | ? |

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between server and client is as below.

```

Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
  authentication  Set authentication method for protection suite
  encryption     Set encryption algorithm for protection suite
  exit           Exit from ISAKMP protection suite configuration mode
  group          Set the Diffie-Hellman group
  hash           Set hash algorithm for protection suite
  lifetime       Set lifetime for ISAKMP security association
  no             Negate a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
  client  Set client configuration policy
  enable  Enable ISAKMP
  key     Set pre-shared key for remote peer
  policy  Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
  dynamic-map  Specify a dynamic crypto map template
  ipsec        Configure IPSEC policy
  isakmp       Configure ISAKMP policy
  key          Long term key operations
  map          Enter a crypto map
Router(config)#crypto ipsec ?
  security-association  Security association parameters
  transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
  ah-md5-hmac  AH-HMAC-MD5 transform
  ah-sha-hmac  AH-HMAC-SHA transform
  esp-3des    ESP transform using 3DES (EDE) cipher (168 bits)
  esp-aes     ESP transform using AES cipher
  esp-des     ESP transform using DES cipher (56 bits)
  esp-md5-hmac  ESP transform using HMAC-MD5 auth
  esp-sha-hmac  ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface fastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if)#crypto map cry-map
*Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON
    
```

IKE Setting in Client must be consistent with server.

SA Setting in Client must be consistent with server.

^ Tunnel Settings

|               |                                                                                     |   |   |
|---------------|-------------------------------------------------------------------------------------|---|---|
| Index         | <input type="text" value="1"/>                                                      |   |   |
| Enable        | <input checked="" type="checkbox" value="ON"/> <input type="checkbox" value="OFF"/> |   |   |
| Description   | <input type="text"/>                                                                |   |   |
| Gateway       | <input type="text" value="58.1.1.1"/>                                               |   | ? |
| Mode          | <input type="text" value="Tunnel"/>                                                 | v |   |
| Protocol      | <input type="text" value="ESP"/>                                                    | v |   |
| Local Subnet  | <input type="text" value="192.168.1.0"/>                                            |   | ? |
| Remote Subnet | <input type="text" value="255.255.255.0"/>                                          |   | ? |

^ IKE Settings

|                          |                                         |   |   |
|--------------------------|-----------------------------------------|---|---|
| Negotiation Mode         | <input type="text" value="Main"/>       | v |   |
| Authentication Algorithm | <input type="text" value="MD5"/>        | v |   |
| Encrypt Algorithm        | <input type="text" value="3DES"/>       | v |   |
| IKE DH Group             | <input type="text" value="MODP(1024)"/> | v |   |
| Authentication Type      | <input type="text" value="PSK"/>        | v |   |
| PSK Secret               | <input type="text" value="*****"/>      |   |   |
| Local ID Type            | <input type="text" value="Default"/>    | v |   |
| Remote ID Type           | <input type="text" value="Default"/>    | v |   |
| IKE Lifetime             | <input type="text" value="86400"/>      |   | ? |

^ SA Settings


|                          |                                         |   |   |
|--------------------------|-----------------------------------------|---|---|
| Encrypt Algorithm        | <input type="text" value="3DES"/>       | v |   |
| Authentication Algorithm | <input type="text" value="MD5"/>        | v |   |
| PFS Group                | <input type="text" value="MODP(1024)"/> | v |   |
| SA Lifetime              | <input type="text" value="28800"/>      |   | ? |
| DPD Interval             | <input type="text" value="60"/>         |   | ? |
| DPD Failures             | <input type="text" value="180"/>        |   | ? |

^ Advanced Settings

|                    |                                                                                     |  |  |
|--------------------|-------------------------------------------------------------------------------------|--|--|
| Enable Compression | <input type="checkbox" value="ON"/> <input checked="" type="checkbox" value="OFF"/> |  |  |
|--------------------|-------------------------------------------------------------------------------------|--|--|

## 4.3.2 OpenVPN

OpenVPN supports two modes, including Client and P2P. Here takes P2P as an example.



The configuration of two points is as follows.

### OpenVPN\_Server:

Generate relevant OpenVPN certificate on the server side firstly, and refer to the following commands to configuration the Server:

```
local 202.96.1.100
mode server
port 1194
proto udp
dev tun
tun-mtu 1500
fragment 1500
ca ca.crt
cert Server01.crt
key Server01.key
dh dh1024.pem
server 10.8.0.0 255.255.255.0
ifconfig-pool-persist ipp.txt
push "route 192.168.3.0 255.255.255.0"
client-config-dir ccd
route 192.168.1.0 255.255.255.0
keepalive 10 120
cipher BF-CBC
comp-lzo
max-clients 100
persist-key
persist-tun
status openvpn-status.log
```

verb 3

**Note:** For more configuration details, please contact your technical support engineer.

## OpenVPN\_Client:

Click **VPN > OpenVPN > OpenVPN** as below.


| OpenVPN           | Status | x509        |      |          |                |                |   |
|-------------------|--------|-------------|------|----------|----------------|----------------|---|
| ^ Tunnel Settings |        |             |      |          |                |                |   |
| Index             | Enable | Description | Mode | Protocol | Server Address | Interface Type | + |

Click **+** to configure the Client01 as below.

| ^ General Settings     |                                                                     |
|------------------------|---------------------------------------------------------------------|
| Index                  | <input type="text" value="1"/>                                      |
| Enable                 | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description            | <input type="text" value="Client01"/>                               |
| Mode                   | <input type="text" value="Client"/> v                               |
| Protocol               | <input type="text" value="UDP"/> v                                  |
| Server Address         | <input type="text" value="202.96.1.100"/>                           |
| Server Port            | <input type="text" value="1194"/>                                   |
| Interface Type         | <input type="text" value="TUN"/> v                                  |
| Authentication Type    | <input type="text" value="X509CA"/> v ?                             |
| Encrypt Algorithm      | <input type="text" value="BF"/> v                                   |
| Renegotiation Interval | <input type="text" value="86400"/> ?                                |
| Keepalive Interval     | <input type="text" value="20"/> ?                                   |
| Keepalive Timeout      | <input type="text" value="120"/> ?                                  |
| Private Key Password   | <input type="password" value="•••••"/>                              |
| Enable Compression     | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT             | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Verbose Level          | <input type="text" value="3"/> v ?                                  |
| ^ Advanced Settings    |                                                                     |
| Enable HMAC Firewall   | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable PKCS#12         | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable nsCertType      | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Expert Options         | <input type="text" value="fragment 1500"/> ?                        |

When finished, click **Submit > Save & Apply** for the configuration to take effect.

### 4.3.3 GRE VPN




The configuration of two points is as follows.

The window is displayed as below by clicking **VPN > GRE > GRE**.



#### GRE-1:

Click **+** button and set the parameters of GRE-1 as below.



When finished, click **Submit > Save & Apply** for the configuration to take effect.

### GRE-2:

Click **+** button and set the parameters of GRE-1 as below.

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between GRE-1 and GRE-2 is as below.

| GRE-1                                                 | GRE-2                                                 |
|-------------------------------------------------------|-------------------------------------------------------|
|                                                       |                                                       |
| Remote IP Address: 59.1.1.1 (GRE-1 public IP)         | Remote IP Address: 58.1.1.1 (GRE-2 public IP)         |
| Local Virtual IP Address: 10.8.0.1 (GRE-1 tunnel IP)  | Local Virtual IP Address: 10.8.0.2 (GRE-2 tunnel IP)  |
| Remote Virtual IP Address: 10.8.0.2 (GRE-2 tunnel IP) | Remote Virtual IP Address: 10.8.0.1 (GRE-1 tunnel IP) |
| Enable NAT: OFF (set the same secret as GRE-2)        | Enable NAT: OFF (set the same secret as GRE-1)        |
| Secrets: *****                                        | Secrets: *****                                        |

## Chapter 5 Introductions for CLI

### 5.1 What Is CLI

The R3000 command-line interface (CLI) is a software interface providing another way to set the parameters of equipment from the [SSH](#) or through a [telnet](#) network connection.

#### Route login:

Router login: admin

Password: admin

#

#### CLI commands:

# ? (**Note:** the '?' won't display on the page.)

|            |                                                                 |
|------------|-----------------------------------------------------------------|
| !          | Comments                                                        |
| add        | Add a list entry of configuration                               |
| clear      | Clear statistics                                                |
| config     | Configuration operation                                         |
| debug      | Output debug information to the console                         |
| del        | Delete a list entry of configuration                            |
| exit       | Exit from the CLI                                               |
| help       | Display an overview of the CLI syntax                           |
| ping       | Send messages to network hosts                                  |
| reboot     | Halt and perform a cold restart                                 |
| route      | Static route modify dynamically, this setting will not be saved |
| set        | Set system configuration                                        |
| show       | Show system configuration                                       |
| status     | Show running system information                                 |
| tftpupdate | Update firmware using tftp                                      |
| traceroute | Print the route packets trace to network host                   |
| urlupdate  | Update firmware using http or ftp                               |
| ver        | Show version of firmware                                        |

## 5.2 How to Configure the CLI

Following is a table about the description of help and the error should be encountered in the configuring program.

| Commands /tips                              | Description                                                                                                                                                                                                                 |
|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ?                                           | Typing a question mark “?” will show you the help information.                                                                                                                                                              |
| Ctrl+c                                      | Press these two keys at the same time, except its “copy” function but also can be used for “break” out of the setting program.                                                                                              |
| Syntax error: The command is not completed  | Command is not completed.                                                                                                                                                                                                   |
| Tick space key+ Tab key                     | It can help you finish you command.<br>Example:<br># config (tick Enter key)<br>Syntax error: The command is not completed<br># config (tick space key+ Tab key)<br>commit                    save_and_apply    loaddefault |
| # config save_and_apply /<br>#config commit | When your setting finished, you should enter those commands to make your setting take effect on the device.<br><b>Note:</b> Commit and save_and_apply plays the same role.                                                  |

### Quick Start with Configuration Examples

The best and quickest way to master CLI is firstly to view all features from the webpage and then read all CLI commands at a time, finally learn to configure it with some reference examples.

#### Example 1: Show current version

```
# status system
hardware_version = 1.2
firmware_version = "3.0.0"
kernel_version = 4.1.0
device_model = R3000
serial_number = 201612221052
uptime = "0 days, 00:40:21"
system_time = "Mon Feb 27 09:52:52 2017"
```

#### Example 2: Update firmware via tftp

```
# tftpupdate (space+?)
  firmware   New firmware
# tftpupdate firmware (space+?)
  String    Firmware name
# tftpupdate firmware R3000-firmware-sysupgrade-unknown.bin host 192.168.100.99 //enter a new firmware name
Downloading
R3000-firmware-s 100% |*****| 5018k  0:00:00 ETA
```

```

Flashing
Checking 100%
Decrypting 100%
Flashing 100%
Verifying 100%
Verify Success
upgrade success //update success
# config save_and_apply
OK // save and apply current configuration, make you configuration effect

```

### Example 3: Set link-manager

```

# set
# set
  at_over_telnet      AT Over Telnet
  cellular            Cellular
  ddns                Dynamic DNS
  ethernet            Ethernet
  event              Event Management
  firewall            Firewall
  gre                 GRE
  ipsec               IPsec
  lan                 Local Area Network
  link_manager        Link Manager
  ntp                 NTP
  openvpn             OpenVPN
  reboot              Automatic Reboot
  RobustLink          RobustLink
  route               Route
  sms                 SMS
  snmp                SNMP agent
  ssh                 SSH
  syslog              Syslog
  system              System
  user_management     User Management
  vrrp                VRRP
  web_server          Web Server
# set link_manager
  primary_link        Primary Link
  backup_link         Backup Link
  backup_mode         Backup Mode
  emergency_reboot    Emergency Reboot
  link                Link Settings
# set link_manager primary_link (space+?)
Enum Primary Link (wwan1/wwan2/wan)

```

```

# set link_manager primary_link wwan1 //select "wwan1" as primary_link
OK //setting succeed
# set link_manager link 1
  type          Type
  desc          Description
  connection_type Connection Type
  wwan          WWAN Settings
  static_addr   Static Address Settings
  pppoe         PPPoE Settings
  ping         Ping Settings
  mtu           MTU
  dns1_overridden Overridden Primary DNS
  dns2_overridden Overridden Secondary DNS
# set link_manager link 1 type wwan1
OK
# set link_manager link 1 wwan
  auto_apn          Automatic APN Selection
  apn              APN
  username          Username
  password         Password
  dialup_number    Dialup Number
  auth_type        Authentication Type
  aggressive_reset Aggressive Reset
  switch_by_data_allowance Switch SIM By Data Allowance
  data_allowance   Data Allowance
  billing_day      Billing Day
# set link_manager link 1 wwan switch_by_data_allowance true
OK
#
# set link_manager link 1 wwan data_allowance 100 //open cellular switch_by_data_traffic
OK //setting succeed
# set link_manager link 1 wwan billing_day 1 //setting specifies the day of month for billing
OK // setting succeed
...
# config save_and_apply
OK // save and apply current configuration, make you configuration effect

```

#### Example 4: Set LAN IP address

```

# show lan all
network {
  id = 1
  interface = lan0
  ip = 192.168.0.1
  netmask = 255.255.255.0
}

```

```
mtu = 1500
dhcp {
    enable = true
    mode = server
    relay_server = ""
    pool_start = 192.168.0.2
    pool_end = 192.168.0.100
    netmask = 255.255.255.0
    gateway = ""
    primary_dns = ""
    secondary_dns = ""
    wins_server = ""
    lease_time = 120
    expert_options = ""
    debug_enable = false
}
}
multi_ip {
    id = 1
    interface = lan0
    ip = 172.16.24.24
    netmask = 255.255.0.0
}
#
# set lan
network      Network Settings
multi_ip     Multiple IP Address Settings
vlan         VLAN
# set lan network 1(space+?)
interface    Interface
ip           IP Address
netmask      Netmask
mtu          MTU
dhcp         DHCP Settings
# set lan network 1 interface lan0
OK
# set lan network 1 ip 172.16.24.24           //set IP address for lan
OK                                           //setting succeed
# set lan network 1 netmask 255.255.0.0
OK
#
...
# config save_and_apply
OK                                           // save and apply current configuration, make you configuration effect
```

## Example 5: CLI for setting Cellular

```
# show cellular all
sim {
    id = 1
    card = sim1
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_gsm_850 = false
    band_gsm_900 = false
    band_gsm_1800 = false
    band_gsm_1900 = false
    band_wcdma_850 = false
    band_wcdma_900 = false
    band_wcdma_1900 = false
    band_wcdma_2100 = false
    band_lte_800 = false
    band_lte_850 = false
    band_lte_900 = false
    band_lte_1800 = false
    band_lte_1900 = false
    band_lte_2100 = false
    band_lte_2600 = false
    band_lte_1700 = false
    band_lte_700 = false
    band_tdd_lte_2600 = false
    band_tdd_lte_1900 = false
    band_tdd_lte_2300 = false
    band_tdd_lte_2500 = false
}
sim {
    id = 2
    card = sim2
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_gsm_850 = false
    band_gsm_900 = false
    band_gsm_1800 = false
    band_gsm_1900 = false
    band_wcdma_850 = false
    band_wcdma_900 = false
```

```

band_wcdma_1900 = false
band_wcdma_2100 = false
band_lte_800 = false
band_lte_850 = false
band_lte_900 = false
band_lte_1800 = false
band_lte_1900 = false
band_lte_2100 = false
band_lte_2600 = false
band_lte_1700 = false
band_lte_700 = false
band_tdd_lte_2600 = false
band_tdd_lte_1900 = false
band_tdd_lte_2300 = false
band_tdd_lte_2500 = false
}
# set(space+?)
at_over_telnet    cellular      ddns          dhcp          dns
event            firewall     ipsec         lan           link_manager
ntp              openvpn     reboot       route        serial_port
sms              snmp        syslog       system       user_management
vrrp

# set cellular(space+?)
  sim    SIM Settings
# set cellular sim(space+?)
  Integer  Index (1..2)

# set cellular sim 1(space+?)
  card                SIM Card
  phone_number        Phone Number
  extra_at_cmd        Extra AT Cmd
  network_type        Network Type
  band_select_type    Band Select Type
  band_gsm_850        GSM 850
  band_gsm_900        GSM 900
  band_gsm_1800       GSM 1800
  band_gsm_1900       GSM 1900
  band_wcdma_850      WCDMA 850
  band_wcdma_900      WCDMA 900
  band_wcdma_1900     WCDMA 1900
  band_wcdma_2100     WCDMA 2100
  band_lte_800        LTE 800 (band 20)
  band_lte_850        LTE 850 (band 5)
  band_lte_900        LTE 900 (band 8)
  band_lte_1800       LTE 1800 (band 3)

```

```

band_lte_1900      LTE 1900 (band 2)
band_lte_2100      LTE 2100 (band 1)
band_lte_2600      LTE 2600 (band 7)
band_lte_1700      LTE 1700 (band 4)
band_lte_700       LTE 700 (band 17)
band_tdd_lte_2600  TDD LTE 2600 (band 38)
band_tdd_lte_1900  TDD LTE 1900 (band 39)
band_tdd_lte_2300  TDD LTE 2300 (band 40)
band_tdd_lte_2500  TDD LTE 2500 (band 41)
# set cellular sim 1 phone_number 18620435279
OK
...
# config save_and_apply
OK                                     // save and apply current configuration, make you configuration effect

```

### 5.3 Commands Reference

| Commands | Syntax                  | Description                                                                                                                                           |
|----------|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Debug    | Debug <i>parameters</i> | Turn on or turn off debug function                                                                                                                    |
| Show     | Show <i>parameters</i>  | Show current configuration of each function , if we need to see all please using “show running ”                                                      |
| Set      | Set <i>parameters</i>   | All the function parameters are set by commands set and add, the difference is that set is for the single parameter and add is for the list parameter |
| Add      | Add <i>parameters</i>   |                                                                                                                                                       |

**Note:** Download the config.XML file from the configured web browser. The command format can refer to the config.XML file format.

# Glossary

| Abbr.    | Description                                                |
|----------|------------------------------------------------------------|
| AC       | Alternating Current                                        |
| APN      | Access Point Name                                          |
| ASCII    | American Standard Code for Information Interchange         |
| CE       | Conformité Européene (European Conformity)                 |
| CHAP     | Challenge Handshake Authentication Protocol                |
| CLI      | Command Line Interface for batch scripting                 |
| CSD      | Circuit Switched Data                                      |
| CTS      | Clear to Send                                              |
| dB       | Decibel                                                    |
| dBi      | Decibel Relative to an Isotropic radiator                  |
| DC       | Direct Current                                             |
| DCD      | Data Carrier Detect                                        |
| DCE      | Data Communication Equipment (typically modems)            |
| DCS 1800 | Digital Cellular System, also referred to as PCN           |
| DI       | Digital Input                                              |
| DO       | Digital Output                                             |
| DSR      | Data Set Ready                                             |
| DTE      | Data Terminal Equipment                                    |
| DTMF     | Dual Tone Multi-frequency                                  |
| DTR      | Data Terminal Ready                                        |
| EDGE     | Enhanced Data rates for Global Evolution of GSM and IS-136 |
| EMC      | Electromagnetic Compatibility                              |
| EMI      | Electro-Magnetic Interference                              |
| ESD      | Electrostatic Discharges                                   |
| ETSI     | European Telecommunications Standards Institute            |
| EVDO     | Evolution-Data Optimized                                   |
| FDD LTE  | Frequency Division Duplexing Long Term Evolution           |
| GND      | Ground                                                     |
| GPRS     | General Packet Radio Service                               |
| GRE      | generic route encapsulation                                |
| GSM      | Global System for Mobile Communications                    |
| HSPA     | High Speed Packet Access                                   |
| ID       | identification data                                        |
| IMEI     | International Mobile Equipment Identity                    |
| IP       | Internet Protocol                                          |
| IPsec    | Internet Protocol Security                                 |
| kbps     | kbits per second                                           |

| Abbr.       | Description                                                   |
|-------------|---------------------------------------------------------------|
| L2TP        | Layer 2 Tunneling Protocol                                    |
| LAN         | local area network                                            |
| LED         | Light Emitting Diode                                          |
| M2M         | Machine to Machine                                            |
| MAX         | Maximum                                                       |
| Min         | Minimum                                                       |
| MO          | Mobile Originated                                             |
| MS          | Mobile Station                                                |
| MT          | Mobile Terminated                                             |
| OpenVPN     | Open Virtual Private Network                                  |
| PAP         | Password Authentication Protocol                              |
| PC          | Personal Computer                                             |
| PCN         | Personal Communications Network, also referred to as DCS 1800 |
| PCS         | Personal Communication System, also referred to as GSM 1900   |
| PDU         | Protocol Data Unit                                            |
| PIN         | Personal Identity Number                                      |
| PLCs        | Program Logic Control System                                  |
| PPP         | Point-to-point Protocol                                       |
| PPTP        | Point to Point Tunneling Protocol                             |
| PSU         | Power Supply Unit                                             |
| PUK         | Personal Unblocking Key                                       |
| R&TTE       | Radio and Telecommunication Terminal Equipment                |
| RF          | Radio Frequency                                               |
| RTC         | Real Time Clock                                               |
| RTS         | Request to Send                                               |
| RTU         | Remote Terminal Unit                                          |
| Rx          | Receive Direction                                             |
| SDK         | Software Development Kit                                      |
| SIM         | subscriber identification module                              |
| SMA antenna | Stubby antenna or Magnet antenna                              |
| SMS         | Short Message Service                                         |
| SNMP        | Simple Network Management Protocol                            |
| TCP/IP      | Transmission Control Protocol / Internet Protocol             |
| TE          | Terminal Equipment, also referred to as DTE                   |
| Tx          | Transmit Direction                                            |
| UART        | Universal Asynchronous Receiver-transmitter                   |
| UMTS        | Universal Mobile Telecommunications System                    |
| USB         | Universal Serial Bus                                          |
| USSD        | Unstructured Supplementary Service Data                       |
| VDC         | Volts Direct current                                          |
| VLAN        | Virtual Local Area Network                                    |

| <b>Abbr.</b> | <b>Description</b>            |
|--------------|-------------------------------|
| VPN          | Virtual Private Network       |
| VSWR         | Voltage Stationary Wave Ratio |
| WAN          | Wide Area Network             |

**Guangzhou Robustel LTD**

Address: 3rd Floor, Building F, Kehui Park, No.95 Dagan Road,  
Guangzhou, China 510660

Tel: 86-20-29019902

Email: [info@robustel.com](mailto:info@robustel.com)